



# Parts Catalog

Mazda RX-7

('86-'88)























FC33-10001-  
FC351-10001-






August 1991

**MAZDA**






# PICTORIAL INDEX

<p><b>1000</b></p>  <p>Engine Gaskets</p>  <p>Transmission Gaskets</p> <p>SHORT ENGINE &amp; GASKIT SETS</p>	<p><b>1</b> 1030</p>  <p>ROTOR HOUSING</p>	<p><b>2</b> 1040</p>  <p>OIL PAN &amp; FRONT &amp; REAR HOUSINGS</p>	<p><b>3</b> 1100</p>  <p>ECCENTRIC SHAFT &amp; FLYWHEEL</p>	<p><b>4</b> 1110</p>  <p>ROTOR &amp; RELATED</p>	<p><b>5</b> 1400</p>  <p>OIL PUMP &amp; FILTER</p>
<p><b>17</b> 4600</p>  <p>Given in Chassis Group</p> <p>CHANGE CONTROLS (MANUAL)</p>	<p><b>18</b> 1960</p>  <p>GASKET &amp; SEAL KIT (AUTOMATIC)</p> <h2 style="text-align: center;">ROTARY ENGINE (1/2)</h2>  <p style="text-align: center;">As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts catalog.</p>				<p><b>6</b> 1600</p>  <p>CLUTCH (MANUAL)</p>
<p><b>16</b> 3900</p>  <p>Given in Chassis Group</p> <p>FRAME &amp; TRANSMISSION MOUNTINGS</p>					<p><b>7</b> 1700</p>  <p>TRANSMISSION CASE (MANUAL)</p>
<p><b>15</b> 1950</p>  <p>MANUAL LINKAGE (AUTOMATIC TRANSMISSION)</p>	<p><b>14</b> 1940</p>  <p>LOW, REVERSE &amp; GOVERNOR (AUTOMATIC TRANSMISSION)</p>	<p><b>13</b> 1930</p>  <p>CLUTCH &amp; PLANETARY GEARS (AUTOMATIC TRANSMISSION)</p>	<p><b>12</b> 1920</p>  <p>CASE &amp; MAIN CON. ROLLS (AUTOMATIC TRANSMISSION)</p>	<p><b>11</b> 1910</p>  <p>CONVERTER OIL PUMP &amp; PIPING (AUTOMATIC TRANSMISSION)</p>	<p><b>8</b> 1710</p>  <p>TRANSMISSION GEARS (MANUAL)</p>
					<p><b>9</b> 1720</p>  <p>CHANGE CONTROLS (MANUAL)</p>






# PICTORIAL INDEX























## ROTARY ENGINE (2/2)



As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts catalog.




# PICTORIAL INDEX

<p><b>1</b> 2500</p>  <p>PROPELLER SHAFT</p>	<p><b>2</b> 2550</p>  <p>REAR DRIVE SHAFTS</p>	<p>2600</p>  <p>REAR AXLE</p>	<p><b>3</b> 2610</p>  <p>REAR BRAKE MECHANISMS</p>	<p><b>4</b> 2710</p>  <p>DIFFERENTIAL (REAR)</p>	<p><b>5</b> 2800 2810</p>  <p>REAR STABILIZER</p> <p>REAR SUSPENSION MECHANISMS</p>
<p><b>16</b> 4600</p>  <p>(MANUAL)</p>  <p>(AUTOMATIC)</p> <p>CHANGE CONTROLS</p>	<p><b>17</b> 1720</p>  <p>Given in Engine Group</p> <p>CHANGE CONTROLS (MANUAL)</p>	<p style="text-align: center;"><b>CHASSIS (1/2)</b></p> 			<p>2830</p>  <p>REAR LOWER ARMS &amp; SUB FRAME</p>
<p><b>15</b> 4000</p>  <p>EX SYSTEM</p>	<p><b>6</b> 3200</p>  <p>STEERING WHEEL</p>				<p><b>6</b> 3200</p>  <p>STEERING WHEEL</p>
<p><b>14</b> 3900</p>  <p>FRONT &amp; TENSION MOUNTINGS</p>		<p><b>8</b> 3220      3230</p>  <p>STEERING GEAR</p> <p>STEERING LINKAGE SYSTEM</p>			
<p><b>13</b> 3410</p>  <p>CROSSMEMBER &amp; STABILIZER</p>	<p><b>12</b> 3400</p>  <p>FRONT SUSPENSION</p>	<p><b>11</b> 3300</p>  <p>FRONT AXLE &amp; BRAKES</p>	<p><b>10</b></p>  <p>POWER STEERING SYSTEM</p>		

*As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts catalog.*

# PICTORIAL INDEX

**1** 3700




TIRE & JACK

**2** 4140




CLUTCH RELEASE & MASTER CYLINDERS

**3** 4160




ACCELERATOR CONTROLS

**4** 4200




FUEL TANK

**5** 4300



CLUTCH & BRAKE


## CHASSIS (2/2)



As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts catalog.

**6**

**7** 4340



TANDEM MASTER CYL & VACUUM POWER ASSIST SYSTEM

**8** 4360



BRAKE PIPING

**11** 4370




ANTI-LOCK BRAKE SYSTEM

**10** 4500



























FUEL & EVAPORATOR PIPING

**9** 4400




























PARKING BRAKE SYSTEM

# PICTORIAL INDEX

<b>1 0900</b>  <b>KEY SETS</b>	<b>2 5020</b>  <b>HEAD LAMP CLEANER</b>	<b>3 5100</b>  <b>HEAD LAMPS</b>	<b>4 5103</b>  <b>HEAD LAMP RETRACTORS</b>	<b>5 5105</b>  <b>FRONT COMBINATION LAMPS</b>	<b>6 5110</b>  <b>REAR COMBINATION LAMPS</b>
<b>19 6704</b>  <b>WIRING HARNESS CLAMPS</b>	<b>20 6720</b>  <b>WINDSHIELD WASHER</b>	<b>21 6730</b>  <b>WINDSHIELD WIPERS</b>	<b>22 675C</b>  <b>WINDOW WIPER &amp; WASHER (REAR)</b>	<b>7 5120</b>  <b>LICENSE LAMPS</b>	
<b>18 6703</b>  <b>WIRING HARNESSSES (DOOR, FLOOR/CEILING)</b>	<p style="text-align: center;"><b>BODY (1/4)</b></p> 				<b>8 5125</b>  <b>INTERIOR LAMPS</b>
<b>17 6702</b>  <b>WIRING HARNESSSES (DASHBOARD)</b>					<b>9 5130</b>  <b>OVERHEAD CONSOLE</b>
<b>16 6701</b>  <b>WIRING HARNESSSES (ENGINE &amp; T/MISSION)</b>					<b>10 6600</b>  <b>SWITCHES &amp; RELAYS (ENGINE)</b>
<b>15 6700</b>  <b>WIRING HARNESSSES (FRONT &amp; REAR)</b>	<b>14 6640</b>  <b>AUTO CRUISE CONTROL SYSTEM</b>	<b>13 6635</b>  <b>HORNS</b>	<b>12 6630</b>  <b>RELAYS &amp; C.P.U. (BODY)</b>	<b>11 6620</b>  <b>DOOR, PARKING LAMP &amp; KICKDOWN SWITCHES</b>	<b>10 6600</b>  <b>SWITCHES &amp; RELAYS (ENGINE)</b>

















As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog.

# PICTORIAL INDEX

<p><b>1 5000</b></p>  <p><b>FRONT BUMPER</b></p>	<p><b>2 5005</b></p>  <p><b>RADIATOR GRILLE</b></p>	<p><b>3 5010</b></p>  <p><b>REAR BUMPER</b></p>	<p><b>4 5030</b></p>  <p><b>WINDOW MOULDINGS</b></p>	<p><b>5 5040</b></p>  <p><b>BODY MOULDINGS</b></p>	<p><b>6 5060</b></p>  <p><b>SIDE PROTECTORS</b></p>
<p><b>20 5840</b></p>  <p><b>FRONT DOOR TRIMS &amp; RELATED PARTS</b></p>	<p><b>21 6200 6230</b></p>  <p><b>LIFT GATE MECHANISMS</b></p>	<p><b>22 6300</b></p>  <p><b>WINDOW GLASSES</b></p>	<p><b>23 6330</b></p>  <p><b>SUNROOF</b></p>	<p><b>24 7800</b></p>  <p><b>SPOILERS &amp; RELATED PARTS</b></p>	<p><b>7 5170</b></p>  <p><b>ORNAMENTS</b></p>
<p><b>19 5830</b></p>  <p><b>FRONT DOOR MECHANISMS</b></p>	<p><b>BODY (2/4)</b></p> 				<p><b>8 5180</b></p>  <p><b>COWL &amp; EXTRACTOR GRILLES</b></p>
<p><b>18 5800</b></p>  <p><b>FRONT DOORS</b></p>					<p><b>9 5230</b></p>  <p><b>BONNET</b></p>
<p><b>17 5390</b></p>  <p><b>FLOOR ATTACHMENTS</b></p>					<p><b>10 5260</b></p>  <p><b>TRUNK LID</b></p>
<p><b>16 5370</b></p>  <p><b>BODY PANELS (FLOOR)</b></p>	<p><b>15 5360</b></p>  <p><b>BODY PANELS (ROOF)</b></p>	<p><b>14 5340</b></p>  <p><b>BODY PANELS (SIDE)</b></p>	<p><b>13 5330</b></p>  <p><b>BODY PANELS (DASH &amp; COWL PANEL)</b></p>	<p><b>12 5320</b></p>  <p><b>BODY PANELS (FENDER &amp; WHEEL APRON)</b></p>	<p><b>11 5310</b></p>  <p><b>BODY PANELS (FRONT)</b></p>

As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog.




















# PICTORIAL INDEX

<p><b>1 5500</b></p>  <p><b>DASHBOARD EQUIPMENTS</b></p>	<p><b>2 5520</b></p>  <p><b>METER HOOD</b></p>	<p><b>3 5530</b></p>  <p><b>SPEEDOMETER CABLE</b></p>	<p><b>4 5540</b></p>  <p><b>METERS</b></p>	<p><b>5 5560</b></p>  <p><b>DASHBOARD &amp; RELATED PARTS</b></p>	<p><b>6 5570</b></p>  <p><b>CONSOLE</b></p>
<p><b>BODY (3/4)</b></p> 					
<p><b>7 6100</b></p>  <p>6120</p>  <p>6110</p>  <p>6115</p> <p><b>HEATER</b></p>					
<p><b>8 6130</b></p>  <p>6140</p>  <p>6150</p> <p><b>AIR CONDITIONER</b></p>					
<p><b>12 6615</b></p>  <p><b>POWER WINDOW SWITCHES</b></p>					
<p><b>11 6612</b></p>  <p><b>CLUSTER SWITCH</b></p>					
<p><b>10 6611</b></p>  <p><b>COMBINATION SWITCH</b></p>					
<p><b>9 6610</b></p>  <p><b>DASHBOARD SWITCHES (MANUAL OPERATING)</b></p>					

This illustration is prepared to be applicable to all models. Some parts are different in specifications from the parts listed in this parts Catalog.



# PICTORIAL INDEX

<p><b>1 5580</b></p>  <p>VENTILATOR</p>	<p><b>2 5700</b></p>  <p>FRONT SEATS</p>	<p><b>3 5750</b></p>  <p>REAR SEATS</p>	<p><b>4 5790</b></p>  <p>SEAT BELTS</p>	<p><b>5 6680</b></p>  <p>AUDIO SYSTEMS (RADIO &amp; TAPE DECK)</p>	<p><b>6 6682</b></p>  <p>AUDIO SYSTEMS (ANTENNA &amp; SPEAKER)</p>	
<p><b>BODY (4/4)</b></p> 						<p><b>7 6684</b></p>  <p>AUDIO SYSTEMS (NOISE SUPPRESSOR &amp; EARTHCORD)</p>
<p><b>18 7250</b></p>  <p>REAR WINDOW GLASSES &amp; TRIMS</p>	<p><b>8 6800</b></p>  <p>CEILING TRIMS</p>					
<p><b>17 6930</b></p>  <p>CAUTION PLATES &amp; LABELS</p>	<p><b>9 6820</b></p>  <p>PILLAR TRIMS</p>					
<p><b>16 6900</b></p>  <p>VISORS, ASSIST HANDLES &amp; MIRRORS</p>	<p><b>10 6810</b></p>  <p>ROLLERBAR</p>					
<p><b>15 6870</b></p>  <p>SERVICE TOOLS</p>	<p><b>14 6865</b></p>  <p>TRIM CLIPS &amp; FASTENERS</p>					
<p><b>13 6860</b></p>  <p>FLOOR MATS &amp; PADS</p>	<p><b>12 6845</b></p>  <p>STORAGE BOX</p>					
<p><b>11 6840</b></p>  <p>TRIMS &amp; SCUFF PLATES</p>						

As this illustration is prepared to be applicable to all models, some parts are different in specifications from the parts listed in this parts Catalog.

## MODEL IDENTIFICATION

MDL NO.	ENG*		T/M	BODY		ROOF	SUSP		DIFF	BRK		SUSP	SEAT	PERIOD		YEAR			TRIM LEVEL							VIN (CHASSIS #)	COMPLETE ASSEMBLY UNIT								
	W/O	W/TURBO	5	A	C	N	S	W/O	W/O	N	L	W/O	W/O	N	H	2	2	F	T	1	1	1	B	L	S		S	G	G	T	C	1	ENGINE	T/MISSION	CABIN
	TURBO	TURBO	SPEED	AUTO	COUPE	CONV	NORM	SUNROOF	W/O	W/O	NORM	LIM	W/O	W/O	NORM	HARD	SEATER	FROM	TO	1986	1987	1988	BASE	PKG	SPORT		TURBO	CONV	10TH ANN						
FB01	X		X	X	X	X	X	X	X	X	X	X	X	8/85	12/88	X	X	X	X	X											FC33*-100001-	N326-02-000	M582-03-000	FB01-07-000	
FB02	X			X	X	X	X	X	X	X	X	X	X	8/85	12/88	X	X	X	X	X											FC33*-100001-	N327-02-000	BU17-19-090F	FB02-07-000	
FB03	X		X	X		X	X	X	X	X	X	X	X	8/85	12/88	X	X	X		X	X										FC33*-100001-	N326-02-000	M582-03-000	FB03-07-000	
FB04	X			X	X		X	X	X	X	X	X	X	8/85	12/88	X	X	X		X	X										FC33*-100001-	N327-02-000	BU17-19-090F	FB04-07-000	
FB07	X		X	X		X	X	X	X	X	X	X	X	8/85	12/88	X	X	X									X				FC33*-100001-	N326-02-000	M582-03-000	FB07-07-000	
FB08	X			X	X		X	X	X	X	X	X	X	8/85	12/88	X	X	X									X				FC33*-100001-	N327-02-000	BU17-19-090F	FB08-07-000	
FB11	X		X	X		X	X	X	X	X	X	X	X	8/85	12/88	X	X	X									X				FC33*-100001-	N326-02-000	M582-03-000	FB07-07-000	
FB12	X			X	X		X	X	X	X	X	X	X	8/85	12/88	X	X	X									X				FC33*-100001-	N327-02-000	BU17-19-090F	FB08-07-000	
FB39	X		X	X		X	X	X	X	X	X	X	X	8/85	12/88	X	X	X	X	X											FC33*-100001-	N326-02-000	M582-03-000	FB01-07-000	
FB40	X			X	X		X	X	X	X	X	X	X	8/85	12/88	X	X	X	X	X											FC33*-100001-	N327-02-000	BU17-19-090F	FB02-07-000	
FB41	X		X	X		X	X	X	X	X	X	X	X	8/85	12/88	X	X	X		X	X										FC33*-100001-	N326-02-000	M582-03-000	FB03-07-000	
FB42	X			X	X		X	X	X	X	X	X	X	8/85	12/88	X	X	X		X	X										FC33*-100001-	N327-02-000	BU17-19-090F	FB04-07-000	
FB43	X		X	X		X	X	X	X	X	X	X	X	8/85	12/88	X	X	X									X	X			FC33*-100001-	N326-02-000	M582-03-000	FB01-07-000	
FB47		X	X	X		X	X	X	X	X	X	X	X	2/86	12/88		X	X										X			FC33*-500001-	N332-02-000	R526-03-000	FB46-07-000	
FB69	X		X	X		X	X	X	X	X	X	X	X	11/85	12/88	X	X	X									X	X			FC33*-100001-	N326-02-000	M582-03-000	FB03-07-000	
FB55	X		X	X		X	X	X	X	X	X	X	X	6/86	12/88		X	X									X				FC33*-500001-	N326-02-000	M582-03-000	FB55-07-000	
FB56	X			X	X		X	X	X	X	X	X	X	6/86	12/88		X	X									X				FC33*-500001-	N327-02-000	BU17-19-090F	FB56-07-000	
FB57	X		X	X		X	X	X	X	X	X	X	X	6/86	12/88		X	X									X				FC33*-500001-	N326-02-000	M582-03-000	FB55-07-000	

\* 13B ENGINE.


# MODEL IDENTIFICATION

MODEL NO.	ENG*		T/M	BODY		ROOF		SUSP		DIFF		BRK		SUSP		SEAT		PERIOD		YEAR			TRIM LEVEL										COMPLETE ASSEMBLY UNIT					
	W/O	W/TURBO	5	A	C	C	N	S	W/O	W/A	N	L	W/O	W/A	N	H	2	2	F	T	1	1	1	B	L	S	S	G	G	T	C	1	PART NUMBER					
	TURBO	TURBO	SPEED	AUTO	COUPE	CONV	ORM	SUNROOF	W/O	W/A	ORM	LIM	W/O	W/A	ORM	HARD	SEATER	SEATER	FROM	TO	986	987	988	BASE	PKG	SPORT	SPORT	TURBO	TURBO	CONV	10TH ANNE D	VN (CHASSIS #)	ENGINE	T/MISSION	CABIN			
FB58	X			X	X		X	X	X	X	X	X	X	X	X	X	X	6/86	12/88		X	X							X					FC33*-500001-	N327-02-000	BU17-19-090F	FR56-07-000	
FB61		X	X		X		X	X		X	X	X	X	X	X	X	X	6/86	12/88		X	X							X					FC33*-500001-	N332-02-000	R526-03-000	FB61-07-000	
FB77	X		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	7/87	12/88			X					X	X						FC33*-600001-	N326-02-000	M582-03-000	FB01-07-000	
FB78	X		X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	7/87	12/88			X					X	X						FC33*-600001-	N326-02-000	M582-03-000	FB03-07-000	
FB68	X		X		X		X	X	X	X	X	X	X	X	X	X	X	7/87	12/88			X								X				FC351-100001-	N338-02-000	M50N-03-000	FB67-07-000	
FB79		X	X				X	X		X	X	X	X	X	X	X	X	2/88	12/88			X									X				FC33*-500001-	N332-02-000	R526-03-000	FB79-07-000


\* 13B ENGINE.

# MODEL IDENTIFICATION

COUPE



CONVERTIBLE



**COMBINATION LIST OF BODY PAINTS AND INTERIOR COLORS**

BODY PAINT		INTERIOR COLOR CODE						EFFECTIVE DATE
NAME	CODE	COUPE			CONV.			
ARCTIC SILVER METALLIC	J5		FD5	FD6		FD5	FD6	
TORONADE SILVER METALLIC	K8	FD2	FD5					
BRILLIANT BLACK	PZ	FD2	FD5			FD5		860402
SUNRISE RED	RH	FD2	FD6			FD5		
CRYSTAL WHITE	UC				FD7			880215
NOBLE WHITE	WY			FD6			FD6	
SATIN GOLD METALLIC	1A	FD2						
CLARET MICA	2H		FD3					870701
SAPPHIRE BLUE METALLIC	5A		FD5	FD6			FD3	
PURE RED	NP		FD5					860402
DOVER WHITE	WU	FD2	FD5	FD6				860402
ROYAL MAROON METALLIC	3A	FD2	FD5					861225

**INTERIOR COLOR CODES**

- FD2 - RED
- FD5 - GRAY
- FD6 - BLUE
- FD7 - BLACK


**VIN BREAKDOWN**

- 860402 FC33\* -140427
- 861225 FC33\* -528438
- 870701 FC33\* -600001

# VEHICLE IDENTIFICATION SYSTEM FOR RX-7

## SERIES (1986~1988)

VIN (= Vehicle Identification Number) for RX-7 series (1986~1988 Year Model) consists of WMI (= World Manufacturer Identifier), VDS (= Vehicle Description Section) and VIS (= Vehicle Identification Section). VDS consisting of six alphanumeric characters denotes the "MODEL SERIES". VIS consisting of eight alphanumeric characters denotes the serial unit number of vehicle and is sequentially numbered within each VDS.




\* Check digit is included as a VIN security feature to permit law enforcement verification of the authenticity of a suspected illegal VIN plate. This single digit number is determined, based upon a complex mathematical formula which is applied to each vehicle's VIN number.

\*\* Miscellaneous Identification Code identifies major components such as engine, brake system, cab type, etc

### LOCATION OF VIN PLATE

The plate is attached to the top ledge of the dash panel under the bonnet (engine hood), refer to the illustration shown right.



### [NOTE]

If the VIN (chassis) reference number in the PCM (Parts catalog microfiche) appeared as.


FC33\*-100001

...the vehicle's VIN would be e.g. FC331H0100001.

# **INSTRUCTIONS**

# HOW TO LOCATE PARTS

There are four approaches to locate parts as follows.




Open the catalog to the illustration page indicating the referred section number at the upper left corner of the page

Find the D-code indicated for the desired part in the illustration

All your necessary information on the desired part is found at the referred D-code that is located within the related text (s) following the illustration


## IMPORTANT

If you are not sure which parts catalog compiled to cover the model you are researching, refer to **MODEL IDENTIFICATION** and/or **VEHICLE IDENTIFICATION SYSTEM** located at the very front part of the parts catalog



## Section Number

The illustration and related text pages are compiled in numerical sequence by section number through the parts catalog. However, there is one exception: the section number, "0900 key sets" is always located in the first part of Body group




## D-code

In the text, the D-codes and the related information are listed in the alphabetical and numerical sequence by D-code within each section number



# HOW TO INTERPRET THE ILLUSTRATION

In the example shown below, each item is interpreted as follows.



## 1 SECTION NUMBER

Each illustration is identified by Section Number which indicates the group of parts classified by function.

## 2 SECTION NAME

## 3 SECTION'S APPLICATION

The section's application is indicated in parentheses ( ) below the section name when the affected illustration/text is applicable to specific model, certain period of the production, etc.

## 4 D-CODE (KEY NUMBER)

The D-code consisting of five or six digits serves as a "KEY NUMBER" to co-ordinate a drawing with its detail information in the text.

## 5 RELATIONSHIP BETWEEN ASSEMBLY AND ITS COMPONENTS

The relationship between an Assembly and its Components is illustrated only by drawing. The example shown left denotes that D-code 68420 includes D-codes, 68421A, 68422 and 68425 and standard part numbers, 9986505168, 999100503 and 997390414.

## 6 STANDARD PART NUMBER

Nine or ten-digit number which appears in the illustration is standard part number. The standard part number indicated in the illustration instead of D-code does not appear in the related text.

# HOW TO INTERPRET THE TEXT

In the example shown below, each item is interpreted as follows.

PART NO	QT	MODEL/RESTRICTION	MODEL RESTRICTION	MODEL/RESTRICTION	FROM-TO
5840-2		FRONT DOOR TRIM & RELATED PARTS (SEDAN & HATCHBACK)			
58-921		FASTENER	AGRAFE, GARNITURE	FUADOR, DECORACION	
G030-68-401	22	CE > SDN	MOT CONV > BRLN	MG > SDN	-3315
C (G030-68-401A)		CE > HB	MOT CONV > A/HYO AR	MG > DPT	
G030-68-401A	22	CE > SDN	MOT CONV > BRLN	MG > SDN	3315-
		CE > HB	MOT CONV > A/HYO AR	MG > DPT	
68-420		TRIM(R), DOOR	GARNITURE (D) PORTE	MOLDURA (DER), PUERTA	
GB06-68-420B	1	(INTEGRATED ARMREST)	(APPUJ-BRAS INTEGRE)	(DESCANSABRAZO INTEGRADO)	-2801
		CE > SDN	MOT CONV > BRLN	MG > SDN	
		CE > HB	MOT CONV > A/HYO AR	MG > DPT	
00		BA1 BLACK	BA1 NOIR	BA1 NEGRO	-2801
A (GB06-68-420C00)					
10		BA2 RED	BA2 ROUGE	BA2 ROJO	-2801
A (GB06-68-420C10)					
GB06-68-420C	1	(INTEGRATED ARMREST)	(APPUJ-BRAS INTEGRE)	(DESCANSABRAZO INTEGRADO)	2801-
		CE > SDN	MOT CONV > BRLN	MG > SDN	
		CE > HB	MOT CONV > A/HYO AR	MG > DPT	
00		BA1 BLACK	BA1 NOIR	BA1 NEGRO	2801-
1C		BA2 RED	BA2 ROUGE	BA2 ROJO	2801-

2801	GC221-50...	G030-68-401	C
	GC241-501129	G030-68-401A	01
3315	GC221-515671	9928-10-500	02
	GC241-504548		

## 1 SECTION NUMBER

## 2 TEXT SEQUENCE NUMBER

The number following a hyphen denotes the text sequence number within each section number.

## 3 SECTION NAME

## 4 SECTION'S APPLICATION

## 5 D-CODE

In the text, D-codes and the related information are listed in the alphabetic and numeric sequence by D-code within each section number.

## 6 PART NAME

Part name is described for each D-code in one through three languages out of four languages such as English, French, Spanish and German. The indicated languages vary, depending upon the market which the parts catalog is applicable to.

## 7 PART NUMBER

Under one D-code, if there are more than one part number due to the part change involved, the part numbers are listed in the sequence of the part production timing; the early used part number is shown first and the later one follows it.

## 8 INTERCHANGEABILITY CODE

One- or two-digit alphabet appearing in the extreme left hand side of the text is an interchangeability code.

This code indicates the nature of interchangeability between the two part numbers shown in the right with parentheses and above.

The following interchangeability codes have been currently used in the parts catalog.

Code	Definition
A	One Way A new part can be used in place of the former part but the former part cannot be used in place of the new part.
AN	Both Way A new part and the former part are fully interchangeable.
C	Plus A new part requires additional part(s) to be used in place of the former part.
CG	Plus A new part requires additional part(s) and modification work to be used in place of the former part.
G	Plus A new part requires modification work to be used in place of the former part.
S	One Way Backward The former part can be used in place of a new part but the new part cannot be used in place of the former part.

● **SUPERSEDING PART NUMBER**

When a part is changed and new part is interchangeable with the former part, the new part number as the superseding part is shown in parentheses right under the former (superseded) part number.

● **NEW PART NUMBER IDENTIFICATION**

An asterisk (\*) denotes that the indicated part number has been added since the last microfiche edition (not the last paper edition).  
The microfiche parts catalog is revised more frequently than the paper one.

● **QUANTITY**

This denotes the quantity of the part used under the indicated D-code within each section number.

● **MODEL APPLICATION**

Model application for each part number is described in one through three languages out of four languages such as English, French, Spanish and German.

● **PART USAGE RESTRICTION**

Part usage restriction is shown for factory installed option parts to indicate under what condition the part is installed.  
This information is also described in one through three languages.

● **COLOR CODE OF PART NUMBER**

For color keyed parts, two-digit color code(s) appear(s) right under its basic part number consisting of nine or ten digits. The complete part number for color keyed parts consists of the basic part number (9 or 10 digits) and the color code (2 digits)

● **INTERIOR or PAINT CODE FOR VEHICLE**


The applicable interior or paint code(s) for the vehicle is (are) indicated to each color code of part number.

● **COLOR DESCRIPTION OF PART**

A color description of the part is indicated to each part's color code in one through three languages

⑰ **PART CHANGE DATE**

When a part is added, changed or deleted, the effective date coded in four digits is shown as follows.




⑱ **VIN NUMBER**

The VIN number(s) related to the part change date is (are) shown in the footnote column, referring each date shown above.

⑲ **MULTIPLE SUPERSESSION**

Shown as the example is a multiple supersession identified by the interchangeability codes "C" and "CG" one part can be replaced by more than one part  
When the interchangeability codes "C" or "CG" appears in the text, a complete information on the multiple supersession will be shown in the footnote column of the same text



## HOW TO INTERPRET THE VIN APPLICATION

If the part change date appears as the example below:

PART NO.	QT	MODEL/RESTRICTION	MODEL/RESTRICTION	MODEL/RESTRICTION	FROM-TO
11-210		ROD, CONNECTING	BIELLE	BIELA	
E301-11-210	4	1100 1300	1100 1300	1100 1300	-3801
E301-11-210A	4	1100 1300	1100 1300	1100 1300	3801-4215
E301-11-210B	4	1100 1300	1100 1300	1100 1300	4215--

3801	BD1012	805912
	BD1032	824340
4215	BD1012	816750
	BD1032	830192

it should be interpreted:

- ① Part No. E301-11-210 is applicable to 1100 cc, from the initial production through BD1012 805911 (= 805912 minus 1) and 1300 cc, from the initial production through BD1032 824339 (= 824340 minus 1).
- ② Part No. E301-11-210A is applicable to 1100 cc, from BD1012 805912 through BD1012 816749 (= 816750 minus 1) and 1300 cc, from BD1032 824340 through BD1032 830191 (= 830192 minus 1).
- ③ Part No. E301-11-210B is applicable to 1100 cc, from and after BD1012 816750 and 1300 cc, from and after BD1032 83192.

### Note:

The parts catalog often shows the catalog designation VIN instead of the actual VIN. For the correct interpretation for the catalog designation VIN, refer to explanation in "Vehicle Identification System" shown in the extreme right row of the last microfiche in this set.

## HOW TO INTERPRET THE SUPERSESSION

If the supersession information appears as the example below:

PART NO.	QT	MODEL/RESTRICTION
58-921		FASTENER
G030-68-401	22	1300
A (G030-68-401A)		1500
G030-68-401A	22	1300
		1500

Interchangeability Code  
Superseding Part Number

Model Application for Part No. G030-68-401

---

PART NO.	QT	MODEL/RESTRICTION
68-420		TRIM (R) DOOR
GB06-68-420A	1	
00		BA1 BLACK
A (GB06-68-420B00)		
10		BA2 RED
A (GB06-68-420B10)		
GB06-68-420B	1	
00		BA1 BLACK
10		BA2 RED

Color Code  
Interchangeability Code  
Superseding Part Number

it should be interpreted:

- ① Part No. G030-68-401A can be used in place of part No. G030-68-401.
- ② Part No. GB06-68-420B00 can be used in place of part No. GB06-68-420A00.
- ③ Part No. GB06-68-420B10 can be used in place of part No. GB06-68-420A10.




## MAZDA STANDARD PARTS

The Parts standardized in form and dimension such as Bolts, Nuts, Washers, Hoses, Disc Wheels, etc. are called Mazda Standard Parts.

All Mazda Standard Part Numbers are identified by "9" in the first digit. The numbering structure of Standard Parts varies, depending upon the type of part.


The following is just one example of Standard Part Number.

For further details and examples, refer to the wall chart, "LIST OF STANDARD PARTS".



## MAZDA SPECIAL TOOLS

In order to repair Mazda Vehicles, several special tools are required. These are called Mazda Special Tools. Mazda Special Tools are identified by the Part Number starting with "49".



## ABBREVIATION LIST

ABBREV.	MAY REPLACE	ABBREV.	MAY REPLACE
1ST	First	CAL.	California
2ND	Second	CASS.	Cassette
3RD	Third	CAT.	Category
4TH	Fourth	Cd	Coefficient Of Drag
4 SPD	Four Speed	CD	Compact Disk
4WS	Four Wheel Steering	C.G.R.	Constant Gear Ratio
4WD, 4X4	Four Wheel Drive	CHG.	Change
5TH	Fifth	CHK.	Check
5 SPD	Five Speed	CHMBR	Chamber
		CHN.	Chain
AA.	Anti Afterburn	CIGAR.	Cigarette
A.A.S.	Auto Adjusting Suspension	CI	Coefficient Of Lift
ABS	Anti Lock Braking System	CLPR	Caliper
AC	Air Conditioning	CVTR.	Converter
A.C.C.	Automatic Cruise Control	COMB.	Combination
ACCEL.	Accelerator	COND.	Condenser
A.C.V.	Air Control Valve	COMP.	Compressor
A.E.	Acoustical Equalizer	CONV.	Convertible
ALUM	Aluminum	C/P	Cab Plus
ALL	Automatic Load Leveling	C.S.D.	Cold Start Device
ALT.	Alternator	CSTG.	Coasting
AMP.	Amplifier	CTR.	Center
ANT.	Antenna	CTRL.	Control
APR	April	CV	Constant Velocity
ASSEMBLY	Assembly	CVR.	Cover
A/T	Automatic Transmission	CYL.	Cylinder
AUG.	August		
AUTO.	Automatic	DASH.	Dashboard
		Db	Decibels
BAL.	Balance	DEC.	December
BELT.	Beltline	DEF.	Defroster
BFGR	B. F. Goodrich	DIAPH	Diaphragm
BRDG	Bridgestone	DIFF.	Differential
BRG.	Bearing	DNLP	Dunlop
BRKT.	Bracket	DOHC	Double Overhead Camshaft
BRN.	Brown		
BLK.	Black	DSL.	Diesel
BLU.	Blue	DTSS	Dynamic Tracking Suspension System
BMPR.	Bumper		
B.S.V.	Bleed Solenoid Valve	DX	Deluxe
BULL.	Bulletin		
BW	Black Wall	ECAT	Electronically Controlled A/T
		EGI	Electronic Gas Injection
		EGR	Exhaust Gas Recirculation

## ABBREVIATION LIST

ABBREV.	MAY REPLACE	ABBREV.	MAY REPLACE
ELEC.	Electric	INN.	Inner
ENG.	Engine	INT.	Interior
ETR	Electronically Tuned Radio	INTMT.	Intermittent
		INJ.	Injector, Injected
EXC.	Except	I.R.S.	Independent Rear Suspension
EXH.	Exhaust		
EXT.	Extension	JAN.	January
EQ	Equalizer	JUL.	July
		JUN.	June
FEB.	February		
FED.	Federal	KG	Kilogram
F.I.	Fuel Injection	KM	Kilometer
FLEX	Flexible	KW	Kilowatt
F/LID	Fuel Lid		
FRT.	Front	(L), LT	Left
FRST	Firestone	L=	Length
FSTNR.	Fastener	LCD	Liquid Crystal Display
		L/B	Long Bed
G	Gram	LH	Left Hand
GAS.	Gasoline	LPG	Liquid Petroleum Gas
GDYR	Goodyear	L.S.D.	Limited Slip Differential
GEN.	General		
GOV.	Governor	LWR	Lower
GRN.	Green	LX	Luxury
GRY.	Gray		
GSKT.	Gasket	M	Metallic
		MAR.	March
H.A.C.	High Altitude Compensator	MC	Mica
		MCHN	Michelin
HARN.	Harness	MLDG.	Moulding, Mould
H/B	Hatchback	MM	Millimeter
HD.	Head	MNFLD.	Manifold
H/DUTY	Heavy Duty	MPX	Multiplex
HDWE.	Hardware	MSTR.	Master
HI. ALT.	High Altitude	M/T	Manual Transmission
HSG.	House, Housing	MTG.	Mounting
HTR.	Heater	MTR	Manually Tuned Radio
IC	Integrated Circuit	N=	Number Of Teeth
ID	Inside Diameter	N/A	Not Available
IGN.	Ignition	N/B	Notchback
ILLUM.	Illumination, Illuminated	NO.	Number
		NORM.	Normal
INCL	Includes	NOV.	November
IND	Indicator		
INFO.	Information		
INST.	Instrument		

## ABBREVIATION LIST

ABBREV.	MAY REPLACE	ABBREV.	MAY REPLACE
OCT.	October	SPEC.	Specification
OD	Outer Diameter	SPEEDO.	Speedometer
O/DRIVE	Overdrive	SPG.	Spring
OHC	Overhead Camshaft	SPKR.	Speaker
OPT.	Optional	SPRKT.	Sprocket
O.S.	Overize	SRS	Supplemental Restraint System
OUT.	Outer	STAB.	Stabilizer
PANSC	Panasonic	STD.	Standard
PARK.	Parking	STRG.	Steering
PB	Parking Brake	S/ROOF	Sunroof
PCV	Positive Crankcase Ventilation	SUSP.	Suspension
PIN.	Pinion	S/W	Station Wagon
PKG	Package	SW.	Switch
PLR	Pillar	SYNC.	Synchronizer
PROD.	Production	T-	Thickness
P/S	Power Steering	TEMP.	Temperature
P/TRIM	Pillar Trim	THERMO.	Thermostat
PTH	Phillips Truss Head	TMG.	Timing
PWR.	Power	TRANSMISSION	Transmission
QTR.	Quarter	TRK.	Truck
QTY.	Quantity	T/LID	Trunk Lid
(R), RT	Right	T/S	Touring Sedan
RH	Right Hand	TTL	Twin Trapezoidal Links
RAD.	Radiator	TURBO	Turbocharged
REINF.	Reinforcement	UP.	Upper
REG.	Regular	U.S.	Underrize
REGUL.	Regulator	VAC.	Vacuum
REL.	Release	V.G.R.	Variable Gear Ratio
REM.	Remote	VPV	Variable Port Valve
RET.	Return	VNL.	Vinyl
REV.	Reverse	W-	Width
RR.	Rear	W/	With
RWL	Raised White Letters	W/P	Water Pump
S/B	Short Bed	WGN.	Wagon
S/ROD	Shift Rod	WHL.	Wheel
S/S	Supercession	W/O	Without
SDN.	Sedan	WHT.	White
SEP.	September	W/SHIELD	Wind Shield, Screen
SERV.	Service	WTR.	Water
SLND.	Solenoid	W/W	White Walls
SOHC	Single Overhead		



# **MAZDA**

## **1984-88 RX-7 ACCESSORIES**

### **AERO**

0000-86-325 - Wing Spoiler  
F061-V4-920 -OF - Factory Spoiler

### **AIR CONDITIONER**

Refer to Accy. Bulletin XA-1 for Air Conditioner information.

### **ALARM**

0000-88-1901 - Electronic Shock Sensor  
Refer to Accy. Bulletin XG-6 for Alarm information.

### **ARM REST**

Refer to Accy. Bulletin XN-1 for replacement parts.

### **BATTERY**

0000-80-126F  
Refer to Accy. Bulletin XG-4 for Battery information.

### **BLOCK HEATER**

0000-88-6600  
Refer to Accy. Bulletin XG-5 for installation information.

### **CAR COVER**

0000-88-092A - Evolution 3 Blue  
0000-88-090 -LK - Lock Kit  
Refer to Accy. Bulletin XG-8 for more Car Cover information.

### **CARGO COVER**

FB01-V1-350 -1F - Red  
FB01-V1-350 -5F - Blue  
FB01-V1-350 -7F - Grey

### **CIGARETTE LIGHTERS**

B001-66-252

### **CRUISE CONTROL**

8AF1-66-340 - Coupe  
8AF2-66-340 - Convertible  
Refer to Accy. Bulletin XG-7 for more Cruise Control information.

### **DOOR EDGE GUARDS**

0000-88-3199-BK - Black Universal Type

### **FLOOR MATS**

0000-88-7688-05 - Gray Plush Mat  
0000-88-7688-11 - Wine Plush Mat  
0000-88-7688-50 - Blue Plush Mat  
0000-88-7688-TA - 10th Anniversary Edition Mat

### **FOG LIGHTS**

0000-88-500A-R6 - Clear Complete Kit  
Refer to Accy. Bulletin XE-4 for Fog Light parts information.

### **FRONT MASK**

0000-88-0588 - GTU, w/o Air Dam

### **MUD GUARDS**

F045-V3-350 -OF - Front Set  
F045-V3-351 -OF - Front Left  
F045-V3-352 -OF - Front Right  
F045-V3-360 -OF - Rear Set  
F045-V3-361 -OF - Rear Left  
F045-V3-362 -OF - Rear Right

### **PAINT**

Refer to Accy. Bulletin XE-2 for Touch-Up Paint information.

### **RACKS**

0000-88-1077 - Piper Ski Rack  
0000-88-1067 - Sport Rack  
0000-88-1200 - Ski Attachment  
0000-88-1300 - Bike Attachment  
0000-88-1400 - Sail/Surf Attachment  
0000-88-1500 - Luggage Attachment

### **STEREO EQUIPMENT**

Refer to Accy. Bulletins XS-1, XS-2, and XS-3 for Audio information.

### **SUNROOF WIND DEFLECTOR**

0000-86-3007

### **TIRES**

Refer to Accy. Bulletins XE-1 for Tire information.



### **WHEEL LOCKS**

0000-88-120C - Wheel Lock Set  
0000-88-120C-BP - Lock Blister Pack  
Refer to Accy. Bulletin XE-5 for more Wheel Lock information.

# SECTION INDEX -- ENGINE


STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME
1 - C 3	1000B	SHORT ENGINE BLOCK & GASKET SETS (W/O TURBO)	1 - C 6	1400B	OIL PUMP & FILTER (W/O TURBO)			
1 - D 3	1000BA	SHORT ENGINE & GASKET SETS (TURBO)	1 - E 6	1400BA	OIL PUMP & FILTER (TURBO)			
1 - E 3	1030B	ROTOR HOUSINGS (W/O TURBO)	1 - G 6	1500B	COOLING SYSTEM (W/O TURBO)			
1 - F 3	1030BA	ROTOR HOUSINGS (TURBO)	1 - I 6	1500BA	COOLING SYSTEM (TURBO)			
1 - G 3	1040B	OIL PAN, FRONT & REAR HOUSING (W/O TURBO)	1 - K 6	1580B	BRACKET, PULLEY & BELT			
1 - H 3	1040BA	OIL PAN, FRONT & REAR HOUSING (TURBO)	1 - L 6	1600	CLUTCH DISC & COVER (MANUAL) (W/O TURBO)			
1 - I 3	1100B	ECCENTRIC SHAFT & FLYWHEEL (W/O TURBO)	1 - M 6	1605A	CLUTCH DISC & COVER (MANUAL) (TURBO)			
1 - J 3	1100BA	ECCENTRIC SHAFT & FLYWHEEL (TURBO)	1 - N 6	1700	TRANSMISSION CASE (MANUAL) (W/O TURBO)			
1 - K 3	1110B	ROTORS & RELATED PARTS (W/O TURBO)	1 - C 7	1700A	TRANSMISSION CASE (MANUAL) (TURBO)			
1 - L 3	1110BA	ROTORS & RELATED PARTS (TURBO)	1 - D 7	1710	TRANSMISSION GEARS (MANUAL) (W/O TURBO)			
1 - M 3	1300B	INTAKE MANIFOLD (W/O TURBO)	1 - G 7	1710A	TRANSMISSION GEARS (MANUAL) (TURBO)			
1 - N 3	1300BA	INTAKE MANIFOLD (TURBO)	1 - J 7	1720	CHANGE CONTROL SYSTEM (MANUAL) (W/O TURBO)			
			1 - K 7	1720A	CHANGE CONTROL SYSTEM (MANUAL) (TURBO)			
1 - C 4	1310B	EXHAUST MANIFOLD (W/O TURBO)	1 - L 7	1800B	ENGINE ELECTRICAL SYSTEM (W/O TURBO)			
1 - D 4	1310BA	EXHAUST MANIFOLD (TURBO)	1 - C 8	1800BA	ENGINE ELECTRICAL SYSTEM (TURBO)			
1 - G 4	1320B	FUEL SYSTEM (W/O TURBO)	1 - F 8	1830B	ALTERNATOR (W/O TURBO)			
1 - I 4	1320BA	FUEL SYSTEM (TURBO)	1 - G 8	1830BA	ALTERNATOR (TURBO)			
1 - K 4	1330B	AIR CLEANER (W/O TURBO)	1 - H 8	1840B	STARTER (W/O TURBO)			
1 - L 4	1330BA	AIR CLEANER (TURBO)	1 - I 8	1840BA	STARTER (TURBO)			
1 - M 4	1350B	STARTING ASSIST SYSTEM (W/O TURBO)	1 - J 8	1850B	BATTERY			
1 - N 4	1350BA	STARTING ASSIST SYSTEM (TURBO)	1 - K 8	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)			
1 - C 5	1364B	THROTTLE BODY COMPONENTS (W/O TURBO)	1 - L 8	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)			
1 - D 5	1364BA	THROTTLE BODY COMPONENTS (TURBO)	1 - C 9	1925	CONTROL VALVE (AUTOMATIC)			
1 - F 5	1371B	AIR PUMP & AIR CONTROL VALVE (W/O TURBO)	1 - E 9	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)			
1 - F 5	1371BA	AIR PUMP & AIR CONTROL VALVE (TURBO)	1 - H 9	1940	GOVERNOR LOW & REVERSE PISTON (AUTOMATIC)			
1 - G 5	1380B	EMISSION CONTROL SYSTEM (EXHAUST SIDE) (W/O TURBO)	1 - I 9	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)			
1 - K 5	1380BA	EMISSION CONTROL SYSTEM (EXHAUST SIDE) (TURBO)	1 - J 9	1960	GASKET & SEAL KIT (AUTOMATIC)			

**1000B-1 SHORT ENGINE BLOCK & GASKET SETS (W/O TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	10 2715	GASKET SET, ENGINE	8AF1-10-271B	1		
	13 1115	GASKET SET, SUB-ENGINE	8AF1-13-111A	1		
	23 0401	O-RING SET	N326-10-560	1		
	23 800	ENGINE BLOCK, SHORT	N326-02-2000	1	M/T	
			N327-02-2000	1	A/T	
		REFER TO PARTS BULL. NOS. R-6 & R-8 FOR REBUILT ENGINE INFO.				
		REFER TO SERV. BULL. NO. 046/88, CAT. 4 FOR AIR BLEED SOCKET INFO.				

**1000BA-1 SHORT ENGINE & GASKET SETS (TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
10 271S		GASKET SET, ENGINE	8AF4-10-271B	1		
13 111S		GASKET SET, SUB-ENGINE	8AF3-13-111A	1		
23 0401		O-RING SET	N318-10-560	1		
23 800		ENGINE BLOCK, SHORT	N332-02-200B	1		
		REFER TO PARTS BULL. NOS. R-6 & R-8 FOR REBUILT ENGINE INFO.				
		REFER TO SERV. BULL. NO. 046/88, CAT. 4 FOR AIR BLEED SOCKET INFO.				

**1030B-1 ROTOR HOUSINGS  
(W/O TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
10 1001		HOUSING, ROTOR-FRONT	N326-10-810	1		
10 105A		STUD, ROTOR HOUSING	0839-10-105	4		
10 1111		DOWEL, TUBULAR	1757-10-111	4		
10 1501		HOUSING, ROTOR-REAR	N326-10-850C	1		
10 1711		RING, SQUARE	N326-10-871A	4		
10 172A		RING, SQUARE-OUTER	N326-10-872	4		
10 1731		O-RING	N231-10-173	4		
10 2501		CAP, OIL FILLER	8871-10-250	1		
10 2521		GASKET, OIL CAP	8871-10-252	1		
10 323A		GASKET, WATER DRAIN	N326-10-323	1		
10 325		PIPE, DIPSTICK	N326-10-441	1		
10 3272		PLUG, JET	N326-14-633	2		
10 4001		HOUSING, INTERMEDIATE	N326-10-D00B	1		
10 410		PIPE, OIL FILLER	N326-10-420	1		
10 415		PLUG, SOCKET	N225-10-415	1		
10 4171		JOINT, PIPE	8562-10-417	1		
10 450		DIPSTICK	N326-10-450B	1		
10 5001		GEAR, STATIONAR' -FRT.	3648-10-500	1		
10 502A		BEARING, MAIN	0820-10-502B	2		
10 5501		GEAR, STATIONARY-RR.	3648-10-550A	1		
10 5551		O-RING	0813-10-555A	1		
10 5561		SEAL, OIL	1668-10-556A	1		
10 806		PIN, SPRING	N326-10-806	4		

6910-

6910 FC33\* -513803

**1030BA-1 ROTOR HOUSINGS (TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
10 1001		HOUSING, ROTOR-FRONT	N332-10-B10	1		
10 105A		STUD, ROTOR HOUSING	0839-10-105	4		
10 1111		DOWEL, TUBULAR	1757-10-111	4		
10 1501		HOUSING, ROTOR-REAR	N332-10-B50B	1		
10 1711		RING, SQUARE	N326-10-B71A	4		
10 172A		RING, SQUARE-OUTER	N326-10-B72	4		
10 1731		O-RING	N231-10-173	4		
10 2501		CAP, OIL FILLER	8871-10-250A	1		
10 2521		GASKET, OIL CAP	8871-10-252	1		
10 323A		GASKET, WATER DRAIN	N326-10-323	1		
10 325		PIPE, DIPSTICK	N318-10-441	1		
10 3272		PLUG, JET	N326-14-633	2		
10 4001		HOUSING, INTERMEDIATE	N332-10-D00B	1		
10 410		PIPE, OIL FILLER	N318-10-D10B	1		
10 415		PLUG, SOCKET	N225-10-415	1		
10 4171		JOINT, PIPE	8562-10-417	1		
10 420		PIPE NO. 2, OIL FILLER	N332-10-420B	1		
10 424		GASKET, OIL FILLER PIPE	N318-10-424	1		
10 450		DIPSTICK	N332-10-450A	1		
10 5001		GEAR, STATIONARY-FRT.	3648-10-500	1		
10 502A		BEARING, MAIN	0820-10-502B	2		
10 5501		GEAR, STATIONARY-RR.	3648-10-550A	1		
10 5551		O-RING	0813-10-555A	1		
10 5561		SEAL, OIL	1668-10-556A	1		
10 806		PIN, SPRING	N326-10-806	4		

6910-

6910 FC33\* -513803


**1040B-1 OIL PAN, FRONT & REAR HOUSING (W/O TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
10 1741		O-RING	N231-10-174	1		
10 2001		HOUSING, FRONT	N326-10-C00C	1		
10 203A		PIN, DOWEL	0839-10-203	2		
10 205A		PLUG, BLIND	8562-10-205	4		
10 2061		PLUG, BLIND	1757-10-206A	1		
10 2071		PLUG, BLIND	1757-10-207A	1		
10 2081		STUD	1757-10-208	4		
10 219A		STUD, HOUSING	N249-10-219	1		
10 3001		HOUSING, REAR	N326-10-C50B	1		
10 3051		COVER, DUST	N225-10-305	1		
10 309		PIN, TUBULAR	1757-10-309	4		
10 351		COVER, DUST	N304-10-351	1		
10 400		PAN, OIL	N326-10-400E	1	FED.	
			N328-10-400E	1	CAL.	
10 404		PLUG, DRAIN	99511-1400	1		
10 431		GASKET, OIL PAN	N3Y6-10-427	1		
10 4511		BOLT, TENSION	N326-10-E51	17		
10 4521		BOLT, TENSION	N326-10-E52	1		
10 4551		WASHER, SEAL	0839-10-455	18		
10 503		PIN, TOP INDICATOR	8871-10-631	1		
10 506		STUD, FRONT COVER	N326-10-506	1		6901-
10 507		SEAL, OIL	0820-10-605	1		
10 6001		COVER, FRONT	N326-10-500B	1		
10 6091		PIN, SPRING	1757-10-609	1		
10 619A		STUD, COVER	N249-10-619	2		
10 641		GASKET, FRONT COVER	8527-10-641	1		
10 8451		BOLT	N307-10-845	1		
10 8611		HANGER, ENGINE	N225-10-861	1		
10 8621		HANGER, ENGINE	N304-10-862	1		
14 115		PLUNGER, CONTROL	0839-14-115	1		
14 273		SPRING	0839-14-273A	1		
14 274		PLUG	0839-14-274	1		
99 384		JOINT, UNION	9938-41-200F	1		
99 560		GASKET	9956-41-400	1		
			9956-41-600	1		

6901 FC33\* -512255

**1040BA-1 OIL PAN, FRONT & REAR HOUSING (TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
10 1741		O-RING	N231-10-174	1		
10 2001		HOUSING, FRONT	N318-10-C008	1		
10 203A		PIN, DOWEL	0839-10-203	2		
10 205A		PLUG, BLIND	8562-10-205	3		
10 2061		PLUG, BLIND	1757-10-206A	1		
10 2071		PLUG, BLIND	1757-10-207A	1		
10 2081		STUD	1757-10-208	4		
10 219A		STUD, HOUSING	N249-10-219	1		
10 3001		HOUSING, REAR	N318-10-C50A	1		
			<AN> N318-10-C50B	1		
10 3051		COVER, DUST	N225-10-305	1		
10 309		PIN, TUBULAR	1757-10-309	4		
10 351		COVER, DUST	N304-10-351	1		
10 400		PAN, OIL	N326-10-400E	1	FED.	
			N328-10-400E	1	CAL.	
10 404		PLUG, DRAIN	99511-1400	1		
10 431		GASKET, OIL PAN	N3Y6-10-427	1		
10 4511		BOLT, TENSION	N326-10-E51	17		
10 4521		BOLT, TENSION	N326-10-E52	1		
10 4551		WASHER, SEAL	0839-10-455	18		
10 503		PIN, TOP INDICATOR	8871-10-631A	1		
10 506		STUD, FRONT COVER	N326-10-506	1		6901-
10 507		SEAL, OIL	0820-10-605	1		
10 561B		HANGER, ENGINE-REAR	N318-10-566A	1		
10 570		BRACKET, HANGER-ENGINE	N318-10-570A	1		
10 6001		COVER, FRONT	N318-10-500B	1		
10 6091		PIN, SPRING	1757-10-609	1		
10 619A		STUD, COVER	N249-10-619	2		
10 641		GASKET, FRONT COVER	8527-10-641	1		
10 8451		BOLT	N318-10-908	1		
14 115		PLUNGER, CONTROL	0839-14-115	1		
14 260A		PIPE, OIL OUTLET	N318-14-260	1		
14 264D		GASKET, OIL OUTLET PIPE	N318-14-264	1		
14 273		SPRING	0839-14-273A	1		
14 274		PLUG	0839-14-274	1		
99 384		JOINT, UNION	9938-41-200F	1		
99 560		GASKET	9956-41-400	1		
			9956-41-600	1		

6901 FC33\* -512255




**1100B-1 ECCENTRIC SHAFT & FLYWHEEL  
(W/O TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
11 301J		KEY, WOODRUFF-PULLEY	9923-60-571	1		
11 371		PULLEY, CRANKSHAFT	N326-11-4008	1		
11 376		BOLT, PULLEY	N318-11-420A	1		
11 4001		SHAFT, ECCENTRIC	N326-11-D00A	1	M/T	
			N327-11-D00A	1	A/T	
11 4031		BEARING, NEEDLE	N326-11-D03	1	M/T	
11 4041		SEAL, OIL	1881-11-404	1	M/T	
11 4111		PLUG, OIL JET	N326-11-D11	2		
11 4121		SPRING	0839-11-412	2		
11 500		FLYWHEEL	N326-11-500	1	M/T	
11 5011		PLATE	1011-11-501	1		
11 502		GEAR, RING-FLYWHEEL	0866-11-702	1	M/T	
11 5021		SPACER	0839-11-509	1	L=8MM	
			0839-11-502	1	L=8.02MM	
			0839-11-506	1	L=8.08MM	
			0839-11-508	1	L=8.04MM	
			8519-11-517	1	L=8.06MM	
11 5041		PLATE, THRUST	1011-11-504	1		
11 5051		BEARING, NEEDLE	0813-11-505B	2		
11 5071		WASHER, THRUST	1011-11-507	1		
11 5111		WEIGHT, BALANCE	N326-11-D61A	1		
11 5311		GEAR, DRIVE	0839-11-531	1		
11 5511		GEAR, DRIVE-OIL PUMP	N326-11-D75	1		
11 7051		KEY, FLYWHEEL	0820-11-705	1		
11 7111		NUT, LOCK	0810-11-711	1		
11 7501		WEIGHT, COUNTER	N327-11-521A	1	A/T	
11 D15		PELLET, THERMO-ECCENTRIC	N326-11-D15	1		
11 D17		SPRING, THERMO PELLE	N326-11-D17	1		
18 201		O-RING	9954-10-1105	1		
99 220		PIN	9923-30-822	3	M/T	7201-

7201 FC33\* -532667

**1100BA-1 ECCENTRIC SHAFT & FLYWHEEL (TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
11 301J		KEY, WOODRUFF-PULLEY	99236-0571	1		
11 371		PULLEY, CRANKSHAFT	N326-11-400B	1		
11 376		BOLT, PULLEY	N318-11-420A	1		
11 4001		SHAFT, ECCENTRIC	N326-11-D00A	1		
11 4031		BEARING, NEEDLE	N326-11-D03	1		
11 4041		SEAL, OIL	1881-11-404	1		
11 4111		PLUG, OIL JET	N326-11-D11	2		
11 4121		SPRING	0839-11-412	2		
11 500		FLYWHEEL	N318-11-500A	1		
11 5011		PLATE	1011-11-501	1		
11 502		GEAR, RING-FLYWHEEL	N318-11-502A	1		
11 5021		SPACER	0839-11-509	1	L=8MM	
			0839-11-502	1	L=8.02MM	
			0839-11-508	1	L=8.04MM	
			8519-11-517	1	L=8.06MM	
			0839-11-506	1	L=8.08MM	
11 5041		PLATE, THRUST	1011-11-504	1		
11 5051		BEARING, NEEDLE	0813-11-505B	2		
11 5071		WASHER, THRUST	1011-11-507	1		
11 5111		WEIGHT, BALANCE	N326-11-D61A	1		
11 5311		GEAR, DRIVE	0839-11-531	1		
11 5511		GEAR, DRIVE-OIL PUMP	N326-11-D75	1		
11 7051		KEY, FLYWHEEL	0820-11-705	1		
11 7111		NUT, LOCK	0810-11-711	1		
11 D15		PELLET, THERMO-ECCENTRIC	N326-11-D15	1		
11 D17		SPRING, THERMO PELLE	N326-11-D17	1		
18 201		O-RING	9954-10-1105	1		
99 220		PIN	9923-30-822	3		

7501 FC33\* -547831


7501-

ROTORS & RELATED PARTS  
(W/O TURBO)





ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	11 1111	BEARING, ROTOR	1011-11-111	2		
	11 3011	SEAL, APEX	N326-11-C00B	6		
	11 3021	PIECE, SIDE	N326-11-C02	6		
	11 3041	SPRING, APEX SEAL	N326-11-C04A	6		
	11 3171	SPRING, SIDE SEAL	N326-11-C17	12		
	11 3211	SEAL, CORNER	N326-11-C20A	12		
	11 3221	PLUG, CORNER SEAL	N326-11-C22A	24		
	11 3231	SPRING, CORNER SEAL	1202-11-323	12		
	11 3411	O-RING, INNER	0820-11-341	4		
	11 3431	O-RING, OUTER	0820-11-341	4		
	11 3511	SPRING, FRT.-INNER	N225-11-351	2		
	11 3531	SPRING, FRT.-OUTER	1011-11-353A	2		
	11 3611	SPRING, REAR-INNER	N225-11-361	2		
	11 3631	SPRING, REAR-OUTER	1011-11-363A	2		
	11 C03	PIECE, 2ND-APEX SEAL	N326-11-C03A	6		
	11 C06	SPRING, OUTER-APEX SEAL	N326-11-C06A	6		
	23 102A	ROTOR	N3Y6-11-800	2		W/O CHROMIUM PLATING
			< AN > N3Y6-11-810	2		W/O CHROMIUM PLATING
	23 151A	SEAL, SIDE	N3Y6-11-C11	12		
	23 1801	SEAL SET, OIL	8871-23-180	4		

**1110BA-1 ROTORS & RELATED PARTS (TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
11 1111		BEARING, ROTOR	1011-11-111	2		
11 3011		SEAL, APEX	N326-11-C008	6		
11 3021		PIECE, SIDE	N326-11-C02A	6		
11 3041		SPRING, APEX SEAL	N326-11-C04A	6		
11 3171		SPRING, SIDE SEAL	N326-11-C17	12		
11 3211		SEAL, CORNER	N326-11-C20A	12		
11 3221		PLUG, CORNER SEAL	N326-11-C22A	24		
11 3231		SPRING, CORNER SEAL	1202-11-323	12		
11 3411		O-RING, INNER	0820-11-341	4		
11 3431		O-RING, OUTER	1202-11-343	4		
11 3511		SPRING, FRT.-INNER	N225-11-351	2		
11 3531		SPRING, FRT.-OUTER	1011-11-353A	2		
11 3611		SPRING, REAR-INNER	N225-11-361	2		
11 3631		SPRING, REAR-OUTER	1011-11-363A	2		
11 C03		PIECE, 2ND-APEX SEAL	N326-11-C03	6		
11 C06		SPRING, OUTER-APEX SEAL	N326-11-C06A	6		
23 102A		ROTOR	N3Y2-11-B10A	2		
23 151A		SEAL, SIDE	N3Y1-11-C11	12		
23 1801		SEAL SET, OIL	8735-23-180	4		

**1300B-1 INTAKE MANIFOLD (W/O TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
13 100		MANIFOLD, INTAKE	N326-13-100D	1		
13 104J		CAP, BLIND	1010-13-104	4		
13 111		GASKET, INTAKE MANIFOLD	N326-13-111	1		
13 116B		GASKET, RESOLUTION CHAMBER	N326-13-112	1		
13 130E		TANK, SURGE	N326-13-130A	1		
13 135C		GASKET	N326-13-135	1		
13 1601		VALVE, VARIABLE PORT	N225-13-160A	2		
13 173		STUD	N225-13-173A	2		
13 180A		SHAFT, VPV CONTROL	N326-13-880A	1		
13 180B		SHAFT, VPV CONTROL	N327-13-880A	1		
13 184		BUSHING	N225-13-184	2		
13 186A		PLATE, LOCATING	N225-13-186	2		
13 187		COVER	N304-13-187	2		
13 188		RUBBER, SEALING	N225-13-188A	2		
13 23X		MANIFOLD, EXTENSION	N326-13-23XE	1	FED.	
			N326-13-23XD	1	CAL.	
13 665B		BRACKET, ACCEL. WIRE	N326-13-660	1		

**1300BA-1 INTAKE MANIFOLD (TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
13 100		MANIFOLD, INTAKE	N332-13-100A	1	FED.	
			N334-13-100A	1	CAL.	
13 100J		O-RING	8527-13-113	2		
13 104J		CAP, BLIND	1010-13-104	1		
13 111		GASKET, INTAKE MANIFOLD	N318-13-111C	1		
13 116B		GASKET, RESOLUTION CHAMBER	N318-13-112	1		
13 130E		TANK, SURGE	N332-13-130C	1		
13 140		BRACKET, SURGE TANK	N319-13-140D	1		
13 665B		BRACKET, ACCEL WIRE	N318-13-660A	1		
41 667B		BRACKET, ACCEL WIRE-THERMOSTAT	FB44-41-667A	1		
41 770B		BRACKET, ACCEL WIRE-SURGE TANK	FB44-41-770A	1		

# SECTION INDEX -- ENGINE

STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME
1 - C 3	1000B	SHORT ENGINE BLOCK & GASKET SETS (W/O TURBO)	1 - K 5	1380BA	EMISSION CONTROL SYSTEM (EXHAUST SIDE) (TURBO)			
1 - D 3	1000BA	SHORT ENGINE & GASKET SETS (TURBO)	1 - C 6	1400B	OIL PUMP & FILTER (W/O TURBO)			
1 - E 3	1030B	ROTOR HOUSINGS (W/O TURBO)	1 - E 6	1400BA	OIL PUMP & FILTER (TURBO)			
1 - F 3	1030BA	ROTOR HOUSINGS (TURBO)	1 - G 6	1500B	COOLING SYSTEM (W/O TURBO)			
1 - G 3	1040B	OIL PAN, FRONT & REAR HOUSING (W/O TURBO)	1 - I 6	1500BA	COOLING SYSTEM (TURBO)			
1 - H 3	1040BA	OIL PAN, FRONT & REAR HOUSING (TURBO)	1 - K 6	1580B	BRACKET, PULLEY & BELT			
1 - I 3	1100B	ECCENTRIC SHAFT & FLYWHEEL (W/O TURBO)	1 - L 6	1600	CLUTCH DISC & COVER (MANUAL) (W/O TURBO)			
1 - J 3	1100BA	ECCENTRIC SHAFT & FLYWHEEL (TURBO)	1 - M 6	1600A	CLUTCH DISC & COVER (MANUAL) (TURBO)			
1 - K 3	1110B	ROTORS & RELATED PARTS (W/O TURBO)	1 - N 6	1700	TRANSMISSION CASE (MANUAL) (W/O TURBO)			
1 - L 3	1110BA	ROTORS & RELATED PARTS (TURBO)	1 - C 7	1700A	TRANSMISSION CASE (MANUAL) (TURBO)			
1 - M 3	1300B	INTAKE MANIFOLD (W/O TURBO)	1 - D 7	1710	TRANSMISSION GEARS (MANUAL) (W/O TURBO)			
1 - N 3	1300BA	INTAKE MANIFOLD (TURBO)	1 - G 7	1710A	TRANSMISSION GEARS (MANUAL) (TURBO)			
			1 - J 7	1720	CHANGE CONTROL SYSTEM (MANUAL) (W/O TURBO)			
1 - C 4	1310B	EXHAUST MANIFOLD (W/O TURBO)	1 - K 7	1720A	CHANGE CONTROL SYSTEM (MANUAL) (TURBO)			
1 - D 4	1310BA	EXHAUST MANIFOLD (TURBO)	1 - L 7	1800B	ENGINE ELECTRICAL SYSTEM (W/O TURBO)			
1 - G 4	1320B	FUEL SYSTEM (W/O TURBO)	1 - C 8	1800BA	ENGINE ELECTRICAL SYSTEM (TURBO)			
1 - I 4	1320BA	FUEL SYSTEM (TURBO)	1 - F 8	1830B	ALTERNATOR (W/O TURBO)			
1 - K 4	1330B	AIR CLEANER (W/O TURBO)	1 - G 8	1830BA	ALTERNATOR (TURBO)			
1 - L 4	1330BA	AIR CLEANER (TURBO)	1 - H 8	1840B	STARTER (W/O TURBO)			
1 - M 4	1350B	STARTING ASSIST SYSTEM (W/O TURBO)	1 - I 8	1840BA	STARTER (TURBO)			
1 - N 4	1350BA	STARTING ASSIST SYSTEM (TURBO)	1 - J 8	1350B	BATTERY			
			1 - K 8	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)			
1 - C 5	1364B	THROTTLE BODY COMPONENTS (W/O TURBO)	1 - L 8	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)			
1 - D 5	1364BA	THROTTLE BODY COMPONENTS (TURBO)	1 - C 9	1925	CONTROL VALVE (AUTOMATIC)			
1 - E 5	1371B	AIR PUMP & AIR CONTROL VALVE (W/O TURBO)	1 - E 9	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)			
1 - F 5	1371BA	AIR PUMP & AIR CONTROL VALVE (TURBO)	1 - H 9	1940	GOVERNOR, LOW & REVERSE PISTON (AUTOMATIC)			
1 - G 5	1380B	EMISSION CONTROL SYSTEM (EXHAUST SIDE) (W/O TURBO)	1 - I 9	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)			
			1 - J 9	1960	GASKET & SEAL KIT (AUTOMATIC)			

1310B-1

**EXHAUST MANIFOLD  
(W/O TURBO)**





ITEM NO	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	13 3801	PLATE, ABSORBER	N326-13-C80A	1		
	13 390D	INSULATOR, EXHAUST MANIFOLD	N326-13-390B	1		
	13 450	MANIFOLD, EXHAUST	N326-13 450	1		
	13 453B	STUD	N326-40-353	2		5903-
	13 462	GASKET, EXHAUST MANIFOLD	N326-13-461	1		
	40 355A	NUT	2158-40-355	4		
	40 398	STUD	N326-40-353	2		

5903 FC33\* -102271



**1310BA-1 EXHAUST MANIFOLD (TURBO)**



**1310BA-2 EXHAUST MANIFOLD (TURBO)**

**SEE ILLUSTRATION/S AT FRAME 1 - D 4**

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	13 231A	PIPE, AIR	N318-13-332B	1		
	13 232	SEAL, RUBBER	N318-13-246C	1		
	13 240D	PIPE, AIR INTAKE-INTERCOOLER	N318-13-24XA	1		
	13 245	JOINT, RUBBER	N319-13-245A	1		
	13 324B	BOLT, INTERCOOLER	N318-13-324	2		
	13 3631	RUBBER, INSULATION	N318-13-363	4		
	13 390D	INSULATOR, EXHAUST MANIFOLD	N332-13-390A	1		
	13 4J0	MANIFOLD, EXHAUST	N332-13-450A	1		
	13 456	STUD	N318-13-456	4		
	13 457	WASHER, LOCK-TURBO CHARGER	N318-13-457	1		
	13 461C	BOLT	N318-13-453B	2		
	13 462	GASKET, EXHAUST MANIFOLD	N318-13-461	1		
	13 483A	GASKET	N236-13-483	2		
	13 530A	PIPE, WATER INTAKE-TURBO CHARGER	N318-13-530	1		-6401
			N319-13-530A	1		6401-
	13 540C	PIPE, WATER OUTLET-TURBO CHARGER	N319-13-540	1		
	13 546	HOSE, WATER-TURBO CHARGER WATER-PIPE	N318-13-546	1		
	13 550	INTERCOOLER	N332-13-550	1		
	13 555C	RUBBER, SEAL-INTERCOOLER	N318-13-555A	1		
	13 556	SCREW, SEAL RUBBER-INTERCOOLER	N319-13-556A	4		
	13 557	CLIP, SEAL RUBBER-INTERCOOLER	N318-13-557	4		
	13 6051	GASKET	N318-13-711	1		
	13 6071	STUD	N253-13-607A	3		
	13 6201	INSULATOR, TURBO	N332-13-380C	1		
	13 6311	GASKET, OIL PIPE	N236-13-631	1		
	13 6351	PIPE, OIL OUTLET	N318-14-290	1		
	13 6381	GASKET, OIL PIPE	N236-13-638	2		
	13 6391	BOLT, OIL PIPE	N236-13-639	4		
	13 6401	PIPE, OIL INLET	N318-14-270B	1		
	13 6551	PIPE, OIL INLET	N318 14-280C	1		
	13 6701	INSULATOR, TURBO	N332-13-38XC	1		
	13 7001	CHARGER, TURBO	N318-13-700C	1		
	13 70Y	ACTUATOR, EXHAUST VALVE	N332-13-70YA	1		
	13 736	CLAMP, HOSE-A.I. PIPE SIDE	FEH4-13-736	1		
			N318-13-736A	5		
	13 746	JOINT, RUBBER	N236-13-746A	1		
	13 761	GASKET	N318-13-164A	1		

6401 FC33\* -140158


**1310BA-3**

**EXHAUST MANIFOLD  
(TURBO)**

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	20 41Y	PIPE, AIR-VALVE ACTUATOR	N332-20-41YD	1		
	20 523	WASHER, PLAIN	E508-20-523	6		
	20 650	BRACKET, INTERCOOLER	N318-13-56X	1		
	20 820A	CLIP, WATER HOSE-BY. A.C.V.	N318-20-820	1		
	40 355A	NUT	8134-40-355	4		

**SEE ILLUSTRATION/S AT FRAME 1 - D 4**


**1320B-1 FUEL SYSTEM (W/O TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
13 150B		DISTRIBUTOR, FUEL	N326-13-151A	1		
13 153A		BOLT, CONNECTOR	N326-13-153	1		
13 157A		CLIP	8574-13-157	12		
13 158		INSULATOR, FUEL DISTRIBUTOR	N326-13-158	1		
13 164		BOLT, FUEL DISTRIBUTOR	N326-13-164	1		
13 165B		BOLT, FUEL DISTRIBUTOR REAR SIDE	N326-13-165	1		
13 2311		PIPE, DELIVERY	N327-13-151	1		
13 240E		PIPE, CONNECTOR	N326-13-285	1		
13 250A		INJECTOR, FUEL	N326-13-250	4		-7601
		REFER TO SERV. BULL. NO. 049/88, CAT. 4 FOR MORE INFO.				
			N327-13-250	4		7601-
13 252		GROMMET	8574-13-252	4		
13 253		O-RING	8574-13-253	5		
13 257		INSULATOR, INJECTION	N326-13-257	4		
13 2601		SOCKET, AIR BLEED	N326-13-C60	2		
			N305-13-260	2		
13 265		GASKET	N326-60-962	1		
13 280A		PRESSURE REGULATOR, FUEL	N326-13-280	1		
13 290C		DAMPER, PULSATION	N304-13-230	1		
13 291		GASKET	N304-13-291	1		
13 295		CONNECTOR, FUEL	N326-13-295B	1		
13 350		PUMP, FUEL	N326-13-350A	1		
13 363		RUBBER, INSULATION	N236-13-363	2		
13 377		BOLT, CONNECTOR	0552-13-377	1		
13 421		HOSE, FUEL MAIN	N326-13-410	1		
			N326-13-416	1		
13 422		PIPE-FUEL	FE69-13-496	1		-5B01
			8574-13-422	1		5B01-
13 428		PROTECTOR	N326-13-428A	1		
13 428A		PROTECTOR	FEB7-13-428	1		
13 432		HOSE, FUEL	N326-13-431B	1		SA01-
13 4481		CLIP	N326-20-811	1		
13 480		FILTER, FUEL	N326-20-490	1		
13 483A		GASKET	N236-13-483	3		
			N326-13-483	2		
13 496		HOSE, FUEL	N326-13-49XC	1		
13 497		HOSE, FUEL	N327-13-497	2		-SA01
				1		SA01-
13 960		BRACKET, CANISTER	N326-13-961A	1		

5A01 FC33\* -107570  
 5B01 FC33\* -113629  
 7601 FC33\* -550168


**1320B-2 FUEL SYSTEM (W/O TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
13 970		CANISTER	N326-13-970	1		
13 971		HOSE, VENTILATION	N326-13-971	1		
13 ZE1		FILTER, FUEL PUMP	N327-13-ZE1	1		
13 ZE4		WASHER, LOCK-PUMP FILTER	FEH2-13-ZE4	1		
20 237		CONNECTOR, FUEL	N326-13-275B	1		
45 125		HOSE, FUEL	FA66-45-125A	1		5A01-
45 146		PROTECTOR, FUEL HOSE	8116-45-146	1		5A01-
93 5104		HOSE	9935-10-4999	1		
93 5108		HOSE	9935-10-8999	1		

5A01 FC??\* -107570


**1320BA-1 FUEL SYSTEM (TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
13 150B		DISTRIBUTOR, FUEL	N333-13-151	1		
13 153A		BOLT, CONNECTOR	N326-13-153	2		
13 157A		CLIP	8574-13-157	12		
13 158		INSULATOR, FUEL DISTRIBUTOR	N326-13-158	1		
13 164		BOLT, FUEL DISTRIBUTOR	N326-13-164	1		
13 165B		BOLT, FUEL DISTRIBUTOR REAR SIDE	N326-13-165	1		
13 2311		PIPE, DELIVERY	N332-13-151	1		
13 250A		INJECTOR, FUEL REFER TO SERV. BULL. NO. 049/88, CAT. 4 FOR MORE INFO.	N318-13-250	4		-7601
			N319-13-250	4		7601-
13 252		GROMMET	8574-13-252	4		
13 253		O-RING	8574-13-253	4		
13 257		INSULATOR, INJECTION	N326-13-257	4		
13 2601		SOCKET, AIR BLEED	N326-13-C60	2		
			N236-13-260A	2		
13 2611		PLATE, MIXING	N236-13-261	2		
13 265		GASKET	N326-60-962	1		
13 280A		PRESSURE REGULATOR, FUEL	N318-13-280	1		
13 282A		O-RING, PRESSURE REGULATOR	N253-13-282	1		
13 290C		DAMPER, PULSATION	N304-13-230	1		
13 291		GASKET	N304-13-291	1		
13 295		CONNECTOR, FUEL-FUEL DISTRIBUTOR	N318-13-295A	1		
13 350		PUMP, FUEL	N318-13-350A	1		
13 363		RUBBER, INSULATION	N236-13-363	2		
13 421		HOSE, FUEL MAIN	N326-13-416	1		
			N318-13-498	2		
13 422		PIPE-FUEL	8574-13-422	1		
13 428		PROTECTOR	N318-13-428	2		
			N326-13-428A	1		
13 428A		PROTECTOR	FE87-13-428	1		
13 432		HOSE, FUEL	N326-13-431B	1		
13 447		CLIP	N326-13-447	2		
13 4481		CLIP	N326-20-811	1		
13 480		FILTER, FUEL	N326-20-490	1		
13 483A		GASKET	N236-13-483	3		
			N326-13-483	4		
13 490		CONNECTOR, FUEL	N318-13-285	1		
13 496		HOSE, FUEL	N326-13-49XC	1		
13 761		GASKET	N318-13-164A	1		


7601 FC33\* -550168

# 1320BA-2 FUEL SYSTEM (TURBO)



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
13 960		BRACKET, CANISTER	N326-13-961A	1		
13 970		CANISTER	N326-13-970	1		
13 971		HOSE, VENTILATION	N326-13-971	1		
13 2E1		FILTER, FUEL PUMP	N327-13-2E1	1		
13 2E4		WASHER, LOCK-PUMP FILTER	FEH2-13-2E4	1		
20 237		CONNECTOR, FUEL	N318-13-275	1		
45 146		PROTECTOR, FUEL HOSE	8116-45-146	1		
93 5104		HOSE	9935-10-4999	1		
93 5108		HOSE	9935-10-8999	1		


**1330B-1 AIR CLEANER (W/O TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	10 481	CAP	2306-10-481	1	FED.	
	13 104K	CAP, BLIND	N326-13-104	1		
	13 205B	CAP, IDLE SWITCH	1481-13-205C	1		
	13 210A	METER, AIR FLOW	N326-13-210	1		
	13 211	GASKET	N326-13-211C	1		
	13 225	DUCT, FRESH AIR	N326-13-201D	1		
	13 226	CLAMP, HOSE	FE05-13-240	1		
	13 310	BRACKET, AIR CLEANER	N326-20-200A	1		
	13 315A	BRACKET, AIR CLEANER	N326-20-210A	1		
	13 317A	BRACKET, AIR CLEANER	N326-20-220B	1		
	13 320	CLEANER, AIR	N326-13-320B	1		
	13 322	HOSE, AIR INTAKE	N326-13-222B	1		
	13 3251	DUCT, AIR	N326-13-221A	1		
	13 3382	SPACER	FE51-13-329	3		
	13 362B	SCREW	N326-13-234A	8		
	13 363N	RUBBER, MOUNTING	FE51-13-363	3		
	13 7251	HOSE, AIR	N326-20-751	1		
	13 726	CLIP, AIR HOSE	1480-13-726	2		
	13 742A	NUT, CAP	N236-13-742	2		
	13 773	HOSE, AIR-BY-PASS	N326-13-773A	1		
	13 790B	RESISTOR, VARIABLE	N236-13-790B	1		
	23 603	ELEMENT, AIR CLEANER	N326-13-240	1		
	23 615C	DUCT, FRESH AIR	N326-13-202A	1		
	23 6731	COVER, AIR CLEANER	N326-13-201	1		




**1330BA-1 AIR CLEANER (TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	10 481	CAP	2306-10-481	1		
	13 210A	METER, AIR FLOW	N318-13-210	1		
	13 211	GASKET	N326-13-211C	1		
	13 225	DUCT, FRESH AIR	N326-13-201D	1		
	13 2651	VALVE, CHECK	N236-13-265	1		
	13 310	BRACKET, AIR CLEANER	N326-20-200A	1		
	13 315A	BRACKET, AIR CLEANER	N326-20-210A	1		
	13 317A	BRACKET, AIR CLEANER	N326-20-220B	1		
	13 320	CLEANER AIR	N326-13-320B	1		
	13 3251	DUCT, AIR	N319-13-220A	1		
	13 3382	SPACER	FE51-13-329	3		
	13 362B	SCREW	N326-13-234A	8		
	13 363N	RUBBER, MOUNTING	FE51-13-363	3		
	13 7251	HOSE, AIR	N332-20-751B	1		
	13 726	CLIP, AIR HOSE	1480-13-726	5		
	13 765	HOSE, AIR-A.B.S.V. & SURGE TANK	N318-13-765A	1		
	13 786A	HOSE, VENTILATION	N318-13-743	1		
	13 790B	RESISTOR, VARIABLE	N236-13-790B	1		
	20 250	VALVE, AIR BY-PASS	FE67-20-250	1		
	23 603	ELEMENT, AIR CLEANER	N326-13-240	1		
	23 615C	DUCT, FRESH AIR	N326-13-202A	1		
	23 6731	COVER, AIR CLEANER	N326-13-201	1		

**1350B-1 STARTING ASSIST SYSTEM  
(W/O TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
13 17X		CONNECTOR, FLUID HOSE	N326-13-17X	1		
13 5101		TANK, STARTING FLUID	1881-13-510G	1	FED.	
13 5151		BRACKET, TANK	N326-13-A5YB	1	FED.	
13 5271		HOSE	N326-13-A6YC	1		
13 5311		THERMO UNIT	N326-13-A61	1	M/T	
13 540A		VALVE, STARTING FLUID	N326-13-A65A	1	M/T	
13 541		GASKET	N326-13-A66	1		
13 A63		PROTECTOR, HOSE-FLUID	N326-13-A63B	1		
13 A64		HOSE, FLUID-START FLUID	N326-13-A64	1		

**1350BA-1 STARTING ASSIST SYSTEM (TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
13 160D		CONNECTOR	E5B6-13-945	1		
13 17X		CONNECTOR, FLUID HOSE	N326-13-17X	1		
13 5101		TANK, STARTING FLUID	1881-13-510G	1	FED.	
13 5151		BRACKET, TANK	N326-13-A5YB	1	FED.	
13 5271		HOSE	N332-13-A6YB	1		
13 5311		THERMO UNIT	N326-13-A61	1		
13 540A		VALVE, STARTING FLUID	N332-13-A65C	1		
13 541		GASKET	N326-13-A66	1		
13 A63		PROTECTOR, HOSE-FLUID	N332-13-A63	1		
13 A64		HOSE, FLUID-START FLUID	N332-13-A64B	1		

# SECTION INDEX -- ENGINE

ENGINE LOCATION	SECT. NO.	SECTION NAME	ENGINE LOCATION	SECT. NO.	SECTION NAME	ENGINE LOCATION	SECT. NO.	SECTION NAME
1 - C 3	1000B	SHORT ENGINE BLOCK & GASKET SETS (W/O TURBO)	1 - C 6	1400B	OIL PUMP & FILTER (W/O TURBO)			
1 - D 3	1000BA	SHORT ENGINE & GASKET SETS (TURBO)	1 - E 6	1400BA	OIL PUMP & FILTER (TURBO)			
1 - E 3	1030B	ROTOR HOUSINGS (W/O TURBO)	1 - G 6	1500B	COOLING SYSTEM (W/O TURBO)			
1 - F 3	1030BA	ROTOR HOUSINGS (TURBO)	1 - I 6	1500BA	COOLING SYSTEM (TURBO)			
1 - G 3	1040B	OIL PAN, FRONT & REAR HOUSING (W/O TURBO)	1 - K 6	1580B	BRACKET, PULLEY & BELT			
1 - H 3	1040BA	OIL PAN, FRONT & REAR HOUSING (TURBO)	1 - L 6	1600	CLUTCH DISC & COVER (MANUAL) (W/O TURBO)			
1 - I 3	1100B	ECCENTRIC SHAFT & FLYWHEEL (W/O TURBO)	1 - M 6	1600A	CLUTCH DISC & COVER (MANUAL) (TURBO)			
1 - J 3	1100BA	ECCENTRIC SHAFT & FLYWHEEL (TURBO)	1 - N 6	1700	TRANSMISSION CASE (MANUAL) (W/O TURBO)			
1 - K 3	1110B	ROTORS & RELATED PARTS (W/O TURBO)	1 - C 7	1700A	TRANSMISSION CASE (MANUAL) (TURBO)			
1 - L 3	1110BA	ROTORS & RELATED PARTS (TURBO)	1 - D 7	1710	TRANSMISSION GEARS (MANUAL) (W/O TURBO)			
1 - M 3	1300B	INTAKE MANIFOLD (W/O TURBO)	1 - G 7	1710A	TRANSMISSION GEARS (MANUAL) (TURBO)			
1 - N 3	1300BA	INTAKE MANIFOLD (TURBO)	1 - J 7	1720	CHANGE CONTROL SYSTEM (MANUAL) (W/O TURBO)			
1 - C 4	1310B	EXHAUST MANIFOLD (W/O TURBO)	1 - K 7	1720A	CHANGE CONTROL SYSTEM (MANUAL) (TURBO)			
1 - D 4	1310BA	EXHAUST MANIFOLD (TURBO)	1 - L 7	1800R	ENGINE ELECTRICAL SYSTEM (W/O TURBO)			
1 - G 4	1320B	FUEL SYSTEM (W/O TURBO)	1 - C 8	1800BA	ENGINE ELECTRICAL SYSTEM (TURBO)			
1 - I 4	1320BA	FUEL SYSTEM (TURBO)	1 - F 8	1830B	ALTERNATOR (W/O TURBO)			
1 - K 4	1330B	AIR CLEANER (W/O TURBO)	1 - G 8	1830BA	ALTERNATOR (TURBO)			
1 - L 4	1330BA	AIR CLEANER (TURBO)	1 - H 8	1840B	STARTER (W/O TURBO)			
1 - M 4	1350B	STARTING ASSIST SYSTEM (W/O TURBO)	1 - I 8	1840BA	STARTER (TURBO)			
1 - N 4	1350BA	STARTING ASSIST SYSTEM (TURBO)	1 - J 8	1850B	BATTERY			
			1 - K 8	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)			
1 - C 5	1364B	THROTTLE BODY COMPONENTS (W/O TURBO)	1 - L 8	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)			
1 - D 5	1364BA	THROTTLE BODY COMPONENTS (TURBO)	1 - C 9	1925	CONTROL VALVE (AUTOMATIC)			
1 - E 5	1371B	AIR PUMP & AIR CONTROL VALVE (W/O TURBO)	1 - E 9	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)			
1 - F 5	1371BA	AIR PUMP & AIR CONTROL VALVE (TURBO)	1 - H 9	1940	GOVERNOR, LOW & REVERSE PISTON (AUTOMATIC)			
1 - G 5	1380B	EMISSION CONTROL SYSTEM (EXHAUST SIDE) (W/O TURBO)	1 - I 9	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)			
1 - K 5	1380BA	EMISSION CONTROL SYSTEM (EXHAUST SIDE) (TURBO)	1 - J 9	1960	GASKET & SEAL KIT (AUTOMATIC)			

THROTTLE BODY COMPONENTS  
(W/O TURBO)




NOTE  
 ①...③ ⇨ 13-W60  
 THE D-CODE OF 13-W60 CONSISTS OF  
 FIGURE NUMBERS ① THROUGH ③.

NOTE  
 ④...⑤ ⇨ 13-W6X  
 THE D-CODE OF 13-W6X CONSISTS OF  
 FIGURE NUMBERS ④ THROUGH ⑤.

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
13 980A		VALVE, THERMO	N304-13-980A	1	M/T	
			N326-13-980	1	A/T	
13 980F		VALVE, DELAY	N236-13-980A	1	A/T	
13 995		VALVE, CHECK	HE41-13-995	1		
13 W60		SPRING SET, THROTTLE BODY	N326-13-W60	1	M/T	
			N327-13-W60	1	A/T	
13 W61		SPRING, DAMPER	N327-13-W61	1	A/T	
13 W64		LEVER, THROTTLE	N326-13-W64	1		
13 W68		NUT	N326-13-W68	1	A/T	
13 W69		O-RING	N326-13-W69	1		
13 W6X		LEVER SET, THROTTLE BODY	N326-13-W6X	1	M/T	
			N327-13-W6X	1	A/T	
13 W76		SCREW, IDLER ADJUST-THROTTLE BODY	N326-13-W76	1		
13 W7Y		DIAPHRAGM	N326-13-W7Y	1	M/T	
			N327-13-W7Y	1	A/T	
13 W80		BRACKET SET, DASH POT-THROTTLE	N326-13-W80	1		
13 W87		WAX	N326-13-W87	1		
13 W89		GASKET	N326-13-W89	1		
13 W8Y		HOUSING, WAX	N326-13-W8Y	1	M/T	
			N327-13-W8Y	1	A/T	
18 9101		SENSOR, THROTTLE	N326-18-911A	1		
18 9121		BOLT	N304-18-912	2		
20 190A		DASH POT	8341-13-215	1		
20 309		VALVE, VACUUM DELAY	8574-20-309	1	A/T	
20 309B		VALVE, DELAY	HE01-20-309	1	M/T	


# 1364BA-1 THROTTLE BODY COMPONENTS (TURBO)



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	13 980A	VALVE, THERMO	N304-13-980A	1		
	13 995	VALVE, CHECK	HE41-13-995	1		
	13 W60	SPRING SET, THROTTLE BODY	N332-13-W60	1		
	13 W61	SPRING, DAMPER	N332-13-W61	1		
	13 W64	LEVER, THROTTLE	N330-13-W64	1		
	13 W68	NUT	N326-13-W68	1		
	13 W69	O-RING	N326-13-W69	1		
	13 W6X	LEVER SET, THROTTLE ROD	N330-13-W6X	1		
	13 W80	BRACKET SET, DASH POT-THROTTLE	N331-13-W80	1		
	13 W87	WAX	N326-13-W87	1		
	13 W89	GASKET	N330-13-W89	1		
	13 W8Y	HOUSING, WAX	N332-13-W8Y	1		
	18 9101	SENSOR, THROTTLE	N326-18-911A	1		
	18 9121	BOLT	N304-18-912	2		
	20 130	ACTUATOR, SHUTTER VALVE	N332-20-130	1		
	20 190A	DASH POT	HE21-20-190	2		


1371B-1

**AIR PUMP & AIR CONTROL VALVE  
(W/O TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
13 7141		STRAP, AIR PUMP	N326-13-812	1		
13 7151		V-BELT	N304-13-715	1		
13 7181		HOSE, AIR	N304-13-718A	1		
13 7201		VALVE, AIR CONTROL	N326-13-990	1	M/T	
			N327-13-990	1	A/T	
13 7241		GASKET, AIR CONTROL VALVE	N304-13-724A	1		
13 726		CLIP, AIR HOSE	N304-13-726	2		
13 7301		VALVE, CHECK	148U-13-730	1		
13 810		PUMP, AIR	N304-13-710	1		
13 920		BRACKET, AIR PUMP	N326-13-921	1		
15 103		SPACER	N304-15-103	1		
23 7131		PULLEY, A-E PUMP	N304-23-713	1		
23 7251		VALVE, SOLENOID	N250-20-725	1		
			N304-20-725	1		

**1371BA-1 AIR PUMP & AIR CONTROL VALVE (TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
13 7141		STRAP, AIR PUMP	N332-13-812A	1		
13 7151		V-BELT	N332-13-813A	1		
13 7181		HOSE, AIR	N332-20-752B	1		
13 7201		VALVE, AIR CONTROL	N332-13-990	1		
13 7241		GASKET, AIR CONTROL VALVE	N318-13-996	1		
13 726		CLIP, AIR HOSE	N304-13-726	2		
13 7301		VALVE, CHECK	1480-13-730	1		
13 810		PUMP, AIR	N332-13-810	1		
13 920		BRACKET, AIR PUMP	N332-13-921A	1		
18 867		CLIP	FE30-18-867A	1		
23 7131		PULLEY, AIR PUMP	N304-23-713	1		
23 7251		VALVE, SOLENOID	N250-20-725	1		
			N304-20-725	1		




**1380B-1 EMISSION CONTROL SYSTEM (EXHAUST SIDE)  
(W/O TURBO)**

(THIS ILLUSTRATION CONSISTS OF 3 PAGES)








(THIS ILLUSTRATION CONSISTS OF 3 PAGES)



<b>93-5104</b> <b>93-5108</b> (HOSE)			<b>9935-10-4999</b> D=4MM <b>9935-10-8999</b> D=8MM		
<b>18-291B</b> <b>13-447</b> (CLIP)					
	N326-13-447	HE21-18-291			
<b>20-950A</b> (VALVE, PURGE)					
	1480-20-950A				
<b>13-9801</b> (VALVE, DELAY)					
	8712-13-980				

**1380B-2 EMISSION CONTROL SYSTEM (EXHAUST SIDE)  
(W/O TURBO)**

(THIS ILLUSTRATION CONSISTS OF 3 PAGES)



1380B-3

EMISSION CONTROL SYSTEM (EXHAUST SIDE)  
(W/O TURBO)

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
13 170		ACTUATOR, A.P.V.	N326-13-870B	2		
13 171		GASKET	N225-13-171	2		
13 208		HOSE, WATER INLET	N326-13-680A	1		
13 240		VALVE, 3-WAY	1481-13-240A	2		
			1482-13-240A	2		
13 243		HOSE, VACUUM	N326-20-341	1		
13 245		HOSE, VACUUM	N326-20-342	1		
13 246		HOSE, VACUUM	N307-13-246	1		
13 253		HOSE, VACUUM	N236-13-253A	1		
13 283		CHAMBER, AIR	N304-13-283A	1		
13 363		RUBBER, INSULATION	N326-13-363A	2		
13 3D0		PIPE, AIR-B.A.C.V. & A.I.H.	N326-13-3D0C	1		
13 447		CLIP	N326-13-447	2		
13 583		HOSE, AIR	N326-13-755	1		
			N326-13-753A	1		
13 584		HOSE, AIR	N326-13-750A	1		
13 590B		SILENCER, RELIEF	N326-13-C90A	1		
13 645		INSULATOR, THROTTLE BODY	N326-13-645A	1		
13 650		PIPE, VACUUM	N326-20-410D	1		
13 650E		BODY, THROTTLE	N326-13-650A	1	M/T	
			N327-13-650A	1	A/T	
13 682B		HOSE, WATER-B.A.C.V. & T.B.	N326-20-665A	1		
13 683B		HOSE, WATER-B.A.C.V. & R.H.	N326-20-666	1		
13 705		PIPE, AIR	N326-13-890A	1		
13 707		HOSE, AIR	N326-13-896A	1		SA01-
13 720D		VALVE, SOLENOID-AIR BLEED	N327-13-720A	1		
13 726		CLIP, AIR HOSE	N304-13-726	3		
13 740		HOSE, VENT.-PURGE CONTROL	N326-13-740	1		-SA01
			N326-13-740B	1		SA01-
13 742B		HOSE, VENTILATION	N326-13-742A	1		
13 761		GASKET	N326-20-661	1		
13 765		HOSE, AIR-A.B.S.V. & SURGE	N326-13-765	1		
13 766		HOSE, AIR	N326-13-766A	1		
13 772		HOSE, AIR	N326-13-772	1		
13 785		CLIP, WATER HOSE	N326-13-785	6		5901-
13 887		PROTECTOR, SPONGE-AIR HOSE	N326-13-887	1		
13 9801		VALVE, DELAY	712-13-980	1		
18 291B		CLAMP, HOSE	HE21-18-291	1		
20 300		VALVE, E.G.R.	N326-20-300A	1		
20 305A		GASKET, E.G.R. VALVE	N326-20-305	1		
20 380		TUBE, VACUUM	N327-20-381	1	A/T	

SEE ILLUSTRATION/S AT FRAME 1 - G 5

5901 FC33\* -10204  
SA01 FC33\* -107570


**1380B-4 EMISSION CONTROL SYSTEM (EXHAUST SIDE)  
(W/O TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	20 660	VALVE, BY-PASS AIR CONTROL	N326-20-660	1		
	20 950A	VALVE, PURGE REFER TO WARR CAMPAIGN NO. 25711 FOR RECALL INFO. ON CERTAIN 1986 MODELS.	1480-20-950A	1	A/T	
	42 307	CAP	0223-42-307	1	M/T	
	93 5104	HOSE	9935-10-4999	1		
	93 5108	HOSE	9935-10-8999	1		

**SEE ILLUSTRATION/S AT FRAME 1 - G 5**


**1380BA-1 EMISSION CONTROL SYSTEM (EXHAUST SIDE)  
(TURBO)**

(THIS ILLUSTRATION CONSISTS OF 3 PAGES)





93-5104 93-5106 93-5108 (HOSE)		9935-10-4999 D=4MM	
		9935-10-6999 D=6MM	
		9935-10-8999 D=8MM	
20-950A (VALVE, PURGE)			
	1480-20-950A		
13-447 (CLIP)			
	N326-13-447		

(THIS ILLUSTRATION CONSISTS OF 3 PAGES)



1380BA-2 EMISSION CONTROL SYSTEM (EXHAUST SIDE)  
(TURBO)

(THIS ILLUSTRATION CONSISTS OF 3 PAGES)



ITEM NO	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
	13 1041	CAP, BLIND	N318-20-662	1		-6501
			< A > N318-20-662A	1		6501-
	13 240	VALVE, 3-WAY	1481-13-240A	3		
			1482-13-240A	2		
	13 2431	HOSE, VACUUM	N318-20-341A	1		
	13 2451	HOSE, VACUUM	N318-20-342	7		-6601
				6		6601-
	13 283	CHAMBER AIR	N304-13-283A	1		
	13 3631	RUBBER, INSULATION	N326-13-363A	2		
	13 447	CLIP	N326-13-447	2		
	13 583	HOSE, AIR	N326-13-753A	1		
	13 584	HOSE, AIR	N319-13-750A	1		
	13 590B	SILENCER, RELIEF	N326-13-C90A	1		
	13 650	PIPE, VACUUM	N332-20-410B	1		-6711
			N332-20-410C	1		6711-
	13 650E	BODY, THROTTLE	N332-13-650	1		
	13 650K	TUBE, VACUUM	N318-20-343	1		-6711
			N318-20-343A	1		6711-
	13 655A	GASKET	N319-13-645A	1		
	13 671	HOSE, WATER	N318-13-681	1		
	13 682B	HOSE, WATER-B.A.C.V & T B	N318-20-665C	1		
	13 683B	HOSE, WATER-B.A.C.V & R H	N318-20-666C	1		
	13 720D	VALVE, SOLENOID-AIR BLEED	N332-13-720	1		
	13 726	CLIP, AIR HOSE	N304-13-726	3		
	13 740	HOSE, VENT.-PURGE CONTROL VALVE	N332-13-741	1		
	13 744	HOSE, VENTILATION	N318-13-744A	1		
	13 752	HOSE, AIR-A B V & AIR CLEANER	N332-13-761B	1		
	13 752A	HOSE, AIR-EXHAUST MANIFOLD	N332-13-752A	1		
	13 755A	HOSE, AIR	N332-13-755A	1		
	13 760A	VALVE, AIR SUPPLY	N304-13-760B	1		
	13 761	GASKET	N304-13-761A	1		
			N326-20-661	1		
	13 7621	HOSE AIR	N332-13-762B	1		
	13 772	HOSE AIR	N318-13-772	1		
	13 785	CLIP WATER HOSE	N326-13-785	8		
	13 787A	HOSE, VENTILATION	N319-13-742	1		
	13 887A	PROTECTOR, SPONGE-WATER HOSE	N318-13-887A	1		
	20 300	VALVE, E G R	N332-20-300	1		
	20 305A	GASKET, E G R VALVE	N332-20-305A	1		
	20 342	HOSE VACUUM	N332-20-342A	1		

SEE ILLUSTRATION/S AT FRAME 1 - K 5

6501	FC33*	146093
6601	FC33*	152302
6711	FC33*	502690

ITEM NO	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
20 344A		HOSE, AIR-A.C.V & VACUUM PIPE	N318-20-344	1		
20 41X		PIPE NO. 2, VACUUM	N318-20-41XD	1	CAL	6621-
			N332-20-41XB	1	FED	6601-6621
20 660		VALVE, BY-PASS AIR CONTROL	N332-20-660	1	FED	6621-
20 820A		CLIP, WATER HOSE	N318-20-820	1		
20 820B		CLIP, FLUID HOSE	N332-20-820B	1		
20 950A		VALVE PURGE	1480-20-950A	1		
		REFER TO WARR. CAMPAIGN NO 25711 FOR RECALL INFO ON CERTAIN 1986 MODELS.				
41 666B		BRACKET, ACCELERATOR WIRE	FB44-41-666A	1		
93 5104		HOSE	9935-10-4999	1		
93 5106		HOSE	9935-10-6999	1		
93 5108		HOSE	9935-10-8999	1		

SEE ILLUSTRATION/S AT FRAME 1 - K 5


6601 FC33\* -152302  
6621 FC33\* -157179



# SECTION INDEX -- ENGINE

STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME
1 - C 3	1000B	SHORT ENGINE BLOCK & GASKET SETS (W O TURBO)	1 - C 6	1400B	OIL PUMP & FILTER (W/O TURBO)			
1 - D 3	1000BA	SHORT ENGINE & GASKET SETS (TURBO)	1 - E 6	1400BA	OIL PUMP & FILTER (TURBO)			
1 - E 3	1030B	ROTOR HOUSINGS (W O TURBO)	1 - G 6	1500B	COOLING SYSTEM (W/O TURBO)			
1 - F 3	1030BA	ROTOR HOUSINGS (TURBO)	1 - I 6	1500BA	COOLING SYSTEM (TURBO)			
1 - G 3	1040B	OIL PAN, FRONT & REAR HOUSING (W O TURBO)	1 - K 6	1580B	BRACKET, PULLEY & BELT			
1 - H 3	1040BA	OIL PAN, FRONT & REAR HOUSING (TURBO)	1 - L 6	1600	CLUTCH DISC & COVER (MANUAL) (W/O TURBO)			
1 - I 3	1100B	ECCENTRIC SHAFT & FLYWHEEL (W/O TURBO)	1 - M 6	1600A	CLUTCH DISC & COVER (MANUAL) (TURBO)			
1 - J 3	1100BA	ECCENTRIC SHAFT & FLYWHEEL (TURBO)	1 - N 6	1700	TRANSMISSION CASE (MANUAL) (W O TURBO)			
1 - K 3	1110B	ROTORS & RELATED PARTS (W O TURBO)	1 - C 7	1700A	TRANSMISSION CASE (MANUAL) (TURBO)			
1 - L 3	1110BA	ROTORS & RELATED PARTS (TURBO)	1 - D 7	1710	TRANSMISSION GEARS (MANUAL) (W/O TURBO)			
1 - M 3	1300B	INTAKE MANIFOLD (W O TURBO)	1 - G 7	1710A	TRANSMISSION GEARS (MANUAL) (TURBO)			
1 - N 3	1300BA	INTAKE MANIFOLD (TURBO)	1 - J 7	1720	CHANGE CONTROL SYSTEM (MANUAL) (W/O TURBO)			
1 - C 4	1310B	EXHAUST MANIFOLD (W O TURBO)	1 - K 7	1720A	CHANGE CONTROL SYSTEM (MANUAL) (TURBO)			
1 - D 4	1310BA	EXHAUST MANIFOLD (TURBO)	1 - L 7	1800B	ENGINE ELECTRICAL SYSTEM (W/O TURBO)			
1 - G 4	1320B	FUEL SYSTEM (W O TURBO)	1 - C 8	1800BA	ENGINE ELECTRICAL SYSTEM (TURBO)			
1 - I 4	1320BA	FUEL SYSTEM (TURBO)	1 - F 8	1830B	ALTERNATOR (W O TURBO)			
1 - K 4	1330B	AIR CLEANER (W O TURBO)	1 - G 8	1830BA	ALTERNATOR (TURBO)			
1 - L 4	1330BA	AIR CLEANER (TURBO)	1 - H 8	1840B	STARTER (W O TURBO)			
1 - M 4	1350B	STARTING ASSIST SYSTEM (W O TURBO)	1 - I 8	1840BA	STARTER (TURBO)			
1 - N 4	1350BA	STARTING ASSIST SYSTEM (TURBO)	1 - J 8	1850B	BATTERY			
1 - C 5	1364B	THROTTLE BODY COMPONENTS (W O TURBO)	1 - K 8	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)			
1 - D 5	1364BA	THROTTLE BODY COMPONENTS (TURBO)	1 - L 8	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)			
1 - E 5	1371B	AIR PUMP & AIR CONTROL VALVE (W O TURBO)	1 - C 9	1925	CONTROL VALVE (AUTOMATIC)			
1 - F 5	1371BA	AIR PUMP & AIR CONTROL VALVE (TURBO)	1 - E 9	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)			
1 - G 5	1380B	EMISSION CONTROL SYSTEM (EXHAUST SIDE) (W O TURBO)	1 - H 9	1940	GOVERNOR LOW & REVERSE PISTON (AUTOMATIC)			
1 - K 5	1380BA	EMISSION CONTROL SYSTEM (EXHAUST SIDE) (TURBO)	1 - I 9	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)			
			1 - J 9	1960	GASKET & SEAL KIT (AUTOMATIC)			


**1400B-1 OIL PUMP & FILTER (W/O TURBO)**



ITEM NO	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
14 100		PUMP, OIL	N326-14-100A	1		
14 1121		SHAFT, OIL PUMP	N326-14-131	1		
14 1131		RING, SNAP	0810-14-113	1		
14 115		PLUNGER, CONTROL	0221-14-115	1		
14 116		SPRING, PRESSURE	0221-14-116	1		
14 1171		BOLT, LOCK	N326-14-117	1		
14 1181		PLATE, MIDDLE	N326-14-135	1		-6A01
			N326-14-135A	1		6A01-
14 1191		KEY	0839-14-119B	3		
14 125		BOLT, SET	8553-14-125	4		
14 143		WHEEL, SPROCKET	N326-14-143	1		
14 151		CHAIN, OIL PUMP	N326-14-151	1		
14 1711		GASKET, OIL STRAINER	0810-14-171A	1		
14 240		STRAINER, OIL	N326-14-240A	1		-6B01
			N326-14-240B	1		6B01-
14 2501		REGULATOR, PRESSURE	3648-14-250	1		
14 296		CLIP, OIL TUBE	N304-14-667C	1		
14 310A		BODY, OIL FILTER	8341-14-310	1		
14 6001		PUMP, METERING OIL	N246-14-600	1		
14 6031		BOLT, CONNECTOR	N236-14-603B	4		
14 6041		O-RING	N236-14-604	1		
14 606A		TUBE NO. 1, AIR	N326-14-606A	1		
14 607		TUBE NO. 2, AIR	N326-14-607A	1		
14 608		TUBE NO. 3, AIR	N326-14-608B	1		
14 609		TUBE NO. 4, AIR	N326-14-609A	1		
14 6111		GASKET, METERING OIL	N236-14-602A	1		
14 616		TUBE, AIR INLET	N326-14-616A	1		
14 617		CONNECTOR, AIR TUBE	N326-14-617	1		
14 6201		SHAFT, DRIVEN GEAR	0820-14-620A	1		
14 6231		PIN, DRIVEN GEAR	0813-14-623	1		
14 6251		GEAR, DRIVEN	0820-14-625A	1		
14 6301		TUBE, METERING OIL	N326-14-660A	1		
14 6311		BOLT, CONNECTOR	N326-14-631	2		
14 6351		BOLT, CONNECTOR	N236-14-635A	2		
14 6401		TUBE, METERING OIL	N326-14-670A	1		
14 6501		TUBE, METERING OIL	N326-14-680A	1		
14 6511		ROD, CONNECTING	N326-14-651	1		
14 6521		SHIM, ADJUST	N236-14-653	2	T=0.5MM	
			N236-14-652A	1	T=1MM	
14 6601		TUBE, METERING OIL	N326-14-690A	1		
14 668A		CLIP, METERING OIL TUBE	N304-14-668E	1		


6A01 FC33-517640  
6B01 FC33-522333

**1400B-2 OIL PUMP & FILTER (W/C TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
14 6801		VALVE, CHECK	N236-14-639B	2		
23 802		CARTRIDGE, OIL FILTER REFER TO PARTS BULL. NO. T-1-7 FOR MORE INFO.	N3Y6-14-302	1		
23 8821		ROTOR SET, OIL PUMP	N326-14-140	2		

# 1400BA-1 OIL PUMP & FILTER (TURBO)




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
14 100		PUMP, OIL	N318-14-100A	1		
14 1121		SHAFT, OIL PUMP	N326-14-131	1		
14 1131		RING, SNAP	0810-14-113	1		
14 115		PLUNGER, CONTROL	0221-14-115	1		
14 116		SPRING, PRESSURE	0221-14-116	1		
14 1171		BOLT, LOCK	N326-14-117	1		
14 1181		PLATE, MIDDLE	N318-14-135	1		-6A01
			N318-14-135A	1		6A01-
14 1191		KEY	0839-14-119B	2		
14 125		BOLT, SET	8553-14-125	4		
14 140		ROTOR	N318-14-140	2		
14 143		WHEEL, SPROCKET	N326-14-143	1		
14 151		CHAIN, C.I. PUMP	N326-14-151	1		
14 1711		GASKET, OIL STRAINER	0810-14-171A	1		
14 240		STRAINER, OIL	N326-14-240A	1		-6B01
			N326-14-240B	1		6B01-
14 2501		REGULATOR, PRESSURE	364B-14-250	1		
14 296		CLIP, OIL TUBE	N318-14-667	1		
14 310A		BODY, OIL FILTER	8341-14-310	1		
14 331		PLATE, BAFFLE	N318-14-126	1		
14 6001		PUMP, METERING OIL	N318-14-600	1		
14 6031		BOLT, CONNECTOR	N236-14-603B	4		
14 6041		O-RING	N236-14-604	1		
14 606A		TUBE NO. 1, AIR	N318-14-606A	1		
14 607		TUBE NO. 2, AIR	N318-14-607	1		
14 608		TUBE NO. 3, AIR	N318-14-608	1		
14 609		TUBE NO. 4, AIR	N318-14-609	1		
14 6111		GASKET, METERING OIL	N236-14-602A	1		
14 616		TUBE, AIR INLET	N318-14-616A	1		
14 617		CONNECTOR, AIR TUBE	N326-14-617	1		
14 6201		SHAFT, DRIVEN GEAR	0820-14-620A	1		
14 6231		PIN, DRIVEN GEAR	0813-14-623	1		
14 6251		GEAR, DRIVEN	0820-14-625A	1		
14 6301		TUBE, METERING OIL	N318-14-660B	1		
14 6311		BOLT, CONNECTOR	N326-14-631	2		
14 6351		BOLT, CONNECTOR	N236-14-635A	2		
14 6401		TUBE, METERING OIL	N318-14-670B	1		
14 6501		TUBE, METERING OIL	N318-14-680B	1		
14 6511		ROD, CONNECTING	N318-14-651	1		
14 6521		SHIM, ADJUST	N236-14-653	2	T=0.5MM	
			N236-14-652A	1	T=1MM	
6A01	FC33*	-517640				
6B01	FC33*	-522333				

**1400BA-2 OIL PUMP & FILTER (TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
14 6601		TUBE, METERING OIL	N318-14-690A	1		
14 668A		CLIP, M. OIL TUBE	N318-14-668A	1		
14 6801		VALVE, CHECK	N236-14-639B	2		
23 802		CARTRIDGE, OIL FILTER	N3Y6-14-302	1		
		REFER TO PARTS BULL. NO. T-1-7 FOR MORE INFO.				


# 1500B-1 COOLING SYSTEM (W/O TURBO)



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
13 413A		PIPE, CONNECTOR	D410-13-413	1		
14 7001		COOLER, OIL	N326-14-700A	1		
14 7102		HOSE, OIL	N326-14-710B	1		
14 717		CLIP, OIL HOSE	N326-14-717B	1		
14 7202		HOSE, OIL	N326-14-720B	1		
14 7401		BRACKET, OIL HOSE	N326-14-760B	1		
14 743		PROTECTOR	N326-14-736	1		
14 746		PROTECTOR	N326-14-737	1		
14 8101		PELLET, THERMO	8871-14-810	1		
14 8211		SPRING, PELLET	1757-14-821	1		
14 8221		NUT, STOPPER	1757-14-822	1		
14 8231		GASKET	1757-14-823	1		
15 010		PUMP, WATER	8AF2-15-010	1	M/T	
			8AF3-15-010	1	A/T	
15 010S		PUMP SET, WATER	8AF2-15-010	1	M/T	6601-6C16
			8AF2-15-010A	1	M/T	6C16-
			8AF3-15-010	1	A/T	6601-6C16
			8AF3-15-010A	1	A/T	6C16-
15 035		FAN, ADDITIONAL	N326-15-035A	1	A/T	
15 081		GASKET	1757-15-106	2		-7201
			N326-15-168	2		7201-
15 100T		HOUSING SET, WATER PUMP	8AF1-15-100A	1		
15 103		SPACER	N304-15-103	1		
15 116		GASKET, WATER PUMP	N326-15-116A	1		
15 117B		HUB, WATER PUMP PULLEY	N326-15-117A	1		
15 120		SEAL, WATER PUMP	8AF30-15-120	1		-7601
15 125		PLATE, WATER BAFFLE	N304-15-125	1		
15 131		PULLEY, WATER PUMP	N326-15-131A	1		
15 140		FAN, COOLING	N326-15-141	1		
15 140A		FAN, COOLING	N326-15-142	1	A/T	
15 150A		MOTOR, COOLING FAN	N326-15-151	1	A/T	
15 162		GASKET	N326-15-162	1		
15 171S		THERMOSTAT SET	8AF1-15-171	1		
15 172		COVER, THERMOSTAT	N326-15-172B	1	M/T	
			N318-15-172A	1	A/T	
15 173		GASKET, THERMOSTAT COVER	1757-15-173	1		
15 174A		RING	N326-15-174	1		
15 175B		BODY, FILLER CAP	N326-15-175A	1		
15 17Y		CAP, FILLER-WATER PUMP	N326-15-17YA	1		
15 17YA		CAP SET, FILLER-RADIATOR	N323-15-17Y	1		
15 182		CLAMP, WATER HOSE	N326-15-182	4		

- 6601 FC33\* -152302
- 6C16 FC33\* -527275
- 7201 FC33\* -532667
- 7601 FC33\* -550168


# 1500B-2 COOLING SYSTEM (W/O TURBO)



ITEM NO.	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
15 185		HOSE, WATER	N326-15-185A	1		
15 186		HOSE, WATER	N326-15-186A	1		
15 200		RADIATOR	N326-15-200C	1	M/T	
			< C > N326-15-200D	1	M/T	
			N327-15-200C	1	A/T	
			< C > N327-15-200D	1	A/T	REQUIRES PIPE: D410-13-413 & CAP, N323-15-17Y
15 202		RUBBER, MOUNTING	N326-15-202	4		
15 205		CAP, RADIATOR	D316-15-205	1		-6C16
			N321-15-205	1		6C16-
			N323-15-205	1		6C16-
15 207		COCK, DRAIN	N326-15-203	2		
15 2101		FAN DRIVE	N326-15-150	1		
15 210A		COWLING, RADIATOR	N326-15-211B	1		
15 210B		COWLING, FAN	N326-15-15X	1	A/T	
15 224A		RUBBER, SEAL	N326-15-156	3	A/T	
15 226		BOLT	N326-15-153	3	A/T	
15 227		SUPPORT, SEAL RUBBER	N326-15-154	3	A/T	
15 228		SEAL, AIR-ADDITIONAL FAN	N326-15-228	1	A/T	
15 234		TANK, UPPER-RADIATOR	N326-15-V02	1		
15 2501		FAN & FAN DRIVE	N326-15-140	1		
15 251		BRACKET, SUB TANK	N332-15-370B	2		
15 2702		SEAL (L), RADIATOR	N326-15-441	1		
15 277		HOSE, WATER SUB TANK	N326-15-381A	1		-6201
			N332-15-381A	1		6201-6C16
			N332-15-381B	1		6C16-
15 2802		SEAL (R), RADIATOR	N326-15-421	1		
15 350		TANK, SUB-RADIATOR	N326-15-350A	1		-6201
			N332-15-350B	1		6201-
15 355A		CAP, SUB TANK	N326-15-355A	1		-6201
			N332-15-355	1		6201-
15 382		PROTECTOR, HOSE-SUB TANK	N332-15-382	1		6201
15 388		CLIP, HOSE-SUB TANK & WATER HOSE	N327-15-388	1		-6C16
15 V03		BRACKET (R), RADIATOR	N326-15-V03	1		
15 V12		BRACKET (L), RADIATOR	N326-15-V12	1		

6201 FC33\* -129445  
6C16 FC33\* -527275

# 1500BA-1 COOLING SYSTEM (TURBO)




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
13 413A		PIPE, CONNECTOR	D410-13-413	1		
14 7001		COOLER, OIL	N326-14-700A	1		
14 7102		HOSE, OIL	N326-14-710B	1		
14 717		CLIP, OIL HOSE	N326-14-717B	1		
14 7202		HOSE, OIL	N326-14-720B	1		
14 7401		BRACKET, OIL HOSE	N326-14-740B	1		
14 743		PROTECTOR	N326-14-736	1		
14 746		PROTECTOR	N326-14-737	1		
14 8101		PELLET, THERMO	8871-14-810	1		
14 8211		SPRING, PELLET	1757-14-821	1		
14 8221		NUT, STOPPER	1757-14-822	1		
14 8231		GASKET	9956-42-200	1		
15 010		PUMP, WATER	8AF4-15-010	1		
15 010S		PUMP SET, WATER	8AF4-15-010	1		6601-6C16
			8AF4-15-010A	1		6C16-
15 035		FAN, ADDITIONAL	N326-15-035A	1		
15 081		GASKET	1757-15-106	2		.7201
			N326-15-168	2		7201-
15 100T		HOUSING SET, WATER PUMP	8AF1-15-100A	1		
15 116		GASKET, WATER PUMP	N326-15-116	1		
15 117B		HUB, WATER PUMP PULLEY	N326-15-117A	1		
15 120		SEAL, WATER-PUMP	8630-15-120	1		.7401
15 125		PLATE, WATER BAFFLE	N304-15-125	1		
15 131		PULLEY, WATER PUMP	N326-15-131A	1		
15 140		FAN, COOLING	N326-15-141	1		
15 140A		FAN, COOLING	N326-15-142	1		
15 150A		MOTOR, COOLING FAN	N326-15-151	1		
15 162		GASKET	N326-15-162	1		
15 1715		THERMOSTAT SET	8AF1-15-171	1		
15 172		COVER, THERMOSTAT	N318-15-172A	1		
15 173		GASKET, THERMOSTAT COVER	1757-15-173	1		
15 174A		RING	N326-15-174	1		
15 175B		BODY, FILLER CAP	N326-15-175A	1		
15 17Y		CAP, FILLER-WATER PUMP	N326-15-17YA	1		.6C16
15 17YA		CAP SET, FILLER-RADIATOR	N323-15-17Y	1		6C16-
15 182		CLAMP, WATER HOSE	N326-15-182	4		
15 185		HOSE, WATER	N326-15-185A	1		
15 186		HOSE, WATER	N326-15-186A	1		
15 210		RADIATOR	N326-15-200C	1		
		<C>	N326-15-200D	1	REQUIRES PIPE: D410-13-413 & CAP: N323-15-17Y	

6601	FC33*	-152302
6C16	FC33*	-527275
7201	FC33*	-532667
7601	FC33*	-550168





# 1500BA-2 COOLING SYSTEM (TURBO)



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
15 202		RUBBER, MOUNTING	N326-15-202	4		
15 205		CAP, RADIATOR	D316-15-205	1		-6C16
			N321-15-205	1		6C16-
			N323-15-205	1		6C16-
15 207		COCK, DRAIN	N326-15-203	2		
15 2101		FAN DRIVE	N326-15-150	1		
15 210A		COWLING, RADIATOR	N326-15-211B	1		
15 210B		COWLING, FAN	N326-15-15X	1		
15 224A		RUBBER, SEAL	N326-15-156	3		
15 226		BOLT	N326-15-153	3		
15 227		SUPPORT, SEAL RUBBER	N326-15-154	3		
15 228		SEAL, AIR-ADDITIONAL FAN	N326-15-228	1		
15 234		TANK, UPPER-RADIATOR	N326-15-V02	1		
15 2501		FAN & FAN DRIVE	N326-15-140	1		
15 251		BRACKET, SUB TANK	N332-15-370B	2		
15 2702		SEAL (L), RADIATOR	N326-15-441	1		
15 277		HOSE, WATER SUB TANK	N332-15-381A	1		-6C16
			N332-15-381B	1		6C16-
15 2802		SEAL (R), RADIATOR	N326-15-421	1		
15 350		TANK, SUB-RADIATOR	N332-15-350B	1		
15 355A		CAP, SUB TANK	N332-15-355	1		
15 382		PROTECTOR, HOSE-SUB TANK	N332-15-382	1		
15 388		CLIP, HOSE-SUB TANK & WATER HOSE	N327-15-388	1		-6C16
15 V03		BRACKET (R), RADIATOR	N326-15-V03	1		
15 V12		BRACKET (L), RADIATOR	N326-15-V12	1		


6C16 FC33\* -527275

1580B-1 BRACKET, PULLEY & BELT



AC	AIR CON.	SECT.NO.	D-CODE
AN	ALTERNATOR	1371	13-7151
AP	AIR PUMP	1580	15-907
DP	DRIVE PULLEY	1580	15-907
IP	IDLE PULLEY	1800	18-381
PS	POWER STEERING		
WP	WATER PUMP		


<P.S.KIT>  
(W/P.S.)  
(W/P.S., W/O AIR CON.)




<A/C KIT>  
(W/P.S., W/AIR CON. - JAPAN MAKE)  
(W/O P.S., W/AIR CON. - JAPAN MAKE)

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
15 907		V-BELT	N326-15-908	1	L=96.5CM TURBO FACTORY A/C	
			N326-15-909	1	L=105.5CM P/S	
15 920		BRACKET, COMPRESSOR	N327-15-811	1	TURBO W/O P/S, W/ A/C	
			N326-15-910A	1	TURBO W/ P/S & A/C	
			N327-15-910A	1	NON-TURBO	
15 925A		BUSHING	N326-15-812	1	P/S	
15 932		SHAFT, PULLEY	N249-15-932A	1	NON-TURBO	
			N326-15-932	1	TURBO	
15 933		COLLAR, COMPRESSOR BRACKET	N326-15-933	1	TURBO	
15 933B		SPACER	N249-15-933	2		
15 934		COVER, DUST	N326-15-934	1	TURBO	
15 940		PULLEY, IDLE	N249-15-940	1		
			R230-15-940	1	TURBO	
15 940J		BEARING	9960-62-203	1		
942		COLLAR, COMPRESSOR BRACKET-PULLEY	N249-15-942	1		
966		BOLT, ADJUST	N326-15-966	1	TURBO W/O P/S	
			N327-15-966	1	TURBO W/ P/S	
			N328-15-966	1	NON-TURBO P/S	


**1600-1 CLUTCH DISC & COVER (MANUAL)  
(W/O TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
16 102		PIN, PIVOT-CLUTCH RELEASE FORK	0603-16-102B	1		
16 103A		SEAL, OIL	0603-16-103	1		
16 145		RUBBER, SEAL	N204-16-145	1		
16 146		COVER, VENTILATION	N302-16-150B	1		
16 214		COVER, DUST-CLUTCH FORK	3975-16-214A	1		
16 220		COVER, FRONT CLUTCH	N204-16-220A	1		
16 225		GASKET, FRONT COVER	8540-16-225	1		
16 232A		SUPPORTER, FORK	1416-16-232A	1		
16 241		PLUG, BLIND	8540-16-241A	1		
16 410		COVER, CLUTCH	N206-16-410 N304-16-410	1	COUPE CONVERTIBLE	
16 432		BOLT	0839-16-432	2		
16 460		DISC, CLUTCH	N303-16-460	1		
16 510		COLLAR, CLUTCH RELEASE	H606-16-510A	1		
16 520		FORK, CLUTCH RELEASE	N204-16-520	1		



ITEM NO	D-CODE	DESCRIPTION	PART NO	QTY	MODEL DESCRIPTION	REMARKS
16 102		PIN, PIVOT-CLUTCH RELEASE FORK	N302-16-102	1		
16 103A		SEAL, OIL	0403-16-103	1		
16 118		STUD, CLUTCH HOUSING	N302-16-118A	4		
16 121		COVER, UNDER CLUTCH HOUSING	N302-16-140	1		
16 146		COVER, VENTILATION	N302-16-150B	1		
16 210		HOUSING, CLUTCH	N302-16-210B	1		
16 214		COVER, DUST-CLUTCH FORK	N302-16-214	1		
16 220		COVER, FRONT CLUTCH	N302-16-221	1		
16 232A		SUPPORTER, FORK	1416-16-232A	1		
16 410		COVER, CLUTCH	JE01-16-410B	1		
16 460		DISC, CLUTCH	N307-16-460	1		
16 510		COLLAR, CLUTCH RELEASE	F853-16-510	1		
16 520		FORK, CLUTCH RELEASE	N302-16-520	1		
17 337		BOLT	R401-17-337A	8		




ITEM NO.	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
17 100		CASE, T/MISSION	M511-17-100B	1		
			< A > M511-17-100C	1		
17 122		PLUG, MAGNET	0810-17-121	1		
17 325		COVER, BEARING	8086-17-326	1		
17 330		HOUSING, EXTENSION	M517-17-330A	1		
17 335A		SEAL, OIL	0437-17-335A	1		
17 441		GEAR, DRIVEN	0862-17-441A	1	N=19 CONVERTIBLE	
			1669-17-441A	1	N=20 COUPE	
17 442		SLEEVE, SPEEDOMETER	1669-17-442B	1		
17 442J		O-RING	1011-17-443	1		
17 442K		SEAL, OIL	9958-60-8166	1		
17 530		BREATHER, AIR-T. MISSION	0884-17-530	1		
17 540		PASS, OIL	8086-17-540A	1		.7201
			M501-17-550A	1		7201-
17 543		RUBBER, SEAL	M501-17-543A	1		7201-

7201 FC33\* 532667

# SECTION INDEX -- ENGINE

STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME
1 - C 3	1000B	SHORT ENGINE BLOCK & GASKET SETS (W/O TURBO)	1 - E 6	1400BA	OIL PUMP & FILTER (TURBO)			
1 - D 3	1000BA	SHORT ENGINE & GASKET SETS (TURBO)	1 - G 6	1500B	COOLING SYSTEM (W/O TURBO)			
1 - E 3	1030B	ROTOR HOUSINGS (W/O TURBO)	1 - I 6	1500BA	COOLING SYSTEM (TURBO)			
1 - F 3	1030BA	ROTOR HOUSINGS (TURBO)	1 - K 6	1580B	BRACKET, PULLEY & BELT			
1 - G 3	1040B	OIL PAN, FRONT & REAR HOUSING (W/O TURBO)	1 - L 6	1600	CLUTCH DISC & COVER (MANUAL) (W/O TURBO)			
1 - H 3	1040BA	OIL PAN, FRONT & REAR HOUSING (TURBO)	1 - M 6	1600A	CLUTCH DISC & COVER (MANUAL) (TURBO)			
1 - I 3	1100B	ECCENTRIC SHAFT & FLYWHEEL (W/O TURBO)	1 - N 6	1700	TRANSMISSION CASE (MANUAL) (W/O TURBO)			
1 - J 3	1100BA	ECCENTRIC SHAFT & FLYWHEEL (TURBO)	1 - C 7	1700A	TRANSMISSION CASE (MANUAL) (TURBO)			
1 - K 3	1110B	ROTORS & RELATED PARTS (W/O TURBO)	1 - D 7	1710	TRANSMISSION GEARS (MANUAL) (W/O TURBO)			
1 - L 3	1110BA	ROTORS & RELATED PARTS (TURBO)	1 - G 7	1710A	TRANSMISSION GEARS (MANUAL) (TURBO)			
1 - M 3	1300B	INTAKE MANIFOLD (W/O TURBO)	1 - J 7	1720	CHANGE CONTROL SYSTEM (MANUAL) (W/O TURBO)			
1 - N 3	1300BA	INTAKE MANIFOLD (TURBO)	1 - K 7	1720A	CHANGE CONTROL SYSTEM (MANUAL) (TURBO)			
1 - C 4	1310B	EXHAUST MANIFOLD (W/O TURBO)	1 - L 7	1800B	ENGINE ELECTRICAL SYSTEM (W/O TURBO)			
1 - D 4	1310BA	EXHAUST MANIFOLD (TURBO)	1 - C 8	1800BA	ENGINE ELECTRICAL SYSTEM (TURBO)			
1 - G 4	1320B	FUEL SYSTEM (W/O TURBO)	1 - F 8	1830B	ALTERNATOR (W/O TURBO)			
1 - I 4	1320BA	FUEL SYSTEM (TURBO)	1 - G 8	1830BA	ALTERNATOR (TURBO)			
1 - K 4	1330B	AIR CLEANER (W/O TURBO)	1 - H 8	1840B	STARTER (W/O TURBO)			
1 - L 4	1330BA	AIR CLEANER (TURBO)	1 - I 8	1840BA	STARTER (TURBO)			
1 - M 4	1350B	STARTING ASSIST SYSTEM (W/O TURBO)	1 - J 8	1850B	BATTERY			
1 - N 4	1350BA	STARTING ASSIST SYSTEM (TURBO)	1 - K 8	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)			
1 - C 5	1364B	THROTTLE BODY COMPONENTS (W/O TURBO)	1 - L 8	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)			
1 - D 5	1364BA	THROTTLE BODY COMPONENTS (TURBO)	1 - C 9	1925	CONTROL VALVE (AUTOMATIC)			
1 - E 5	1371B	AIR PUMP & AIR CONTROL VALVE (W/O TURBO)	1 - E 9	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)			
1 - F 5	1371BA	AIR PUMP & AIR CONTROL VALVE (TURBO)	1 - H 9	1940	GOVERNOR (LOW & REVERSE PISTON) (AUTOMATIC)			
1 - G 5	1380B	EMISSION CONTROL SYSTEM (EXHAUST SIDE) (W/O TURBO)	1 - I 9	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)			
1 - K 5	1380BA	EMISSION CONTROL SYSTEM (EXHAUST SIDE) (TURBO)	1 - J 9	1960	GASKET & SEAL KIT (AUTOMATIC)			
1 - C 6	1400B	OIL PUMP & FILTER (W/O TURBO)						


**1700A-1 TRANSMISSION CASE (MANUAL)  
(TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL DESCRIPTION	REMARKS
17 100		CASE, T:MISSION	R503-17-200E	1		
17 121B		MAGNET	B501-17-121	1		6402-
17 121C		PLUG, MAGNET	0107-17-121	1		
17 122		PLUG, MAGNET	0810-17-121	1		
17 325		COVER, BEARING	0884-17-325B	1		
17 330		HOUSING, EXTENSION	R503-17-330C	1		
17 335		SEAL, OIL	M502-17-335A	1		
17 337		BOLT	R501-17-337A	5		
17 337A		BOLT	R504-17-337	1		
17 338		BOLT	R501-17-338A	1		
17 371		COVER, UNDER	0862-17-371	1		.6402
			R501-17-371A	1		6402-
17 373A		PLATE, DRAIN PLUG-UNDER COVER	R501-17-373	1		6402-
17 375		GASKET UNDER COVER	R501-17-375	1		
17 381		COVER, BLIND	0810-17-381A	2		
17 385		GASKET, BLIND COVER	0810-17-385	2		
17 441		GEAR, DRIVEN	1669-17-441A	1	N=20	
17 442		SLEEVE, SPEEDOMETER	1669-17-442B	1		
17 442J		O-RING	1011-17-443	1		
17 442K		SEAL, OIL	9958-60-8166	1		
17 530		BREATHER, AIR-T:MISSION	0884-17-530	1		
17 540		PASS, OIL	R502-17-540B	1		
17 543		RUBBER, SEAL	M501-17-543A	1		
17 550		GUIDE, OIL	1281-17-550	1		
17 660		PASS, OIL	0862-17-660C	1		
43 608		SPACER	1281-17-383	2		

6402 FC33\* .140427

**1710-1 TRANSMISSION GEARS (MANUAL)  
(W/O TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
17 201		GEAR, MAIN DRIVE	M515-17-201A	1		
17 201J		BEARING, BALL-MAIN DRIVE GEAR	M502-17-295C	1		
17 203		BEARING, NEEDLE	M501-17-210	1		
17 204		BEARING, BALL-MAIN SHAFT	M503-17-204	1		7123-
17 205		BEARING, ROLLER	R502-17-306	1		
			<C> R502-17-306A	1	REQUIRES SPACER: R502-17-316	
17 221		SHAFT, MAIN	M505-17-221A	1		
17 221J		BEARING, BALL	M503-17-204	1		.7123
17 225		RING, SNAP	0317-17-225	1		
17 230		GEAR, 3RD	M510-17-231A	1		
17 241		HUB, CLUTCH	M508-17-261A	1	3RD GEAR, OVERTOP	
17 242A		SLEEVE, CLUTCH HUB	F401-17-242A	1	OVERTOP	
17 243		KEY, SYNCHRONIZER	F401-17-243A	9		
17 250		GEAR, 2ND	M508-17-251	1		
17 261		HUB, CLUTCH	M502-17-261	1	1ST, 2ND	
17 262		SLEEVE, CLUTCH HUB	M503-17-262	1	1ST, 2ND	
17 264		SPRING, SYNCHRONIZER KEY	G401-17-264	2	1ST, 2ND	
17 264A		SPRING, SYNCHRONIZER	F401-17-264A	2	2ND	
17 265		RING, SYNCHRONIZER	M502-17-265A	2	1ST, 2ND	
17 271		GEAR, 1ST	M510-17-271	1		
17 274		BEARING, NEEDLE	4069-17-283A	2		
17 275		RACE, INNER	4069-17-284E	1	REVERSE	
17 276		WASHER, THRUST	0259-17-276	2	T=2.2MM	
			0259-17-277	2	T=2.7MM	
			0259-17-274A	2	T=3MM	
			0259-17-278	2	T=3.2MM	
			0259-17-279	2	T=3.7MM	
17 279		SLEEVE, GEAR	8540-17-275A	1	1ST	
17 281		GEAR, REVERSE	M501-17-281B	1		
17 287J		SHIM, ADJUST	9996-36-310	2	T=0.1MM	
			9996-36-315	1	T=0.15MM	
			9996-36-330	2	T=0.3MM	
17 297		BEARING, BALL-COUNTER SHAFT GEAR	R502-17-306	1		
			<C> R502-17-306A	1	REQUIRES SPACER: R502-17-316	
17 297A		BEARING, BALL-COUNTER SHAFT GEAR	M502-17-297A	1		
17 298		BEARING	M502-17-298A	1		
17 301		GEAR, COUNTER SHAFT	M519-17-300B	1		
17 302		GEAR, COUNTER REVERSE	J386-17-302C	1		.7301

7123 FC33\* -531326  
7301 FC33\* -537230




**1710-2 TRANSMISSION GEARS (MANUAL)  
(W/O TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
17 302	(CONT'D)		M503-17-302B	1		7301-
17 302A		GEAR, FRICTION	M502-17-302B	1		
17 303C		SPRING, DIAPHRAGM	M501-17-303	1		
17 304		SPACER	M504-17-304	1		
17 304B		SPACER	M501-17-304B	1		
17 305A		RING, RETAINING-BALL BEARING	0839-17-305B	1		
17 306		BEARING, BALL	M502-17-299A	1		
17 308		GEAR, COUNTER	M504-17-308	1		-6422
		REFER TO SERV. BULL. NO. 020/86, CAT. 7 FOR MORE INFO.				
			M507-17-308	1		6422-
17 309B		NUT, LOCK-COUNTER SHAFT BRACKET	M501-17-309	1		
17 310		GEAR, REVERSE IDLE	M504-17-310C	1		
17 313		WASHER, THRUST-REVERSE IDLE GEAR	4069-17-313	1		
17 313B		WASHER, THRUST	4077-17-316	1	T=2.6MM	
			4077-17-314A	1	T=2.8MM	
			4077-17-315A	1	T=3MM	
17 315		SHAFT, REVERSE IDLE GEAR	8086-17-140A	1		
17 327		SHIM, ADJUST-COUNTER SHAFT GEAR	0305-17-327	2	T=0.1MM	
			0305-17-328	1	T=0.3MM	
17 341A		GEAR, SPEEDOMETER DRIVE	1281-17-341	1		
17 611		GEAR, OVERTOP	M509-17-611	1		-6422
		REFER TO SERV. BULL. NO. 020/86, CAT. 7, FOR MORE INFO.				
			M512-17-611	1		6422-
17 621		HUB, CLUTCH	M510-17-261	1	OVERTOP & REVERSE	
17 626A		RING, RETAINING-CLUTCH HUB	3648-17-626	1	OVERTOP & REVERSE	
17 629		NUT, LOCK-CLUTCH HUB	8601-17-629	1		
17 631		WASHER, THRUST LOCK-OVERTOP GEAR	0884-17-632B	1	T=6.2MM	
			0884-17-633B	1	T=6.4MM	
			0884-17-634B	1	T=6.5MM	
			0884-17-635B	1	T=6.6MM	
17 651		WASHER, THRUST	M501-17-655	2	T=2.9MM	
			M501-17-651	4	T=3MM	
			M501-17-653	2	T=3.1MM	
			M501-17-654	2	T=3.2MM	
17 652		RING, THRUST WASHER	M501-17-652	2		


6422 FC33\* -144863  
730 FC33\* -537230

**1710.3 TRANSMISSION GEARS (MANUAL)  
(W/O TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
17 724A		SPRING, SYNCHRONIZER KEY	W501-17-724	2	3RD & OVERTOP	
17 725A		RING, SYNCHRONIZER	W501-17-725A	2	3RD & OVERTOP	
17 725C		RING, SYNCHRONIZER	V501-17-725	1	OVERTOP	
17 732		SLEEVE, CLUTCH HUB	W501-17-732A	1	3RD & OVERTOP	


**1710A-1 TRANSMISSION GEARS (MANUAL)  
(TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
17 10AK		SHIM, ADJUST	9996-36-910	2	T=0.1MM	
			9996-36-930	1	T=0.3MM	
17 201		GEAR, MAIN DRIVE	R501-17-21XA	1		
17 201J		BEARING, BALL-MAIN DRIVE GEAR	R421-17-295	1		
17 203A		SPRING, DIAPHRAGM	R502-17-203A	1		6311-7201
			R504-17-203	1		7201-7421
17 204		BEARING, BALL-MAIN SHAFT	R421-17-204	1	1ST	
			9960-66-3563	1	OVERTOP	
17 205		BEARING, ROLLER	R502-17-306	1		
			<C> R502-17-306A	1	REQUIRES SPACER. R502-17-316	
17 205B		BEARING, NEEDLE	H505-17-283A	1		
17 221		SHAFT, MAIN	R503-17-221B	1		
17 225		RING, SNAP	0317-17-225	1		
17 230		GEAR, 3RD	R502-17-231B	1		
17 241		HUB, CLUTCH	R501-17-241	1	3RD, OVERTOP	
17 242		SLEEVE, CLUTCH HUB	R501-17-242	1	3RD, OVERTOP	
17 242A		SLEEVE, CLUTCH HUB	F401-17-242A	1	REVERSE	-6801
17 243		KEY, SYNCHRONIZER	F401-17-243A	6	3RD, REVERSE	
17 250		GEAR, 2ND	R502-17-250A	1		
17 261		HUB, CLUTCH	R501-17-261	1	1ST, 2ND	
17 262		SLEEVE, CLUTCH HUB	R501-17-262	1		
17 263A		KEY, SYNCHRONIZER	W501-17-263A	3		
17 264		SPRING, SYNCHRONIZER KEY	G402-17-264	2	3RD, OVERTOP	
17 264A		SPRING, SYNCHRONIZER	R501-17-264	2	1ST, 2ND	
			F401-17-264A	2	REVERSE	-6801
17 265		RING, SYNCHRONIZER	M502-17-265A	2	1ST, 2ND	
17 265A		RING, SYNCHRONIZER	R502-17-265A	2	1ST, 2ND	
17 265B		RING, SYNCHRONIZER	R503-17-265A	1	REVERSE	6801-
17 271		GEAR, 1ST	R502-17-270A	1		
17 274		BEARING, NEEDLE	0884-17-274	4		
17 275		RACE, INNER	3648-17-275A	1	REVERSE	
17 275B		RACE, INNER	0884-17-275B	1	1ST	
17 276		WASHER, THRUST	0839-17-276	1	T=2.5MM	
			0839-17-277	2	T=3MM	
			0839-17-278	1	T=3.5MM	
17 281		GEAR, REVERSE	R501-17-281A	1		-6801
			R502-17-281A	1		6801-
17 287		SHIM, ADJUST	0839-17-287	2	T=0.1MM	
			0839-17-288	1	T=0.3MM	
17 301		GEAR, COUNTER SHAFT	R506-17-300G	1		


6311 FC33\* -136264  
 6801 FC33\* -522333  
 7201 FC33\* -532667  
 7421 FC33\* -547007

**1710A-2 TRANSMISSION GEARS (MANUAL)  
(TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
17 301J		BEARING, BALL	R521-17-299	1		
17 302		GEAR, COUNTER REVERSE	0821-17-302A	1		-6801
			R501-17-302	1		6801-
17 302A		GEAR, FRICTION	R502-17-304B	1		-6311
17 303		BEARING, BALL	0821-17-303	1		
17 303C		SPRING, DIAPHRAGM	M502-17-303	1		-6311
17 304		SPACER	R501-17-304	1		
17 304A		GEAR, FRICTION	R505-17-304	1		6311-7421
17 304B		SPACER	M501-17-304B	1		-6311
			R501-17-316A	1		6311-
17 305A		RING, RETAINING-BALL BEARING	0839-17-305B	1		
17 306A		RING, SNAP	0727-17-306	1		
17 308		GEAR, COUNTER	R503-17-308A	1		-6801
			R505-17-308	1		6801-
17 309B		NUT, LOCK-COUNTER SHAFT BRACKET	M501-17-309	1		
17 310		GEAR, REVERSE IDLE	3648-17-310	1		-6801
			R502-17-310	1		6801-
17 313		WASHER, THRUST-REVERSE IDLE GEAR	0821-17-313	2		
17 315		SHAFT, REVERSE IDLE GEAR	0884-17-315	1		
17 322		SLEEVE, CLUTCH HUB	R501-17-622	1	REVERSE	6801-
17 323		BOLT SET	4069-17-323	1		
17 327		SHIM, ADJUST-COUNTER SHAFT GEAR	0305-17-327	1	T=0.1MM	-6501
				2	T=0.1MM	6501-
			0305-17-328	1	T=0.3MM	
17 341A		GEAR, SPEEDOMETER DRIVE	R501-17-341	1		
17 341K		KEY	M501-17-342	1		
17 611		GEAR, OVERTOP	R503-17-611	1		-6801
			R505-17-610B	1		6801-
17 612		BEARING, NEEDLE	R501-17-612	1		
17 613		RING, RETAINING	R501-17-613	1		
17 621		HUB, CLUTCH	R501-17-621	1	REVERSE	-6801
			R502-17-621A	1	REVERSE	6801-
17 624		SPRING, SYNCHRONIZER	F401-17-264A	2	REVERSE	-6801
17 626A		RING, RETAINING-CLUTCH HUB	3648-17-626	1	REVERSE	-6801
17 629		NUT, LOCK-CLUTCH HUB	3648-17-629	1		
17 631		WASHER, THRUST LOCK-OVERTOP GEAR	R501-17-636	1	T=6.2MM	
			R501-17-635	1	T=6.3MM	
			R501-17-631A	1	T=6.4MM	
			R501-17-632A	1	T=6.5MM	


6311 FC33\* -136264  
 6501 FC33\* -146093  
 6801 FC33\* -522333  
 7421 FC33\* -547007



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
17 631	(CONT'D)		R501-17-633A	1	T=6.6MM	
			R501-17-634A	1	T=6.7MM	
17 641D		RING, SNAP	O821-17-641B	1		
17 651		WASHER, THRUST	M502-17-655	2	T=2.9MM	
			M502-17-651	4	T=3MM	
			M502-17-653	2	T=3.1MM	
			M502-17-654	2	T=3.2MM	
17 652		RING, THRUST WASHER	M502-17-652	2		
17 724A		SPRING, SYNCHRONIZER KEY	W501-17-724	2	REVERSE	6801-
17 725A		RING, SYNCHRONIZER	W501-17-725A	1		6801-
17 725C		RING, SYNCHRONIZER	V501-17-725	1		-6801

6801 FC33\* -522333


CHANGE CONTROL SYSTEM (MANUAL)  
(W/O TURBO)



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
17 351A		PIN, INTER LOCK	0114-17-351	2		
17 402		FORK, SHIFT (1ST & 2ND)	M502-17-402A	1		
17 404		FORK, SHIFT (3RD & 4TH)	M501-17-404B	1		.6C01
17 406		FORK, SHIFT	M504-17-406A	1		
17 410		ROD, SHIFT (1ST & 2ND)	M502-17-411A	1		
17 410A		END, S/ROD (1ST & 2ND)	M501-17-412	1		
17 411		SPRING, SHIFT ROD	0103-17-411	2		
17 411A		SPRING, SHIFT ROD-REVERSE	0014-17-411	2		
17 420		ROD, SHIFT (3RD & 4TH)	M503-17-421	1		
17 422A		END, S/ROD (3RD & 4TH)	M501-17-422	1		
17 431		ROD, SHIFT-OVERTOP & REVERSE	M505-17-431A	1		
17 432		END, SHIFT	M501-17-432	1		
17 450		LEVER, SHIFT	M512-17-450	1		
17 461A		END, CONTROL LEVER	M505-17-461A	1		
17 465C		SPRING, SELECT	M501-17-465B	1		
17 470		CASE, CHANGE CONTROL	M508-17-470D	1		
17 474A		CAP, SPRING	M501-17-474	1		
17 475		BOOT, DUST-CHANGE LEVER	M509-17-480A	1		
17 475A		GASKET, SPRING CAP	M501-17-475	1		
17 476		SPINDLE, SELECT LOCK	M502-17-476A	1		
17 477		SPRING	M501-17-477	1		
17 481A		BUSHING, CHANGE	M508-17-481A	1		
17 482		WASHER, WAVE-CHANGE CONTROL CASE	M505-17-482	1		
			B599-17-482	1		
17 483		SPRING	0824-17-483	1		
17 486A		COVER, BLIND	M501-17-486A	1		
17 490A		COVER, ROD	M502-17-490A	1		
17 491B		CAP, SPRING	0183-17-491	1		
17 510		LEVER, CHANGE	M515-17-510A	1		
17 520		KNOB, CHANGE LEVER	M507-17-520	1		
		BLACK	00			
17 524		NUT, LOCK	M503-17-524A	1		

6C01 FC33\* -525576

**1720A-1 CHANGE CONTROL SYSTEM (MANUAL) (TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
17 351A		PIN, INTER LOCK	0114-17-351	2		
17 402		FORK, SHIFT (1ST & 2ND)	R501-17-402A	1		
17 404		FORK, SHIFT (3RD & 4TH)	R501-17-404A	1		-7601
			< A > R501-17-404B	1		7601-
17 406		FORK, SHIFT	R503-17-406A	1		-6801
			R504-17-406A	1		6801-
17 410		ROD, SHIFT (1ST & 2ND)	R502-17-411B	1		
17 410A		END, S/ROD (1ST & 2ND)	R502-17-412	1		
17 411		SPRING, SHIFT ROD	0103-17-411	3		
17 420		ROD, SHIFT (3RD & 4TH)	R502-17-421B	1		
17 422A		END, S/ROD (3RD & 4TH)	R502-17-422	1		
17 431		ROD, SHIFT-OVERTOP & REVERSE	R503-17-431A	1		-7101
			R506-17-431	1		7101-
17 432		END, SHIFT	R502-17-432	1		
17 441B		PLUG, CAP	0221-17-441	2		
17 461		LEVER, CONTROL	R503-17-450	1		
17 461A		END, CONTROL LEVER	M505-17-461A	1		
17 465C		SPRING, SELECT	M501-17-465A	1		
17 470		CASE, CHANGE CONTROL	M508-17-470A	1		
17 474A		CAP, SPRING	M501-17-474	1		
17 475		BOOT, DUST-CHANGE LEVER	M509-17-480A	1		
17 475A		GASKET, SPRING CAP	M501-17-475	1		
17 476		SPINDLE, SELECT LOCK	M502-17-476A	1		
17 477		SPRING	M501-17-477	1		
17 481A		BUSHING, CHANGE	M508-17-481A	1		
17 482		WASHER, WAVE-CHANGE CONTROL CASE	M505-17-482	1		
			8599-17-482	1		
17 483		SPRING	0824-17-483	1		
17 486A		COVER, BLIND	M501-17-486A	1		
17 490A		COVER, ROD	M501-17-490B	1		
17 491B		CAP, SPRING	0183-17-491	1		
17 510		LEVER, CHANGE	M515-17-510A	1		
17 520		KNOB, CHANGE LEVER	M507-17-520	1		
		BLACK	00			
17 524		NUT, LOCK	M503-17-524A	1		



6801 FC33\* -522333  
 7101 FC33\* -528625  
 7601 FC33\* -550168

**1800B-1 ENGINE ELECTRICAL SYSTEM  
(W/O TURBO)**


(THIS ILLUSTRATION CONSISTS OF 2 PAGES)

(TRAILING SIDE)

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



(LEADING SIDE)





ITEM NO	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
	13 3633	RUBBER, MOUNTING-IGNITION COIL	N327-13-363	1		6501-
	18 100B	COIL & IGNITER, LEADING	N327-18-100	1		
	18 100C	COIL & IGNITER, TRAILING	N326-18-100A	1		-6501
		< C >	N326-18-100B	1	REQUIRES: N326-18-115A (BRACKET) & N327-13-363 (RUBBER)	6501-
	18 100D	COIL, IGNITION LEADING	N339-18-100	1		
	18 100E	COIL, IGNITION-TRAILING	N338-18-100	2		
	18 110	PLUG, SPARK	N343-18-110	2	LEADING	
		REFER TO SPECIAL SERVICE PROGRAM NO. SSPO3 FOR MORE INFO.				
			N342-18-110	2	TRAILING	
	18 110S	PLUG SET, SPARK	N3X4-18-110	1	BLISTER PACK	
		REFER TO SPECIAL SERVICE PROGRAM NO. SSPO3 FOR MORE INFO				
	18 120	BRACKET, IGNITION COIL	N326-18-105	1		
	18 1301	WIRE, HIGH TENSION (T-1)	N326-18-160B	1		
	18 140	WIRE SET, HIGH TENSION	0000-18-100A	1		
	18 1401	WIRE, HIGH TENSION (T-2)	N326-18-190B	1		
	18 141E	SUPPORTER, WIRE	N326-18-141	1		
	18 144	BRACKET, SUPPORT-HIGH TENSION WIRE	N326-18-144	1		
	18 151	BRACKET, HIGH TENSION WIRE SUPPORTER	N326-18-151	1		
	18 1701	WIRE, HIGH TENSION (L-1)	N326-18-170B	1		
	18 1801	WIRE, HIGH TENSION (L-2)	N326-18-180B	1		
	18 1901	BRACKET, IGNITION COIL	N326-18-115	1		-6501
			N326-18-115A	1		6501-
	18 201	O-RING	9954 10-3501	1		
	18 251	IGNITER, IGNITION COIL-LEADING	N327-18-251	1		
	18 251A	IGNITER, IGNITION COIL-TRAILING	N326-18-251	1		-6501
		< C >	N326-18-251A	1		6501
	18 361	STRAP, ALTERNATOR	N326-18-361A	1		
	18 371	BRACKET, ALTERNATOR	N245-18-311B	1		
	18 380	BOLT, ALTERNATOR	N326-18-397	1		
	18 381	V-BELT	8871 18-381	1	L=800MM	
	18 401	BOLT, STARTER	N327-18-401	1		
	18 401C	BRACKET, STARTER	N327-18-410	1	A T	5901
	18 402A	BRACKET, STARTER	N327-18-411	1	A T	5901
	5901	FC 33*	102044			
	6501	FC 33*	146093			

SEE ILLUSTRATION/S AT FRAME 1 - L 7

1800B.3

**ENGINE ELECTRICAL SYSTEM  
(W/O TURBO)**

ITEM NO	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
	18 742	BRACKET	N327-18-141	1		
	18 T11	COVER, IGNITION COIL-LEADING	N327-18-T11	1		
	18 T11B	COVER, IGNITION COIL-T-1	N326-18-T11	1		
	18 T12B	COVER, IGNITION COIL-T-2	N326-18 T12	1		
	18 T15A	BRACKET, IGNITION COIL-TRAILING	N326-18-T15	1		




SEE ILLUSTRATION/S AT FRAME 1 - L 7

# SECTION INDEX -- ENGINE

STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME
1 - C 3	1000B	SHORT ENGINE BLOCK & GASKET SETS (W O TURBO)	1 - E 6	1400BA	OIL PUMP & FILTER (TURBO)			
1 - D 3	1000BA	SHORT ENGINE & GASKET SETS (TURBO)	1 - G 6	1500B	COOLING SYSTEM (W O TURBO)			
1 - E 3	1030B	ROTOR HOUSINGS (W O TURBO)	1 - I 6	1500BA	COOLING SYSTEM (TURBO)			
1 - F 3	1030BA	ROTOR HOUSINGS (TURBO)	1 - K 6	1580B	BRACKET, PULLEY & BELT			
1 - G 3	1040B	OIL PAN, FRONT & REAR HOUSING (W O TURBO)	1 - L 6	1600	CLUTCH DISC & COVER (MANUAL) (W O TURBO)			
1 - H 3	1040BA	OIL PAN, FRONT & REAR HOUSING (TURBO)	1 - M 6	1600A	CLUTCH DISC & COVER (MANUAL) (TURBO)			
1 - I 3	1100B	ECCENTRIC SHAFT & FLYWHEEL (W O TURBO)	1 - N 6	1700	TRANSMISSION CASE (MANUAL) (W O TURBO)			
1 - J 3	1100BA	ECCENTRIC SHAFT & FLYWHEEL (TURBO)	1 - C 7	1700A	TRANSMISSION CASE (MANUAL) (TURBO)			
1 - K 3	1110B	ROTORS & RELATED PARTS (W O TURBO)	1 - D 7	1710	TRANSMISSION GEARS (MANUAL) (W O TURBO)			
1 - L 3	1110BA	ROTORS & RELATED PARTS (TURBO)	1 - G 7	1710A	TRANSMISSION GEARS (MANUAL) (TURBO)			
1 - M 3	1300B	INTAKE MANIFOLD (W O TURBO)	1 - J 7	1720	CHANGE CONTROL SYSTEM (MANUAL) (W O TURBO)			
1 - N 3	1300BA	INTAKE MANIFOLD (TURBO)	1 - K 7	1720A	CHANGE CONTROL SYSTEM (MANUAL) (TURBO)			
1 - C 4	1310B	EXHAUST MANIFOLD (W O TURBO)	1 - L 7	1800B	ENGINE ELECTRICAL SYSTEM (W O TURBO)			
1 - D 4	1310BA	EXHAUST MANIFOLD (TURBO)	1 - C 8	1800BA	ENGINE ELECTRICAL SYSTEM (TURBO)			
1 - G 4	1320B	FUEL SYSTEM (W O TURBO)	1 - F 8	1830B	ALTERNATOR (W O TURBO)			
1 - I 4	1320BA	FUEL SYSTEM (TURBO)	1 - G 8	1830BA	ALTERNATOR (TURBO)			
1 - K 4	1330B	AIR CLEANER (W O TURBO)	1 - H 8	1840B	STARTER (W O TURBO)			
1 - L 4	1330BA	AIR CLEANER (TURBO)	1 - I 8	1840BA	STARTER (TURBO)			
1 - M 4	1350B	STARTING ASSIST SYSTEM (W O TURBO)	1 - J 8	1850B	BATTERY			
1 - N 4	1350BA	STARTING ASSIST SYSTEM (TURBO)	1 - K 8	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)			
1 - C 5	1364B	THROTTLE BODY COMPONENTS (W O TURBO)	1 - L 8	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)			
1 - D 5	1364BA	THROTTLE BODY COMPONENTS (TURBO)	1 - C 9	1925	CONTROL VALVE (AUTOMATIC)			
1 - E 5	1371B	AIR PUMP & AIR CONTROL VALVE (W O TURBO)	1 - E 9	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)			
1 - F 5	1371BA	AIR PUMP & AIR CONTROL VALVE (TURBO)	1 - H 9	1940	GOVERNOR LOW & REVERSE PISTON (AUTOMATIC)			
1 - G 5	1380B	EMISSION CONTROL SYSTEM (EXHAUST SIDE) (W O TURBO)	1 - I 9	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)			
1 - K 5	1380BA	EMISSION CONTROL SYSTEM (EXHAUST SIDE) (TURBO)	1 - J 9	1960	GASKET & SEAL KIT (AUTOMATIC)			
1 - C 6	1400B	OIL PUMP & FILTER (W O TURBO)						


**1800BA-1 ENGINE ELECTRICAL SYSTEM (TURBO)**

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)




(THIS ILLUSTRATION CONSISTS OF 2 PAGES)

(TRAILING SIDE)



(LEADING SIDE)



**1800BA-2 ENGINE ELECTRICAL SYSTEM (TURBO)**

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	13 3633	RUBBER, MOUNTING-IGNITION COIL	N327-13-363	1		
	18 100B	COIL & IGNITER, LEADING	N327-18-100	1		
	18 100C	COIL & IGNITER, TRAILING	N326-18-100A	1		.6501
		< C >	N326-18-100B	1	REQUIRES BRACKET - N326-18-115A & RUBBER - N327-13-363	6501-
	18 100D	COIL, IGNITION-LEADING	N339-18-100	1		
	18 100E	COIL, IGNITION-TRAILING	N338-18-100	2		
	18 110	PLUG, SPARK	N343-18-110	2	LEADING	
		REFER TO SPECIAL SERVICE PROGRAM NO. SSPO3 FOR MORE INFO.				
			N342-18-110	2	TRAILING	
	18 110S	PLUG SET, SPARK	N3X4-18-110	1	BLISTER PACK	6C18-
		REFER TO SPECIAL SERVICE PROGRAM NO. SSPO3 FOR MORE INFO.				
	18 120	BRACKET, IGNITION COIL	N326-18-105	1		
	18 1301	WIRE, HIGH TENSION (T-1)	N318-18-160B	1		
	18 140	WIRE SET, HIGH TENSION	0000-18-100A	1	RC-ZE02, NGK	
	18 1401	WIRE, HIGH TENSION (T-2)	N318-18-190B	1		
	18 141	SUPPORTER	N318-18-141	3		
	18 141E	SUPPORTER, WIRE	N326-18-141	2		
	18 144	BRACKET, SUPPORT-HIGH TENSION WIRE	N318-18-144	1		
			N326-18-144	1		
	18 1701	WIRE, HIGH TENSION (L-1)	N318-18-170B	1		
	18 1801	WIRE, HIGH TENSION (L-2)	N318-18-180B	1		
	18 1901	BRACKET, IGNITION COIL	N326-18-115	1		.6501
			N326-18-115A	1		6501-
	18 201	O-RING	9954-10-3501	1		
	18 251	IGNITER, IGNITION COIL-LEADING	N327-18-251	1		
	18 251A	IGNITER, IGNITION COIL-TRAILING	N326-18-251	1		.6501
		< C >	N326-18-251A	1	REQUIRES: N326-18-115A (BRACKET) (BRACKET)	6501-
	18 361	STRAP, ALTERNATOR	N326-18-361	1		
	18 371	BRACKET, ALTERNATOR	N245-18-311B	1		
	18 380	BOLT, ALTERNATOR	N326-18-397	1		
	18 381	V-BELT	8311-18-381A	1	L=800MM	
	18 401	BOLT, STARTER	N327-18-401	1		

**SEE ILLUSTRATION/S AT FRAME 1 - C 8**


6501 FC33\* -146093  
6C18 FC33\* -527592

**1800BA-3 ENGINE ELECTRICAL SYSTEM  
(TURBO)**

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	18 T11	COVER, IGNITION COIL-LEADING	N327-18-T11	1		
	18 T11B	COVER, IGNITION COIL-T-1	N326-18-T11	1		
	18 T12B	COVER, IGNITION COIL-T-2	N326-18-T12	1		
	18 T15A	BRACKET, IGNITION COIL-TRAILING	N326-18-T15	1		


**SEE ILLUSTRATION/S AT FRAME 1 - C 8**

**1830B-1 ALTERNATOR  
(W/O TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
18 300		ALTERNATOR REFER TO PARTS BULL. NO. R-1 FOR CORE RETURN PROCEDURES.	N320-18-300R	1	REMANUFACTURED	
18 W50		COVER, REAR-ALTERNATOR	N326-18-W50	1		
18 W51		COVER, REAR-ALTERNATOR	F811-18-W51A	1		
24 501		STATOR	ESD3-18-W45	1		
24 503		BEARING, BALL-ALTERNATOR REAR	B612-18-W36	1		
24 510		RECTIFIER	ESD3-18-W60A	1		
24 514		BEARING, BALL-ALTERNATOR FRONT	FE38-18-W27	1		
24 520		REGULATOR	E356-18-W70	1		
24 521		SPRING, BRUSH	8173-24-521	2		
24 522		BRUSH	FE65-24-522	2		
24 526		SCREW SET	FE65-24-526	1		
24 530		PULLEY	N304-24-530A	1		
24 533		NUT SET	8028-24-533	1		
24 535		SCREW SET	FE65-24-535	1		
24 540		ROTOR	FE81-18-W35A	1		
24 550		BRACKET, FRONT	F811-24-550B	1		
24 590		TERMINAL SET	N326-18-W80	1		



**1830BA-1 ALTERNATOR  
(TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
18 300		ALTERNATOR REFER TO PARTS BULL. NO. R-1 FOR CORE RETURN PROCEDURES.	N318-18-300R	1	REMANUFACTURED	
18 W50		COVER, REAR-ALTERNATOR	N318-18-W50	1		
18 W51		COVER, REAR-ALTERNATOR	F811-18-W51A	1		
24 501		STATOR	ESD3-18-W45	1		
24 503		BEARING, BALL-ALTERNATOR REAR	B612-18-W36	1		
24 510		RECTIFIER	ESD3-18-W60A	1		
24 514		BEARING, BALL-ALTERNATOR FRONT	FE38-18-W27	1		
24 520		REGULATOR	E356-18-W70	1		
24 521		SPRING, BRUSH	8173-24-521	2		
24 522		BRUSH	FE65-24-522	2		
24 526		SCREW SET	FE65-24-526	1		
24 530		PULLEY	N304-24-530A	1		
24 533		NUT SET	8028-24-533	1		
24 535		SCREW SET	FE65-24-535	1		
24 540		ROTOR	FEB1-18-W35A	1		
24 550		BRACKET, FRONT	F811-24-550B	1		
24 590		TERMINAL SET	N326-18-W80	1		




**1840B-1 STARTER (W/O TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
18 400		STARTER	N326-18-400R	1	M/T REMANUFACTURED	
		REFER TO PARTS BULL. NO. R-1 FOR CORE RETURN PROCEDURES.				
			N327-18-400R	1	A/T REMANUFACTURED	
18 X20		SHAFT, PINION	N318-18-X20	1	A/T	
			N326-18-X20	1	M/T	
18 X56		GEAR, INTERNAL-STARTER	N326-18-X56	1		
24 701		YOKE	N326-18-X65	1	M/T	
			N327-18-X65	1	A/T	
24 710		BRACKET, FRONT	N326-18-X00	1	M/T	
			N327-18-X00	1	A/T	
24 712		STOPPER SET	N326-18-X30	1		
24 720		ARMATURE	N326-18-X60	1	M/T	
			N327-18-X60	1	A/T	
24 7222		SLEEVE, BEARING-REAR	N326-18-X62	1		
24 725		SCREW SET	E366-18-X95	1		
24 726		WASHER SET	N326-18-X92	1		
24 729		BOLT	N326-18-X91	2	M/T	
			JE01-18-X91	2	A/T	
24 730		LEVER	N326-18-X05	1		
24 740		BRACKET, REAR	N326-18-X80	1		
24 740A		SHAFT	N326-18-X40	1		
24 7432		SLEEVE, BEARING-FRONT	E356-18-X01	1		
24 744A		BALL, STEEL	N326-18-X93	1		
24 746		GEAR	N326-18-X57	3		
24 746A		PINION	N318-18-X25	1	A/T	
			N326-18-X25	1	M/T	
24 750		HOLDER, BRUSH	N326-18-X70	1	M/T	
			N327-18-X70	1	A/T	
24 752		SPRING, BRUSH	N318-18-X71	2	M/T	
			1-376-18-X71	2	M/T	
			N327-18-X71	4	A/T	
24 753		BRUSH, YOKE	N326-18-X66	1	M/T	
			N327-18-X66	1	A/T	
24 760		SWITCH	N326-18-X10	1		
24 760A		GASKET	N326-18-X87	1		

**1840BA-1 STARTER (TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
18 400		STARTER REFER TO PARTS BULL. NO. R-1 FOR CORE RETURN PROCEDURES.	N318-18-400R	1	REMANUFACTURED	
18 X20		SHAFT, PINION	N318-18-X20	1		
18 X56		GEAR, INTERNAL-STARTER	N326-18-X56	1		
24 701		YOKE	N326-18-X65	1		
24 710		BRACKET, FRONT	N318-18-X00	1		
24 712		STOPPER SET	N326-18-X30	1		
24 720		ARMATURE	N326-18-X60	1		
24 7222		SLEEVE, BEARING-REAR	N326-18-X62	1		
24 725		SCREW SET	E356-18-X95	1		
24 726		WASHER SET	N326-18-X92	1		
24 729		BOLT	N326-18-X91	2		
24 730		LEVER	N326-18-X05	1		
24 740		BRACKET, REAR	N326-18-X80	1		
24 740A		SHAFT	N326-18-X40	1		
24 7432		SLEEVE, BEARING-FRONT	E356-18-X01	1		
24 744A		BALL, STEEL	N326-18-X93	1		
24 746		GEAR	N326-18-X57	3		
24 746A		PINION	N318-18-X25	1		
24 750		HOLDER, BRUSH	N326-18-X70	1		
24 752		SPRING, BRUSH	N318-18-X71	2		
			N326-18-X71	2		
24 753		BRUSH, YOKE	N326-18-X66	1		
24 760		SWITCH	N326-18-X10	1		
24 760A		GASKET	N326-18-X87	1		

**1850B-1 BATTERY**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
18 520		BATTERY REFER TO ACC. BULL. NO. XG-4 FOR MORE INFO.	0000-80-126F	1		
18 522		BAND, BATTERY	FE50-18-522	1		
18 592		SEAL, RUBBER-BATTERY BOX	N318-18-592A	1		
18 593		COVER, BOX-BATTERY	N318-18-593C	1		
18 59X		BOX, BATTERY	N318-18-59XD	1		
56 030		CLAMP, BATTERY	FB01-56-030	1		
56 863A		TRAY, BATTERY	FB01-56-981D	1		
67 801A		BOLT, CLAMP	0243-56-231	2		

**1910-1 TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
13 331		SPACER, AIR CLEANER	2850-13-331	2		
19 020		PLATE, DRIVE	BU17-19-020B	1		
19 025		PLATE, BACKING	0842-19-025	1		
19 027A		COVER, UNDER	BU17-19-027	1		
19 029		COVER, TOP	BU17-19-050	1		
19 064		BOLT	3649-19-064A	4		
19 090A		T/MISSION, COMPLETE	BU17-19-090F	1		
19 100A		CONVERTER, TORQUE	BU17-19-100	1		
19 211		HOUSING, CONVERTER	BU17-19-211A	1		
19 215		GASKET, OIL PUMP	BU01-19-215	1		
19 216		BOLT	BU01-19-216	6		
19 220		PUMP, OIL	BU18-19-220	1		
19 223A		SEAL, OIL	0338-19-223A	1		
19 240		COVER	BU18-19-240	1		
19 245		BALL	0338-19-245A	2		
19 248		SPRING	0338-19-248	1		
19 255		BOLT	0338-19-255	5		
19 258		SEAL, CUT RING	0338-19-258	1		
19 678		SHAFT, INPUT	BU01-21-678	1		
19 904		HOSE, VACUUM	0338-19-904A	1		
19 910		PIPE, VACUUM	BU17-19-910	1		
19 917		CLIP	BU17-19-917	1		
19 920		PIPE, OIL	BU17-19-920B	1		
19 930		PIPE, OIL	BU17-19-930B	1		
19 933		HOSE, OIL	BV09-19-933A	1		
19 934		HOSE, OIL	BV09-19-930A	1		
19 940		BRACKET, PIPE	BU17-19-940	1		
19 941		CLIP	BU01-19-941	1		
19 960		BRACKET	BU17-19-961A	1		
21 660		TUBE, GOVERNOR	BU01-21-660A	1		
21 665		WASHER, SEAL	BU01-21-665	4		
21 666		BOLT, CONNECTOR	BU17-21-666	2		
21 677		O-RING	BU01-21-677	1		
45 903D		CLIP, PIPE	8173-45-903	4		


**1920-1 TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
17 335		SEAL, OIL	M502-17-335A	1		
17 441		GEAR, DRIVEN	0862-17-441A	1	N=19	
17 442		SLEEVE, SPEEDOMETER	1669-17-442B	1		
17 442J		O-RING	1011-17-443	1		
17 442K		SEAL, OIL	9V58-60-8166	1		
19 040		INSULATOR, OIL PAN	BU17-19-040A	1		
19 247		SPRING	0338-19-247	1		
19 256		RING, SEAL	BU01-19-256	4		
19 257		RING, SEAL	BU01-19-257	2		
19 258		SEAL, CUT RING	0338-19-258	1		
19 310		CASE, T MISSION	BU05-19-310A	1		
19 331		PLUG, SQUARE HEAD	0338-19-331A	3		
19 332		CONNECTOR, STRAIGHT	BU01-19-332A	1		
19 336		RACE, INNER	0338-19-336	1		
19 337		WASHER, PLAIN	0338-19-337	8		
19 338		BOLT	0338-19-338	8		
19 341		BOLT, ANCHOR END	0338-19-341	2		
19 344		BREATHER, AIR	0397-19-340	1		
19 361		STRUT, BAND	0338-19-361B	2		
19 363A		SPRING, PISTON RETURN	BU10-19-363	1		.6620
			BU06-19-363	1		6620.
19 368		SPRING, CUSHION-PISTON STEM	BU17-19-368	1		
19 381		PISTON, BAND SERVO	BU17-19-381	1		
19 384A		SEAL, PISTON	BU05-19-384	1		
19 385		SEAL, PISTON	BU17-19-385	1		
19 386		STEM, PISTON	BU17-19-386	1		
19 389		NUT	0238-19-389	2		
19 391		RETAINER, SERVO	BU17-19-391	1		
19 392		COVER, SERVO	1758-19-392A	1		
19 395		O-RING	0338-19-395	1		
19 396		GASKET	1758-19-394A	2		
19 397		BOLT	1758-19-397	3		
19 398		BOLT	0338-19-398	3		
19 399		RING, SNAP	BU17-19-399	1		
19 3A0		SPACER, PISTON STEM	BU17-19-3A0	1	T=8MM	
			BU17-19-3A1	1	T=8.5MM	
			BU17-19-3A2	1	T=9MM	
			BU17-19-3A3	1	T=9.5MM	
			BU17-19-3A4	1	T=10MM	
			BU17-19-3A5	1	T=10.5MM	
			BU17-19-3A6	1	T=11MM	

6620 FC33\* -156850



# 1920-2 TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)



ITEM NO	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
19 403		RING, SNAP-PISTON STEM-LOWER	BU17-19-403	1		
19 404		RING, SNAP-PISTON STEM-UPPER	BU17-19-404	1		
19 406		RETAINER, SPRING-PISTON STEM	BU17-19-406	1		
19 710		HOUSING, EXTENSION	BU17-19-710	1		
19 735		GASKET, EXTENSION	0338-19-735	1		
19 737		BOLT	0338-19-737	8		
19 739		WASHER, PLAIN	0338-19-739	8		
19 750		VALVE, CONTROL	BU17-19-750C	1		
19 768		VALVE, MANUAL	0338-19-768	1		
19 815		STRAINER, OIL	BU01-19-815	1		
19 822		SEAL, O-RING	0338-19-822	2		
19 823		DIAPHRAGM, VACUUM	BU17-19-823	1		
19 825		ROD, DIAPHRAGM	0338-19-828	1	L=29MM	
			0338-19-829	1	L=29.5MM	
			0338-19-825	1	L=30MM	
			0338-19-827	1	L=30.5MM	
			0338-19-826	1	L=31MM	
19 831		BOLT, CONTROL VALVE	0338-19-831	3		
19 832		BOLT, CONTROL VALVE	0338-19-832	2		
19 833		BOLT, CONTROL VALVE	0338-19-833	2		
19 835		GASKET, OIL PAN	0338-19-835B	1		
19 836		PAN, OIL	BU17-19-830	1		
19 837		BOLT, OIL PAN	0338-19-837	18		
19 870		TUBE, OIL LEVEL	BU17-19-870A	1		
19 880		GAUGE, OIL LEVEL	BU17-19-880B	1		
19 890		TUBE, OIL FILTER-UPPER	BU17-19-890B	1		
21 212		O-RING	BU01-21-212	1		
21 250		SUPPORT, DRUM	BU10-21-250	1		
21 253		GASKET, DRUM SUPPORT	BU01-21-253	1		
21 255		BOLT	BU01-21-255	2		
21 271		PISTON ACCUMULATOR	BU10-21-271	1		
21 272		SPRING, ACCUMULATOR	BU01-21-272A	1		
21 273		PLUG, ACCUMULATOR	BU01-21-273	1		
21 274		SEAL, O-RING	BU01-21-274	1		
21 275		SEAL, O-RING	BU10-21-275	1		
21 277		O-RING	BU01-21-277	1		
21 320		CASE, OVERDRIVE	BU17-21-320A	1		
21 322		GASKET, O DRIVE CASE	BU01-21-322	1		
21 386		STEM, PISTON BAND	BU01-21-386	1		
21 391		RETAINER, SERVO	BU20-21-391	1		
21 395		O-RING	BU01-21-395	2		

# SECTION INDEX -- ENGINE



STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME
1 - C 3	1000B	SHORT ENGINE BLOCK & GASKET SETS (W O TURBO)	1 - E 6	1400BA	OIL PUMP & FILTER (TURBO)			
1 - D 3	1000BA	SHORT ENGINE & GASKET SETS (TURBO)	1 - G 6	1500B	COOLING SYSTEM (W/O TURBO)			
1 - E 3	1030B	ROTOR HOUSINGS (W O TURBO)	1 - I 6	1500BA	COOLING SYSTEM (TURBO)			
1 - F 3	1030BA	ROTOR HOUSINGS (TURBO)	1 - K 6	1580B	BRACKET, PULLEY & BELT			
1 - G 3	1040B	OIL PAN, FRONT & REAR HOUSING (W O TURBO)	1 - L 6	1600	CLUTCH DISC & COVER (MANUAL) (W/O TURBO)			
1 - H 3	1040BA	OIL PAN, FRONT & REAR HOUSING (TURBO)	1 - M 6	1600A	CLUTCH DISC & COVER (MANUAL) (TURBO)			
1 - I 3	1100B	ECCENTRIC SHAFT & FLYWHEEL (W O TURBO)	1 - N 6	1700	TRANSMISSION CASE (MANUAL) (W/O TURBO)			
1 - J 3	1100BA	ECCENTRIC SHAFT & FLYWHEEL (TURBO)	1 - C 7	1700A	TRANSMISSION CASE (MANUAL) (TURBO)			
1 - K 3	1110B	ROTORS & RELATED PARTS (W O TURBO)	1 - D 7	1710	TRANSMISSION GEARS (MANUAL) (W/O TURBO)			
1 - L 3	1110BA	ROTORS & RELATED PARTS (TURBO)	1 - G 7	1710A	TRANSMISSION GEARS (MANUAL) (TURBO)			
1 - M 3	1300B	INTAKE MANIFOLD (W O TURBO)	1 - J 7	1720	CHANGE CONTROL SYSTEM (MANUAL) (W/O TURBO)			
1 - N 3	1300BA	INTAKE MANIFOLD (TURBO)	1 - K 7	1720A	CHANGE CONTROL SYSTEM (MANUAL) (TURBO)			
1 - C 4	1310B	EXHAUST MANIFOLD (W O TURBO)	1 - L 7	1800B	ENGINE ELECTRICAL SYSTEM (W/O TURBO)			
1 - D 4	1310BA	EXHAUST MANIFOLD (TURBO)	1 - C 8	1800BA	ENGINE ELECTRICAL SYSTEM (TURBO)			
1 - G 4	1320B	FUEL SYSTEM (W O TURBO)	1 - F 8	1830B	ALTERNATOR (W/O TURBO)			
1 - I 4	1320BA	FUEL SYSTEM (TURBO)	1 - G 8	1830BA	ALTERNATOR (TURBO)			
1 - K 4	1330B	AIR CLEANER (W O TURBO)	1 - H 8	1840B	STARTER (W/O TURBO)			
1 - L 4	1330BA	AIR CLEANER (TURBO)	1 - I 8	1840BA	STARTER (TURBO)			
1 - M 4	1350B	STARTING ASSIST SYSTEM (W O TURBO)	1 - J 8	1850B	BATTERY			
1 - N 4	1350BA	STARTING ASSIST SYSTEM (TURBO)	1 - K 8	1910	TORQUE CONVERTER, OIL PUMP & PIPINGS (AUTOMATIC)			
1 - C 5	1364B	THROTTLE BODY COMPONENTS (W O TURBO)	1 - L 8	1920	TRANSMISSION CASE & MAIN CONTROL SYSTEM (AUTOMATIC)			
1 - D 5	1364BA	THROTTLE BODY COMPONENTS (TURBO)	1 - C 9	1925	CONTROL VALVE (AUTOMATIC)			
1 - E 5	1371B	AIR PUMP & AIR CONTROL VALVE (W O TURBO)	1 - E 9	1930	CLUTCHES & PLANETARY GEARS (AUTOMATIC)			
1 - F 5	1371BA	AIR PUMP & AIR CONTROL VALVE (TURBO)	1 - H 9	1940	GOVERNOR, LOW & REVERSE PISTON (AUTOMATIC)			
1 - G 5	1380B	EMISSION CONTROL SYSTEM (EXHAUST SIDE) (W O TURBO)	1 - I 9	1950	MANUAL LINKAGE SYSTEM (AUTOMATIC)			
1 - K 5	1380BA	EMISSION CONTROL SYSTEM (EXHAUST SIDE) (TURBO)	1 - J 9	1960	GASKET & SEAL KIT (AUTOMATIC)			
1 - C 6	1400B	OIL PUMP & FILTER (W O TURBO)						



b		19-807	D=1.0MM (BU17-19-807)
c		19-807	D=1.5MM (BU01-19-807)
d		19-807	D=2MM (0338-19-807A)
e		19-808	D=4.77MM, L=15.5MM
f		19-814	D=5.6MM, L=28.0MM
g		19-816	L=25MM
h		19-817	L=40MM
i		19-818	L=57MM
j		19-819	
k		99611-2000	

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
19 750		VALVE, CONTROL	BU17-19-750C	1		
19 760		BODY, CONTROL VALVE-UPPER	BU17-19-760A	1		
19 765		SPRING	0338-19-765	1		
19 768		VALVE, MANUAL	0338-19-768	1		
19 771		VALVE, REGULATOR	BU01-19-771	1		
19 772		SPRING, REGULATOR	0338-19-772	1		
19 773		SEAT, REGULATOR SPRING	0338-19-773	1		
19 774		PLUG, REGULATOR	0397-19-774	1		
19 775		SLEEVE, REGULATOR PLUG	0397-19-775	1		
19 777		VALVE, SECONDARY LOCK	0338-19-777	1		
19 778		SPRING, SECONDARY LOCK	0338-19-778	1		
19 781		PLATE, SIDE 'D'	1758-19-781	1		
19 782		SCREW	0338-19-782	9		
19 785		VALVE, 1-2 SHIFT	0338-19-785	1		
19 786		SPRING, 1-2 SHIFT	1758-19-786	1		
19 787		VALVE, 2-3 SHIFT	0338-19-787	1		
19 788		SPRING, 2-3 SHIFT	BU17-19-788	1		
19 789		PLUG, 2-3 SHIFT	BU17-19-789	1		
19 791		VALVE, MODIFIER	0338-19-791A	1		
19 793		PLATE, SIDE 'A'	0338-19-793A	1		
19 795		VALVE, THROTTLE	0338-19-795B	1		
19 797		VALVE, THROTTLE BACK-UP	0338-19-797	1		
19 798		SPRING, THROTTLE BACK-UP	BU02-19-798	1		
19 801		VALVE, DOWN SHIFT	0338-19-801	1		
19 802		SPRING, DOWN SHIFT	0338-19-802	1		
19 803		PLATE, SIDE 'B'	BU01-19-803A	1		
19 805		PLATE, SEPARATOR	BU17-19-805	1		
19 807		VALVE, ORIFICE CHECK	BU01-19-807	1		
			BU17-19-807	1		
			0338-19-807A	2		
19 808		SPRING	0338-19-808	4		
19 811		BODY, VALVE-LOWER	BU10-19-811	1		
19 814		SPRING	0338-19-814	1		
19 815		STRAINER, OIL	BU01-19-815	1		
19 816		SCREW	0338-19-816	7		
19 817		SCREW	0338-19-817	10		
19 818		BOLT	0338-19-818	2		
19 819		NUT	0338-19-819	2		
21 681		VALVE, 3-4 SHIFT	BU01-21-681	1		
			BU16-21-681	1		
21 682		SPRING, 3-4 SHIFT	BU05-21-682	1		






b		19-807	D=1.8MM (BU17-19-807)
c		19-807	D=1.5MM (BU01-19-807)
d		19-807	D=2MM (0338-19-807A)
e		19-808	D=4.77MM, L=15.5MM
f		19-814	D=5.6MM, L=26.8MM
g		19-816	L=25MM
h		19-817	L=40MM
i		19-818	L=57MM
j		19-813	
k		99611-2000	


ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
21 683		PLUG, 3-4 SHIFT	BU03-21-683A	1		
21 684		VALVE, 3-4 SHIFT-COAST	BU01-21-684	1		
			BU16-21-684	1		
21 813		VALVE, 3-2 TIMING	BU17-21-813	1		
21 815		SPRING, 3-2 TIMING	BU17-21-815	1		

1930-1 CLUTCHES & PLANETARY GEARS (AUTOMATIC)




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	12 9506	PLATE, RETAINING	BU05-21-528	1	T=7MM DIRECT	
	19 360	BAND, BRAKE	0338-19-360B	2		
	19 460	CLUTCH, FRONT	BU17-19-460	1		
	19 470	DRUM, CLUTCH	0338-19-470	1		
	19 475	SEAL, O-RING	0338-19-475	3	FRONT, REAR & DIRECT CLUTCH	
	19 476	SEAL, LATHE CUT	0338-19-476	3	FRONT, REAR & DIRECT CLUTCH	
	19 480	PISTON, CLUTCH	0338-19-480	3	FRONT, REAR & DIRECT CLUTCH	
	19 486	SPRING, PISTON RETURN	0338-19-486	25	FOR FRONT 5, REAR 10 & DIRECT 10	
	19 487	RETAINER, SPRING	0338-19-487	3	FOR FRONT, REAR & DIRECT CLUTCH	
	19 488	RING, SNAP	0338-19-488	3	FRONT, REAR & DIRECT CLUTCH	
	19 498	PLATE, DISHED	0338-19-498	3	FRONT 1, DIRECT 2	
	19 498A	PLATE, DISHED	BU17-19-498	1	REAR	
	19 499	PLATE, DRIVEN	FT01-19-499	12	FRONT 5, REAR 5, DIRECT 2	
	19 500B	PLATE, DRIVE	BU17-19-500	11	FRONT 4, REAR 5, DIRECT 2	
	19 503	PLATE, RETAINING	3959-19-503	1	T=5MM FRONT	
			3959-19-504	1	T=5.2MM FRONT	
			3959-19-505	1	T=5.4MM FRONT	
			3959-19-506	3	T=5.6MM FRONT, REAR & DIRECT	
			3959-19-507	2	T=5.8MM FRONT & DIRECT	
			3959-19-508	2	T=6MM FRONT & DIRECT	
			3959-19-509	2	T=6.2MM FRONT & DIRECT	
	19 504A	PLATE, RETAINING	BU05-21-525	1	T=6.4MM DIRECT	
			BU05-21-526	1	T=6.6MM DIRECT	
			BU05-21-527	1	T=6.8MM DIRECT	
			BU05-21-528	1	T=7MM DIRECT	
	19 509	RING, SNAP	0338-19-509	3	FRONT, REAR & DIRECT	
	19 510	CLUTCH, REAR	BU17-19-510	1		
	19 511	DRUM, REAR CLUTCH	1758-19-511	1		

1930-2 CLUTCHES & PLANETARY GEARS (AUTOMATIC)




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
19 530		HUB, REAR CLUTCH	0338-19-530	1		
19 531		HUB, REAR CLUTCH	0338-19-531	1		
19 533		GEAR, INTERNAL	0338-19-533	1	REAR CLUTCH HUB	
19 533B		GEAR, INTERNAL	BU03-19-533	1	OVERDRIVE CLUTCH HUB	
19 534		RING, SNAP	0338-19-534	1	REAR CLUTCH	
19 534B		RING, SNAP	BU03-19-534	1	OVERDRIVE CLUTCH HUB	
19 540		CARRIER, FRONT	BU02-19-540	1		
19 560		GEAR, SUN	BU02-19-560	1		
19 565		SHELL, CONNECTING	BU02-19-565	1		
19 566		RACE, SHELL BEARING	FT01-19-566	1		
19 567		RING, SNAP	BU02-19-567	1		
19 570		CARRIER, REAR	BU02-19-570	1		
19 598		RING, SNAP	0338-19-598	1		
19 621		BEARING, NEEDLE	0338-19-621	2		
19 622		BEARING, NEEDLE	0338-19-622	1		
19 623		BEARING, NEEDLE	0338-19-623	5		
19 624		BEARING, NEEDLE	0338-19-624	3		
19 631		RACE, BEARING PUMP COVER	0338-19-631	1	T= 2MM	
			0338-19-632	1	T= 1.4MM	
			0338-19-633	1	T= 1.6MM	
			0338-19-634	1	T= 1.8MM	
			0338-19-635	1	T= 2MM	
			0338-19-636	1	T= 2.2MM	
19 639A		RACE, BEARING	0338-19-639	4		
19 641A		WASHER	0338-19-648	2	T= 1.3MM	
			0338-19-646	2	T= 1.5MM	
			0338-19-647	2	T= 1.7MM	
			0338-19-641	2	T= 1.9MM	
			0338-19-642	2	T= 2.1MM	
			0338-19-643	2	T= 2.3MM	
			0338-19-644	2	T= 2.5MM	
			0338-19-645	2	T= 2.7MM	
19 656		RACE, BEARING OIL DISTRIBUTOR	0436-19-656	1		
21 510		CLUTCH, DIRECT	BU17-21-510	1		
21 520		DRUM, DIRECT	BU05-21-520	1		
21 531		HUB, O/DRIVE CLUTCH	BU03-21-531	1		
21 540		CARRIER, OVERDRIVE	BU03-21-540	1		
21 560		GEAR, OVERDRIVE	BU03-21-560	1		
21 565		CONNECTING, SHELL	BU03-21-565	1		

1930-3 CLUTCHES & PLANETARY GEARS (AUTOMATIC)




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
21 567		RING, SNAP	BU03-21-567	1		
21 631		RACE, BEARING HUB CLUTCH	BU01-21-631	1	L=1.2MM	
			BU01-21-632	1	L=1.4MM	
			BU01-21-633	1	L=1.6MM	
			BU01-21-634	1	L=1.8MM	
			BU01-21-635	1	L=2MM	
			BU01-21-636	1	L=2.2MM	
21 679		SHAFT, INTERMEDIATE	BU01-21-679	1		



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
17 341A		GEAR, SPEEDOMETER DRIVE	R501-17-341	1		
17 341K		KEY	M501-17-342	1		
19 397A		BOLT	0338-19-398	4		
19 533		GEAR, INTERNAL	0338-19-533A	1		
19 534		RING, SNAP	0338-19-534	1		
19 580		FLANGE	0338-19-580	1		
19 581		FLANGE, DRIVE	0338-19-581	1		
19 590		DRUM, CONNECTING	0338-19-590	1		
19 591		DRUM, CONNECTING	0338-19-591	1		
19 593		RACE, OUTER	0338-19-593	1		
19 594		RING, SNAP	0338-19-594	1		
19 595		CLUTCH, ONE-WAY	0338-19-595	1		
19 596		RING, SNAP	0338-19-596	2		
19 601		PISTON, LOW & REVERSE	BT08-19-600	1		
19 603		SEAL, PISTON	0338-19-603	1		
19 604		SEAL, O-RING	0338-19-604	1		
19 606		SPRING, PISTON	0338-19-606	1		
19 607		RING, SNAP	0338-19-607	1		
19 608		PLATE, DISHED	0338-19-608	1		
19 609		PLATE, DRIVEN	0338-19-609	5		
19 610		PLATE, DRIVE	BU17-19-610	5		
19 613		PLATE, RETAINING	1758-19-613	1	T=7.8MM	
			1758-19-614	1	T=8MM	
			1758-19-615	1	T=8.2MM	
			1758-19-616	1	T=8.4MM	
			1758-19-617	1	T=8.6MM	
			1758-19-618	1	T=8.8MM	
19 619		RING, SNAP	0338-19-619	1		
19 622		BEARING, NEEDLE	0338-19-622	1		
19 650		DISTRIBUTOR, OIL	BU02-19-650A	1		
19 655		RING, SEAL	0338-19-655	3		
19 656		RACE, BEARING OIL DISTRIBUTOR	0436-19-656	1		
19 660		GOVERNOR	BU02-19-660	1		
19 663		VALVE	0338-19-663	1		
19 664		SPRING	0338-19-664	1		
19 665		VALVE	BU02-19-665	1		
19 666		SPRING, GOVERNOR	0338-19-666	1		
19 667		PLATE, RETAINER	0338-19-667	3		
19 670		SHAFT	BU17-19-670	1		
19 676		RING	0338-19-676	1		

1950-1 MANUAL LINKAGE SYSTEM (AUTOMATIC)




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
19 031		LEVER, SELECT	BU17-19-031	1		
19 431		SHAFT, MANUAL	0338-19-431	1		
19 432		O-RING	0338-19-432	1		
19 433		WASHER	0338-19-433A	1		
19 440		PLATE, MANUAL	BU17-19-440	1		
19 443		NUT, SHAFT	0338-19-443	1		
19 448		LEVER, PARKING	0338-19-448	1		
19 449		RING, SNAP	0338-19-449	1		
19 450		ROD, PARKING	BU17-19-450	1		
19 701		SUPPORTER, ACTUATOR	BU17-19-701	1		
19 702		PLATE, RETAINING	0338-19-702A	1		
19 703		SPRING, BALL PARK	BU17-19-703	2		
19 704		RETAINER	BU17-19-704	1		
19 706		BOLT	0338-19-706	2		
19 731		SHAFT, PARKING PAWL	0338-19-731	1		
19 732		PAWL, PARKING	BU17-19-732	1		
19 733		SPRING, PAWL RETURN	0338-19-733C	1		
19 734		SPACER, DOWEL	0338-19-734A	1		
19 838B		BOLT	BU17-19-838	2		

1960-1 GASKET & SEAL KIT (AUTOMATIC)

22-900

- a-SEAL, "O" RING.....(3)
- b-SEAL.....(3)
- c-GASKET, DRUM SUPPORT.....(1)
- d-GASKET, DRIVE CASE.....(1)
- e-SEAL, "O" RING.....(1)
- f-SEAL, "O" RING.....(1)
- g-RING, "O".....(1)
- h-RING, "O".....(1)
- i-SEAL, OIL.....(1)
- j-RING, "O".....(1)
- k-SEAL.....(1)
- l-GASKET, OIL PUMP.....(1)
- m-RING, "O".....(1)
- n-RING, "O".....(1)
- p-RING, "O".....(1)
- q-SEAL, OIL.....(1)
- r-SEAL, "O" RING.....(1)
- s-SEAL, PISTON.....(1)
- t-SEAL, "O" RING.....(2)
- u-SEAL, PISTON.....(1)
- v-SEAL, PISTON.....(1)
- w-SEAL.....(1)
- x-GASKET.....(1)
- y-GASKET, OIL PAN.....(1)
- z-RING, "O".....(1)
- aa-RING, "O".....(1)
- ab-RING, "O".....(1)
- ac-RING, "O".....(2)
- ad-GASKET, EXTENTION.....(1)



ITEM NO	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	22 900	GASKET & SEAL KIT	BU01-99-190	1		-7501
		<A>	BU01-99-190A	1		7501-

7501 FC33\* -547831



**ENGINE**



**CHASSIS**





**ENGINE**



**CHASSIS**



**ENGINE**



**CHASSIS**



**ENGINE**



**CHASSIS**



**ENGINE**



**CHASSIS**



**ENGINE**

**CHASSIS**



**ENGINE**



**CHASSIS**



**ENGINE**



**CHASSIS**



**ENGINE**



**CHASSIS**





**ENGINE**



**CHASSIS**



**ENGINE**



**CHASSIS**



**ENGINE**

**CHASSIS**



**ENGINE**




**CHASSIS**

# SECTION INDEX -- CHASSIS


STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME
1 - C11	2500	DRIVESHAFT	1 - K14	3900BA	ENGINE & TRANSMISSION MOUNTINGS (TURBO)			
1 - D11	2550	REAR DRIVESHAFTS	1 - L14	4000B	EXHAUST SYSTEM (W/O TURBO)			
1 - E11	2600	REAR AXLE	1 - C15	4000BA	EXHAUST SYSTEM (TURBO)			
1 - F11	2610	REAR BRAKE MECHANISMS	1 - E15	4140B	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)			
1 - H11	2710	REAR DIFFERENTIALS (W O TURBO)(NORMAL DIFFERENTIAL)	1 - F15	4160	ACCELERATOR CONTROL SYSTEM			
1 - J11	2710A	REAR DIFFERENTIALS (W O TURBO)(LIMITED-SLIP DIFFERENTIAL)	1 - G15	4200	FUEL TANK			
1 - L11	2710C	REAR DIFFERENTIALS (TURBO)(LIMITED-SLIP DIFFERENTIAL)	1 - H15	4300	CLUTCH & BRAKE PEDALS			
1 - N11	2800	REAR SUSPENSION MECHANISMS (W O TURBO) (W O AUTOMATIC ADJUSTING SUSPENSION)	1 - J15	4340	BRAKE MASTER CYLINDER & POWER BRAKE (W/O ANTI-LOCK BRAKE SYSTEM)			
1 - C12	2800A	REAR SUSPENSION MECHANISMS (W O TURBO) (FOR AUTOMATIC ADJUSTING SUSPENSION)	1 - L15	4340A	BRAKE MASTER CYLINDER & POWER BRAKE (ANTI-LOCK BRAKE SYSTEM)			
1 - D12	2800B	REAR SUSPENSION MECHANISMS (TURBO)	1 - N15	4360	BRAKE PIPINGS (W/O ANTI-LOCK BRAKE SYSTEM)			
1 - E12	2810	REAR STABILIZER	1 - C16	4360A	BRAKE PIPINGS (ANTI-LOCK BRAKE SYSTEM)			
1 - F12	2830	REAR LOWER ARMS & SUB-FRAME	1 - D16	4370	ANTI-LOCK BRAKE SYSTEMS			
1 - H12	3200	STEERING WHEEL	1 - F16	4400	PARKING BRAKE SYSTEM			
1 - I12	3210	STEERING COLUMN & SHAFTS	1 - G16	4500B	FUEL PIPINGS (W O ANTI-LOCK BRAKE SYSTEM)			
1 - J12	3210A	STEERING COLUMN & SHAFTS (W POWER STEERING)	1 - H16	4500BA	FUEL PIPINGS (ANTI-LOCK BRAKE SYSTEM)			
1 - K12	3220	STEERING GEAR (W O POWER STEERING)	1 - I16	4600	CHANGE CONTROL SYSTEM (AUTOMATIC TRANSMISSION)			
1 - L12	3220A	STEERING GEAR (W POWER STEERING)						
1 - M12	3230	STEERING LINKAGE SYSTEM						
1 - C13	3240	POWER STEERING SYSTEM						
1 - E13	3300	FRONT AXLE & BRAKE MECHANISMS (FOR NORMAL SUSPENSION)						
1 - I13	3300A	FRONT AXLE & BRAKE MECHANISMS (FOR HARD SUSPENSION) (W O ANTI LOCK BRAKE SYSTEM)						
1 - K13	3300B	FRONT AXLE & BRAKE MECHANISMS (FOR HARD SUSPENSION) (ANTI-LOCK BRAKE SYSTEM)						
1 - M13	3400	FRONT SUSPENSION MECHANISMS (W O TURBO) (W O AUTOMATIC ADJUSTING SUSPENSION)						
1 - N13	3400A	FRONT SUSPENSION MECHANISMS (W O TURBO) (FOR AUTOMATIC ADJUSTING SUSPENSION)						
1 - C14	3400B	FRONT SUSPENSION MECHANISMS (TURBO)						
1 - D14	3410	CROSSMEMBER & STABILIZER						
1 - E14	3700	TIRES & JACK (W O TURBO)						
1 - H14	3700A	TIRES & JACK (TURBO)						
1 - J14	3900B	ENGINE & TRANSMISSION MOUNTINGS (W O TURBO)						

**2500-1 DRIVESHAFT**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
25 100A		DRIVESHAFT	M060-25-100C	1	M/T, W/O TURBO	
			M051-25-100C	1	A/T, W/O TURBO	
			P039-25-100A	1	TURBO	
25 123		BOLT	P012-25-123	4	W/O TURBO	
			1368-25-124	4	TURBO	
			1368-25-124	4	TURBO	
25 124		NUT	1368-25-124	4		
25 901		WASHER, BALANCE WEIGHT	M055-25-901	2	W=2.2G	
			M055-25-902	2	W=3.4G	
			M055-25-903	2	W=4.5G	
			M055-25-904	2	W=5.6G	

**2550-1 REAR DRIVESHAFTS**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
22 510B		JOINT SET, OUTER	M030-22-510A	2	W/O TURBO	
			M040-22-510B		TURBO	
22 520		JOINT SET, INNER	M030-22-520A	2	W/O TURBO	
			M040-22-520A		TURBO	
22 530		BOOT SET, OUTER JOINT	M030-22-530A	2	W/O TURBO	
			M040-22-530B		TURBO	
22 540		BOOT SET, INNER JOINT	M030-22-540A	2	W/O TURBO	
			M040-22-540A		TURBO	
22 550		CLIP SET	M030-22-550A	2	W/O TURBO	
			M040-22-550B		TURBO	
25 124		NUT	1368-25-124	8		
25 500		DRIVESHAFT	M030-25-500B	2	W/O TURBO	
			< A > M030-25-500C			
			M040-25-500D		TURBO	

2600-1 REAR AXLE





VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	5 HOLES-15"/16"
CONVERTIBLE	-	-	5 HOLES-15"

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
26 113B		BOLT, HUB	H001-26-113	8	NORMAL SUSPENSION	
				10	HARD SUSPENSION	
26 114B		WASHER, PLAIN	H001-26-114A	2		
26 132C		WASHER, SLEEVE-REAR BRAKE	FB01-26-132	2		
26 133		BOLT	FB01-26-133	2		
26 134		BOLT, LOWER ARM	FB01-26-134	2		
26 135		NUT, LOWER ARM	FB01-26-135	1		
26 136		BOLT, LOWER ARM	FB01-26-136	2		
26 137		WASHER, PLAIN-LOWER ARM	FB01-26-137	8		
			<AN> FB05-26-137	8		
26 139		RING, RETAINING	FB01-26-139	2		
26 141A		HUB (R), TOE CONTROL-OUTER	FB01-49-130	1		
26 141Y		HUB (L), TOE CONTROL-OUTER	FB01-49-140	1		
26 151		BEARING, REAR AXLE	FB01-26-151A	2		
26 154		SEAL, OIL-REAR AXLE	FB01-26-065A	2		
26 221		SLEEVE, LOWER ARM	FB01-26-221A	4		
26 241		FLANGE, REAR AXLE	FB01-26-241	2	NORMAL SUSPENSION	
			FB05-26-241A	2	HARD SUSPENSION	
26 335		STOPPER, LOWER ARM	FB01-26-335	2		
26 410B		RUBBER, SEAT-BEARING HOUSING	FC01-26-410			
26 471		ROTOR, SENSOR-REAR A.B.S.	F048-26-471	2		
33 042A		NUT	H001-26-042	2		
39 023		WASHER, SPRING-LOWER ARM	FB01-39-023	4		



# 2610-1 REAR BRAKE MECHANISMS





VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	
CONVERTIBLE	-	-	5 HOLES-15"

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
26 121A		BOLT, REAR BRAKE	FB01-26-121A	4		
26 122		WASHER, PLAIN-REAR BRAKE	FB01-26-122	4		
26 178		BOLT, DUST COVER	FB01-26-138	8		
26 205		BEARING	H001-26-205	2		
26 233		V-SPRING, REAR BRAKE	FB01-26-233	2	NORMAL SUSPENSION	
			FB05-26-233	2	HARD SUSPENSION	
26 251B		PLATE, DISC	FB01-26-251A	2	NORMAL SUSPENSION, 4-BOLT WHEEL	
			FB05-26-251A	2	HARD SUSPENSION, 5-BOLT WHEEL	
26 261		COVER, DUST	FB01-26-261B	2		
26 280B		SUPPORT, MOUNTING	FB01-26-281A	2	NORMAL SUSPENSION	
			FB05-26-281A	2	HARD SUSPENSION	
26 285		PLATE, GUARD-CALIPER BRAKE	FB01-26-285A	2		
26 610		CALIPER (R), REAR BRAKE	FB01-26-610B	1	NORMAL SUSPENSION	
			FB05-26-610B	1	HARD SUSPENSION	
26 610Z		CALIPER (L), REAR BRAKE	FB01-26-710B	1	NORMAL SUSPENSION	
			FB05-26-710B	1	HARD SUSPENSION	
26 660		PISTON, CALIPER-REAR	FA18-26-660	2		
26 668		SPRING (R), CALIPER-REAR	FB01-26-668	1		
26 668Z		SPRING (L), CALIPER-REAR	FB01-26-669	1		
26 680		BOLT	FA18-26-680	2		
26 690		STOPPER, CALIPER-REAR	FB01-26-694	2		
26 691		PIN, GUIDE	FA66-26-695	2		
26 699		PIN, LOCK	FA66-26-998	2		
26 731		SPINDLE, ADJUSTER	H001-26-731A	2		
26 800		LEVER (R), OPERATING	FB01-26-800A	1		
26 800Z		LEVER (L), OPERATING	FB01-26-810A	1		
26 812		LINK, CONNECTING	H001-26-812	2		
26 851		BRACKET (R), CALIPER-REAR	FB01-26-851	1		
26 851Z		BRACKET (L), CALIPER-REAR	FB01-26-861	1		
26 980		CALIPER (R), REAR BRAKE	FB01-26-980F	1	NORMAL SUSPENSION	
			FB05-26-980F	1	HARD SUSPENSION	
26 980Z		CALIPER (L), REAR BRAKE	FB01-26-990F	1	NORMAL SUSPENSION	
			FB05-26-990F	1	HARD SUSPENSION	
33 691		SCREW, BLEEDER	B107-33-691	4		
33 693A		CAP, BLEEDER SCREW	O259-33-693	4		
49 240A		SEAL KIT	FB02-49-240	1		6901-
			H010-49-240	1	HARD SUSPENSION ONLY	-6901
49 250A		BOOT KIT, REAR CALIPER	FA67-26-45Z	1		
49 280A		PAD SUB SET, REAR	FB06-49-280	1		

6901 FC33\* -512255


**2610-2 REAR BRAKE MECHANISMS**



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	5 HOLES-15"/16"
CONVERTIBLE	-	-	5 HOLES-15"

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
49 280A (CONT'D)						
49 290A		ATTACHMENT, PAD-REAR	FB06-49-280A	1	REQUIRES ATTACH. KIT; FB02-49-290B	
			FB02-49-290B	1	NORMAL SUSPENSION	
			FB06-49-290B	1	HARD SUSPENSION	


**REAR DIFFERENTIALS  
(W/O TURBO)(NORMAL DIFFERENTIAL)**



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	
CONVERTIBLE	-	-	5 HOLES-15"

ITEM NO	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
17 122		PLUG, MAGNET	0910-17-121	1		
26 060		BREATHER	0730-26-060	1		
27 012		WASHER	0223-27-012	1		
27 018		SEAL, OIL	M055-27-165	1		
27 020		FLANGE, COMPANION	M055-27-120E	1		
27 030		NUT, LOCK	0223-27-030	1		
27 100		DRIVE & DIFFERENTIAL	M055-27-100D	1	COUPE, M/T	
			M067-27-100E	1	CONVERTIBLE	
27 110		GEAR SET, FINAL	M055-27-110A	1	COUPE, M/T	
			M067-27-110A	1	CONVERTIBLE	
27 141		BEARING, PINION	0755-27-210	1		
27 141A		BEARING, PINION	M025-27-210	1		
27 143A		BEARING, BALL-DRIVE PINION	M055-27-143	2		
27 150		CARRIER, DIFFERENTIAL	M055-27-150B	1		
27 157		STUD, DIFFERENTIAL CARRIER	P090-27-157	3		
27 171		PIECE, DISTANCE	M035-27-171	1		
27 172		COLLAR, LONG-DRIVE & DIFFERENTIAL	M055-27-172B	1		
27 230		CASE	M025-27-231B	1		
27 235		BOLT, RING GEAR	8051-27-235	10	D=10MM	
			8051-27-236	10	D=10.2MM	
27 238		SEAL, OIL	F003-27-238A	2		
27 251		GEAR, DIFFERENTIAL SIDE	M025-27-251	2		
27 252		WASHER	0290-27-252	2	T=2MM	
			0290-27-256	2	T=2.05MM	
			0290-27-253	2	T=2.1MM	
			0290-27-259	2	T=2.15MM	
			0290-17-254	2	T=2.2MM	
27 255		PINION, DIFFERENTIAL	M025-27-255B	2		
27 256		WASHER, THRUST	M025-27-256	2	T=2MM	
27 261		SHAFT, DIFFERENTIAL PINION	M025-27-261A	1		
27 262		PIN	0114-27-262	1		
27 270		YOKE, DIFFERENTIAL	M055-27-270	2		
27 301A		SCREW, ADJUST	0290-27-301	2		
27 302		PLATE, LOCK	0290-27-302	2		
27 305		BEARING	0221-27-350	2		
27 401		SPACER	0223-27-401A	1	T=3.08MM	
			0223-27-402A	1	T=3.11MM	
			0223-27-403A	1	T=3.14MM	
			0223-27-404A	1	T=3.17MM	
			0223-27-405A	1	T=3.2MM	
			0223-27-406A	1	T=3.23MM	


REAR DIFFERENTIALS  
(W/O TURBO)(NORMAL DIFFERENTIAL)



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A.A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	
CONVERTIBLE	-	-	5 HOLES-15"


ITEM NO.	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
27 401 (CONT'D)			0223-27-407A	1	T=3.26MM	
			0223-27-408A	1	T=3.29MM	
			0223-27-409A	1	T=3.32MM	
			0223-27-411A	1	T=3.35MM	
			0223-27-412A	1	T=3.38MM	
			0223-27-413A	1	T=3.41MM	
			0223-27-414A	1	T=3.44MM	
			0223-27-415A	1	T=3.47MM	
27 421		CLIP	M005-27-421	2		
27 600		CASING, DIFFERENTIAL	M055-27-600C	1		
27 604		BOLT, CARRIER	M053-27-604	1		
			M053-27-605	1		
27 609		PLATE, BAFFLE-DIFFERENTIAL CASING	M055-27-609	1		
28 890E		RUBBER, MOUNTING-DIFFERENTIAL CASING	FB01-28-890C	2		

**2710A-1 REAR DIFFERENTIALS  
(W/O TURBO)(LIMITED-SLIP DIFFERENTIAL)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
17 122		PLUG, MAGNET	0810-17-121	1		
26 060		BREATHER	0730-26-060	1		
27 012		WASHER	0223-27-012	1		
27 017		PLATE, CAUTION-DIFFERENTIAL	M055-27-017	1		
27 018		SEAL, OIL	M055-27-145	1		
27 020		FLANGE, COMPANION	M055-27-120E	1		
27 030		NUT, LOCK	0223-27-030	1		
27 100		DRIVE & DIFFERENTIAL	M068-27-100E	1	A/T	
			M095-27-100F	1	M/T	
27 110		GEAR SET, FINAL	M055-27-110A	1	M/T	
			M067-27-110A	1	A/T	
27 141		BEARING, PINION	0755-27-210	1		
27 141A		BEARING, PINION	M025-27-210	1		
27 143A		BEARING, BALL-DRIVE PINION	M055-27-143	2		
27 150		CARRIER, DIFFERENTIAL	M055-27-150B	1		
27 157		STUD, DIFFERENTIAL CARRIER	P090-27-157	3		
27 171		PIECE, DISTANCE	M035-27-171	1		
27 172		COLLAR, LONG-DRIVE & DIFFERENTIAL	M055-27-172B	1		
27 200		DIFFERENTIAL	M081-27-200	1		
27 230		CASE	M081-27-230	1		
27 235		BOLT, RING GEAR	8051-27-235	10	D=10MM	
			8051-27-236	10	D=10.2MM	
27 238		SEAL, OIL	F003-27-238	2		
27 251		GEAR, DIFFERENTIAL SIDE	M080-27-251	2		
27 252		WASHER	M020-27-252	2	T=1.6MM	
			M020-27-253	2	T=1.8MM	
27 255		PINION, DIFFERENTIAL	M020-27-255	4		
27 258		PLATE, FRICTION	M020-27-258	6		
27 259B		SPRING, CONICAL	M020-27-259	2		
27 261		SHAFT, DIFFERENTIAL PINION	M020-27-261	1		
27 265		RING, PRESSURE	M020-27-265	2		
27 270		YOKE, DIFFERENTIAL	M055-27-270	2		
27 301A		SCREW, ADJUST	0290-27-301	2		
27 302		PLATE, LOCK	0290-27-302	2		
27 305		BEARING	0221-27-350	2		
27 401		SPACER	0223-27-401A	1	T=3.08MM	
			0223-27 402A	1	T=3.11MM	
			0223-27 403A	1	T=3.14MM	
			0223-27-404A	1	T=3.17MM	
			0223-27-405A	1	T=3.2MM	
			0223-27-406A	1	T=3.23MM	

REAR DIFFERENTIALS  
(W/O TURBO/LIMITED-SLIP DIFFERENTIAL)




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
27 401 (CONT'D)			0223-27-407A	1	T=3.26MM	
			0223-27-408A	1	T=3.29MM	
			0223-27-409A	1	T=3.32MM	
			0223-27-411A	1	T=3.35MM	
			0223-27-412A	1	T=3.38MM	
			0223-27-413A	1	T=3.41MM	
			0223-27-414A	1	T=3.44MM	
			0223-27-415A	1	T=3.47MM	
27 421		CLIP	M005-27-421	2		
27 600		CASING, DIFFERENTIAL	M055-27-600C	1		
27 604		BOLT, CARRIER	M053-27-604	1		
			M053-27-605	1		
27 609		PLATE, BAFFLE-DIFFERENTIAL CASING	M055-27-609	1		
	:90E	RUBBER, MOUNTING-DIFFERENTIAL CASING	FB01-28-890C	2		
79 977		DISC, FRICTION	M020-27-256	2	T=2MM	
			M020-27-257	2	T=2.1MM	

**2710C-1 REAR DIFFERENTIALS  
(TURBO)(LIMITED-SLIP DIFFERENTIAL)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
17 122		PUG, MAGNET	0810-17-121	1		
26 060		BREATHER	0730-26-060	1		
27 012		WASHER	0223-27-012	1		
27 017		PLATE, CAUTION-DIFFERENTIAL	M055-27-017	1		
27 018		SEAL, OIL	P090-27-165	1		
27 020		FLANGE, COMPANION	P016-27-120F	1		
27 030		NUT, LOCK	0223-27-030	1		
27 100		DRIVE & DIFFERENTIAL	P090-27-100G	1		
27 110		GEAR SET, FINAL	P012-27-110A	1		
27 141A		BEARING, MINION	M025-27-210	1		
			0604-27-220	1		
27 143A		BEARING, BALL-DRIVE MINION	P016-27-143	2		
27 150		CARRIER, DIFFERENTIAL	P016-27-150A	1		
27 157		STUD, DIFFERENTIAL CARRIER	P090-27-157	3		
27 171		PIECE, DISTANCE	0305-27-171	1		
27 172		COLLAR, LONG-DRIVE & DIFFERENTIAL	P016-27-172A	1		
27 200		DIFFERENTIAL	P090-27-200B	1		
27 230		CASE	P090-27-230A	1		
27 235		BOLT, RING GEAR	8051-27-235	10	D=10MM	
			8051-27-236	10	D=10.2MM	
27 238		SEAL, OIL	P016-27-238	2		
27 251		GEAR, DIFFERENTIAL SIDE	P090-27-251	2		
27 252		WASHER	0578-27-252	2	T=1.5MM	
			0578-27-253	2	T=1.6MM	
			0578-27-254	2	T=1.7MM	
27 255		PINION, DIFFERENTIAL	P020-27-255	4		
27 258		PLATE, FRICTION	P020-27-258	2		
27 261		SHAFT, DIFFERENTIAL PINION	P090-27-261	1		
27 265		RING, PRESSURE	P020-27-265	2		
27 266		SEAT, PINION-DIFFERENTIAL	P020-27-266	6		
27 270A		SHAFT, OUTPUT	P016-27-270A	2		
27 301A		SCREW, ADJUST	0110-27-301	2		
27 302		PLATE, LOCK	0578-27-302	2		
27 305		BEARING	0118-27-350A	2		
27 401		SPACER	0223-27-401A	1	T=3.08MM	
			0223-27-402A	1	T=3.11MM	
			0223-27-403A	1	T=3.14MM	
			0223-27-404A	1	T=3.17MM	
			0223-27-405A	1	T=3.2MM	
			0223-27-406A	1	T=3.23MM	
			0223-27-407A	1	T=3.26MM	



**2710C-2 REAR DIFFERENTIALS  
(TURBO)(LIMITED-SLIP DIFFERENTIAL)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
27 401 (CONT'D)			0223-27-408A	1	T=3.29MM	
			0223-27-409A	1	T=3.32MM	
			0223-27-411A	1	T=3.35MM	
			0223-27-412A	1	T=3.38MM	
			0223-27-413A	1	T=3.41MM	
			0223-27-414A	1	T=3.44MM	
			0223-27-415A	1	T=3.47MM	
	27 421		CLIP	P016-27-421	2	
27 600		CASING, DIFFERENTIAL	P016-27-600B	1		
27 604		BOLT, CARRIER	M053-27-605	2		
27 609		PLATE, BAFFLE-DIFFERENTIAL CASING	M055-27-609	1		
28 890E		RUBBER, MOUNTING-DIFFERENTIAL CASING	F801-28-890C	2		
79 977		DISC, FRICTION	P020-27-256	4	T=1.75MM	
			P020-27-257	4	T=1.85MM	



REAR SUSPENSION MECHANISMS (W/O TURBO)  
(W/O AUTOMATIC ADJUSTING SUSPENSION)



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	
CONVERTIBLE	-	-	5 HOLES-15"


ITEM NO.	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
	28 010A	SPRING, COIL-REAR	FB01-28-011A	2	COUPE, NORMAL SUSPENSION	6701-
			FB67-28-011A	2	CONVERTIBLE, NORMAL SUSPENSION	
			FB01-28-011A	2	HARD SUSPENSION	.6701
28 014B		RUBBER, STOPPER-REAR DAMPER	FB01-28-014	2		
28 015B		BUSHING, RUBBER-REAR DAMPER	FO44-28-015	2		
28 016B		BUSHING, RUBBER-REAR DAMPER	FO44-28-013	2		
28 020		PLATE SET, REAR DAMPER	FB01-28-020	2		
28 025		SPACER, REAR DAMPER	FB01-28-025	2		
28 030		STOPPER, REAR DAMPER	FB01-28-030A	2		
28 040		SHEET, SPRING-REAR DAMPER	FB01-28-040	2		
28 050		PLATE, MOUNTING-REAR DAMPER	FB01-28-050	2		
28 314		BOLT 'B', LINK	H260-34-037A	2		6711-
28 333A		NUT, FLANGE	H001-28-333	4		
28 401		WASHER	FB01-28-401	2		6801-
28 600		LINK, LATERAL	FB01-28-200	2		
28 700		DAMPER, REAR	FB44-28-700C	2	CONVERTIBLE, NORMAL SUSPENSION	
			FB01-28-700E	2	COUPE, NORMAL SUSPENSION	
			FB43-28-700F	2	HARD SUSPENSION	
34 662		WASHER	H001-28-401	2		.6801
39 037		NUT	B001-39-037B	4		

6701	FC33*	500010
6711	FC33*	502690
6801	FC33*	522333


# SECTION INDEX -- CHASSIS

STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME
1 - C11	2500	DRIVESHAFT	1 - K14	3900BA	ENGINE & TRANSMISSION MOUNTINGS (TURBO)			
1 - D11	2550	REAR DRIVESHAFTS	1 - L14	4000B	EXHAUST SYSTEM (W/O TURBO)			
1 - E11	2600	REAR AXLE	1 - C15	4000BA	EXHAUST SYSTEM (TURBO)			
1 - F11	2610	REAR BRAKE MECHANISMS	1 - E15	4140B	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)			
1 - H11	2710	REAR DIFFERENTIALS (W/O TURBO)(NORMAL DIFFERENTIAL)	1 - F15	4160	ACCELERATOR CONTROL SYSTEM			
1 - J11	2710A	REAR DIFFERENTIALS (W/O TURBO)(LIMITED-SLIP DIFFERENTIAL)	1 - G15	4200	FUEL TANK			
1 - L11	2710C	REAR DIFFERENTIALS (TURBO)(LIMITED-SLIP DIFFERENTIAL)	1 - H15	4300	CLUTCH & BRAKE PEDALS			
1 - N11	2800	REAR SUSPENSION MECHANISMS (W/O TURBO) (W/O AUTOMATIC ADJUSTING SUSPENSION)	1 - J15	4340	BRAKE MASTER CYLINDER & POWER BRAKE (W/O ANTI-LOCK BRAKE SYSTEM)			
1 - C12	2800A	REAR SUSPENSION MECHANISMS (W/O TURBO) (FOR AUTOMATIC ADJUSTING SUSPENSION)	1 - L15	4340A	BRAKE MASTER CYLINDER & POWER BRAKE (ANTI-LOCK BRAKE SYSTEM)			
1 - D12	2800B	REAR SUSPENSION MECHANISMS (TURBO)	1 - N15	4360	BRAKE PIPINGS (W/O ANTI-LOCK BRAKE SYSTEM)			
1 - E12	2810	REAR STABILIZER	1 - C16	4360A	BRAKE PIPINGS (ANTI-LOCK BRAKE SYSTEM)			
1 - F12	2830	REAR LOWER ARMS & SUB-FRAME	1 - D16	4370	ANTI-LOCK BRAKE SYSTEMS			
1 - H12	3200	STEERING WHEEL	1 - F16	4400	PARKING BRAKE SYSTEM			
1 - I12	3210	STEERING COLUMN & SHAFTS	1 - G16	4500B	FUEL PIPINGS (W/O ANTI-LOCK BRAKE SYSTEM)			
1 - J12	3210A	STEERING COLUMN & SHAFTS (W/ POWER STEERING)	1 - H16	4500BA	FUEL PIPINGS (ANTI-LOCK BRAKE SYSTEM)			
1 - K12	3220	STEERING GEAR (W/O POWER STEERING)	1 - I16	4600	CHANGE CONTROL SYSTEM (AUTOMATIC TRANSMISSION)			
1 - L12	3220A	STEERING GEAR (W/ POWER STEERING)						
1 - M12	3230	STEERING LINKAGE SYSTEM						
1 - C13	3240	POWER STEERING SYSTEM						
1 - E13	3300	FRONT AXLE & BRAKE MECHANISMS (FOR NORMAL SUSPENSION)						
1 - I13	3300A	FRONT AXLE & BRAKE MECHANISMS (FOR HARD SUSPENSION) (W/O ANTI-LOCK BRAKE SYSTEM)						
1 - K13	3300B	FRONT AXLE & BRAKE MECHANISMS (FOR HARD SUSPENSION) (ANTI-LOCK BRAKE SYSTEM)						
1 - M13	3400	FRONT SUSPENSION MECHANISMS (W/O TURBO) (W/O AUTOMATIC ADJUSTING SUSPENSION)						
1 - N13	3400A	FRONT SUSPENSION MECHANISMS (W/O TURBO) (FOR AUTOMATIC ADJUSTING SUSPENSION)						
1 - C14	3400B	FRONT SUSPENSION MECHANISMS (TURBO)						
1 - D14	3410	CROSSMEMBER & STABILIZER						
1 - E14	3700	TIRES & JACK (W/O TURBO)						
1 - H14	3700A	TIRES & JACK (TURBO)						
1 - J14	3900B	ENGINE & TRANSMISSION MOUNTINGS (W/O TURBO)						

**REAR SUSPENSION MECHANISMS (W/O TURBO)  
(FOR AUTOMATIC ADJUSTING SUSPENSION)**





FRAME, SUB  
(REFER TO SECT.NO.2830)



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A.A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	<	x	
CONVERTIBLE	-	-	5 HOLES-15"

ITEM NO.	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
28 010A		SPRING, COIL-REAR	FB01-28-011A	2		
28 014B		RUBBER, STOPPER-REAR DAMPER	FB01-28-014	2		
28 015B		BUSHING, RUBBER-REAR DAMPER	F044-28-015	2		
28 016B		BUSHING, RUBBER-REAR DAMPER	F044-28-013	2		
28 020		PLATE SET, REAR DAMPER	FB01-28-020	2		
28 025		SPACER, REAR DAMPER	FB01-28-025	2		
28 030		STOPPER, REAR DAMPER	FB01-28-030A	2		
28 040		SHEET, SPRING-REAR DAMPER	FB01-28-040	2		
28 050		PLATE, MOUNTING-REAR DAMPER	FB01-28-050	2		
28 314		BOLT 'B', LINK	H260 34-037A	2		6711-
28 333A		NUT, FLANGE	H001-28-333	4		
28 401		WASHER	FB01-28-401	2		6801-
28 600		LINK, LATERAL	FB01-28-200A	2		
28 700		DAMPER, REAR	FB52-28-700C	2		
34 080A		ACTUATOR, REAR DAMPER	FB07-28-080B	2		
34 088A		PLATE	H126-28-088	2		
34 662		WASHER	H001-28-401	2		-6801
39 037		NUT	B001-39-037B	4		

6711 FC33\* -502690  
6801 FC33\* -522333




VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A.A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	
CONVERTIBLE	-	-	5 HOLES-15"

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	28 010A	SPRING, COIL-REAR	FB01-28-011A	2		
	28 014B	RUBBER, STOPPER-REAR DAMPER	FB01-28-014	2		
	28 016B	BUSHING, RUBBER-REAR DAMPER	F044-28-015	2		
	28 016B	BUSHING, RUBBER-REAR DAMPER	F044-28-013	2		
	28 020	PLATE SET, REAR DAMPER	FB01-28-020	2		
	28 025	SPACER, REAR DAMPER	FB01-28-025	2		
	28 030	STOPPER, REAR DAMPER	FB01-28-030A	2		
	28 040	SHEET, SPRING-REAR DAMPER	FB01-28-040	2		
	28 050	PLATE, MOUNTING-REAR DAMPER	FB01-28-050	2		
	28 314	BOLT 'B', LINK	H260-34-037A	2		6711-
	28 333A	NUT, FLANGE	H001-28-333	4		6801-
	28 401	WASHER	FB01-28-401	2		6801-
	28 600	LINK, LATERAL	FB01-28-200	2		
	28 700	DAMPER, REAR	FB44-28-700C	2		
	34 662	WASHER	H001-28-401	2		-6801
	39 037	NUT	B001-39-037B	4		

6711 FC33\* -502690  
6801 FC33\* -522333

**2810-1 REAR STABILIZER**




VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	
CONVERTIBLE	-	-	5 HOLES-15"

ITEM NO	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
28 101		STABILIZER, REAR	FB01-28-151B	1	NORMAL SUSPENSION	
			FB43-28-151C	1	HARD SUSPENSION	
28 102		BUSHING, STABILIZER-REAR	FB01-28-156	2	NORMAL SUSPENSION	
			FB43-28-156A	2	HARD SUSPENSION	
28 103		PLATE, STABILIZER	G030-28-155	2		-7101
			FB01-28-155	2		7101-
28 155		BRACKET, STABILIZER SUPPORT	FB01-28-160	2		-7101
			<C> FB01-28-160A	2	REQUIRES FB01-28-155 -	7101-
				2	BRACKET	
28 170B		LINK, CONTROL-STABILIZER	FB01-28-170B	2		

7101 FC33\* -528625

2830-1


REAR LOWER ARMS & SUB-FRAME



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	
CONVERTIBLE	-	-	5 HOLES-15"

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
25 124		NUT	1368-25-124	4		
26 220		BUSHING, RUBBER-REAR LOWER ARM	FB01-26-220	2		
26 230		BALL, PILLOW-REAR LOWER ARM	FB01-26-230	2		
26 250		RUBBER, SEAL-REAR LOWER ARM	FB01-26-250	4		
28 091		NUT	FB01-28-091	2		
			B037-28-091	9		-5801
				7		5801-
						6501-
28 092		BOLT, CONTROL LINK	FB01-28-092	4		
28 210		LINK, CONTROL-LOWER ARM	FB01-28-210	2		
			<AN> FC01-28-210	2		
28 300		ARM (R), LOWER	FB43-28-300B	1		
28 300Z		ARM (L), LOWER	FB43-28-350D	1		
28 370		BOLT, ADJUST	FB01-28-470A	2		
28 390B		PLATE, CAM	FB01-28-473	4		-5801
				2		5801-
28 398		BOLT, DAMPER-REAR	F044-28-398A	2		
28 460		BUSHING, LOWER ARM	FB01-28-460	4		
28 800		FRAME, SUB	FB43-28-800G	1		
28 830		LINK, SUB-LOWER ARM	FB01-28-830	1		
28 840		RUBBER, SUB-FRAME	FB43-28-840	2		
28 845		WASHER (R), STOP-LOWER ARM	FB43-28-845B	1	W/ A.A.S.	6301-
					W/O A.A.S.	7108-
			FB01-28-845A	1	NORMAL SUSPENSION	-5801
			FB43-28-845A	1	HARD SUSPENSION W/O A.A.S.	-7108
					HARD SUSPENSION W/ A.A.S.	-6301
					NORMAL SUSPENSION	5801-7108
28 845Z		WASHER (L), STOP-LOWER ARM	FB43-28-855B	1	W/ A.A.S.	6301-
					W/O A.A.S.	7108-
			FB43-28-855A	1	NORMAL SUSPENSION	-5801
					HARD SUSPENSION W/O A.A.S.	-7108
					HARD SUSPENSION W/ A.A.S.	-6301
			FB43-28-855A		NORMAL SUSPENSION	5801-7108
28 880A		WASHER, STOP	FB01-28-880A	2		
28 895		RUBBER, MOUNTING-DIFFERENTIAL	FC01-28-980	1		
28 896		WASHER, MOUNTING RUBBER-DIFFERENTIAL	FB01-28-896	1		
34 222		NUT	8871-34-222	2		5810-
58 10	FC33*	-100079				
58 01	FC33*	-113629				
63 01	FC33*	-134718				
65 01	FC33*	-146093				
71 08	FC33*	-528997				



2830-2 REAR LOWER ARMS & SUB-FRAME



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A.A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
CONVERTIBLE	-	-	5 HOLES-15"

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	39 037	NUT	8001-30-037B	2		



**3200-1 STEERING WHEEL**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
32 016C		PLATE, CONTACT	FB01-32-750	1		
32 017A		PLATE, CONTACT	FB01-32-760	1		
32 039		CORD	FB01-32-016	1		
32 041		PLATE, SET	FB01-32-986	1		
32 049		COVER, WHEEL CORE	FB01-32-049	1		
32 740C		PARTS SET, STEERING WHEEL BOSS	FB01-32-740	1		
32 800		CAP, HORN	FB05-32-800A FB06-32-800A	1		
32 820		TERMINAL	FB01-32-981	1		
32 980		BOSS, STEERING WHEEL	FB01-32-980B	1	STD, SE, SPORT URETHANE, 2-SPOKE	
			FB03-32-980B	1	GXL, TURBO LEATHER, 2-SPOKE	
			FB06-32-980B	1	CONV. LEATHER, 3-SPOKE	
32 981		PAD, HORN	FB01-32-730	1		



# 3210-1 STEERING COLUMN & SHAFTS





ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
32 020C		BOLT	8001-32-020	2		
32 084		BOLT	W001-32-084	4	TURBO (TILT STEERING)	
32 087		O-RING	W048-32-087	1	TURBO, (TILT STEERING)	-5925
				1	STD. (W/O TILT STEERING)	-6221
32 090B		SHAFT, INTERMEDIATE	FB02-32-090B	1		
32 100		SHAFT, ENERGY ABSORBER	FB01-32-100	1	STD. (W/O TILT STEERING)	
			FB05-32-100A	1	TURBO (TILT STEERING)	
32 101A		SPRING, BALANCE-SHAFT	FB05-32-101	1	TURBO (TILT STEERING)	
32 102		SPRING, RETURN-SHAFT	FB05-32-102	1	TURBO (TILT STEERING)	
32 157		PLATE, COATING-SHAFT	FB01-32-157	2	STD. (W/O TILT STEERING)	
			FB05-32-157	2	TURBO (TILT STEERING)	
32 168A		WASHER, STOP	FB01-32-168	1		
32 169A		BOLT	8001-32-169A	1		
32 210		COVER, STEERING SHAFT	FB01-32-210	1		
32 411		COVER, DUST	FB01-32-411A	1		

5925 FC33\* -106572  
 .221 FC33\* -133099

3210A-1


STEERING COLUMN & SHAFTS  
(W/ POWER STEERING)



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
32 020C		BOLT	B001-32-020	2		
32 084		BOLT	W001-32-084	4	(TILT STEERING)	
32 087		O-RING	W048-32-087	1	(TILT STEERING)	-5925
				1	(W/O TILT STEERING)	-6221
32 090B		SHAFT, INTERMEDIATE	FB05-32-090F	1		
32 100		SHAFT, ENERGY ABSORBER	FB01-32-100	1	(W/O TILT STEERING)	
			FB05-32-100A	1	(TILT STEERING)	
32 101A		SPRING, BALANCE-SHAFT	FB05-32-101	1	(TILT STEERING)	
32 102		SPRING, RETURN-SHAFT	FB05-32-102	1	(TILT STEERING)	
32 157		PLATE, COATING-SHAFT	FB01-32-157	2	(W/O TILT STEERING)	
			FB05-32-157	2	(TILT STEERING)	
32 168A		WASHER, STOP	FB01-32-168	1		
32 169A		BOLT	B001-32-169A	1		
32 210		COVER, STEERING SHAFT	FB01-32-210	1		
32 411		COVER, DUST	FB01-32-411A	1		

5925 FC33\* -106572  
6221 FC33\* -133099



**STEERING GEAR  
(W/O POWER STEERING)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
19 840J		O-RING	9954-10-1401	1		
32 110		GEAR, STEERING	FB01-32-110F	1		
32 112		COVER, DUST	FB01-32-112	1		
32 113		SPRING, YOKE	FB01-32-113	1		
32 114		BUSHING, RACK	FB01-32-114	1		
32 119E		RACK, STEERING GEAR	FB01-32-119	1		
32 120A		HOUSING, RACK	FB01-32-120	1		
32 122C		MINION, STEERING GEAR	FB01-32-122	1		
32 123		RUBBER, MOUNTING	FB01-32-123	1		
32 124		RUBBER, MOUNTING	FB01-32-124	1		
32 125B		BOOT, RACK	FB01-32-125	1		
32 126A		BOOT, RACK	FB01-32-126	1		
32 128A		SEAL, SHAFT	FB01-32-128	1		
32 129B		PLUG, MINION	FB01-32-129	1		
32 131A		NUT, LOCK-RACK	FB01-32-131	1		
32 132C		NUT, LOCK	FB01-32-132	1		
32 133		PLATE, CLAMP	FB01-32-133	1		
32 134		PLATE, CLAMP	FB01-32-134	1		
32 140B		SPACER	FB01-32-145	1		
32 188B		BAND SET, STEERING GEAR	FB01-32-118	1		

3220A-1

STEERING GEAR  
(W/ POWER STEERING)





ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
19 840J		O-RING	9954-10-1401	1		
32 110		GEAR, STEERING	FB05-32-110F	1		.7701
			FB78-32-110C	1		7701-
32 111		YOKE, SUPPORT	FB05-32-111	1		.7701
32 112		COVER, DUST	FB05-32-112	1		.7701
32 113		SPRING, YOKE	FB05-32-113	1		.7701
32 115		BEARING	FB05-32-115	1		.7701
32 119E		RACK, STEERING GEAR	FB05-32-119	1		.7701
32 120A		HOUSING, RACK	FB05-32-120	1		.7701
32 123		RUBBER, MOUNTING	FB05-32-123	1		.7701
32 124		RUBBER, MOUNTING	FB01-32-124	1		.7701
32 125B		BOOT, RACK	FB01-32-125	1		.7701
32 126		SEAL, SHAFT	FB01-32-126	1		.7701
32 129B		PLUG, PINION	FB05-32-129	1		.7701
32 131A		NUT, LOCK-RACK	FB05-32-131	1		.7701
32 133		PLATE, CLAMP	FB05-32-133	1		.7701
32 134		PLATE, CLAMP	FB01-32-134	1		.7701
32 147A		BEARING	FB05-32-147	1		.7701
32 148		EYE BOLT KIT, STEERING GEAR	FB05-32-148	2		.7701
32 151		COVER, END	FB05-32-151	1		.7701
32 152A		NUT, ADJUST	FB05-32-152	1		.7701
32 153		RING, BACK-UP	FB05-32-153	1		.7701
32 154A		HOLDER, STEERING GEAR	FB05-32-154	1		.7701
32 155		BUSHING, RUBBER	FB05-32-155	1		.7701
32 180A		SEAL KIT, STEERING GEAR	FB05-32-180	1		.7701
32 186C		CLIP KIT, STEERING GEAR	FB05-32-186	1		.7701
32 380A		VALVE	FB05-32-380	1		.7701
32 451		PIPE 'A', STEERING GEAR	FB05-32-451	1		.7701
32 452		PIPE 'B', STEERING GEAR	FB05-32-452	1		.7701
32 481B		PIPE 'A', CYLINDER	FB05-32-481	1		.7701
32 482		HOSE NO. 2, RETURN	FB05-32-482	1		.7701

7701 FC33\* -550169

3230.1

STEERING LINKAGE SYSTEM




ITEM NO	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
32 240A		JOINT, BALL	FB02-32-240	1	W/O P/S	.7701
			FB01-32-240A	1	W/O P/S	7701.
				2	W/ P/S	7701.
32 241		PIN, SPRING-STEERING GEAR	FB01-32-241	2		
32 279		SEAL, DUST-BALL JOINT	8021-32-279	2		
32 280S		JOINT SET, BALL	BAF1-32-280	2		

7701 FC33\* -550169


# SECTION INDEX -- CHASSIS

STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME
1 - C11	2500	DRIVESHAFT	1 - K14	3900BA	ENGINE & TRANSMISSION MOUNTINGS (TURBO)			
1 - D11	2550	REAR DRIVESHAFTS	1 - L14	4000B	EXHAUST SYSTEM (W/O TURBO)			
1 - E11	2600	REAR AXLE	1 - C15	4000BA	EXHAUST SYSTEM (TURBO)			
1 - F11	2610	REAR BRAKE MECHANISMS	1 - E15	4140B	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)			
1 - H11	2710	REAR DIFFERENTIALS (W/O TURBO)(NORMAL DIFFERENTIAL)	1 - F15	4160	ACCELERATOR CONTROL SYSTEM			
1 - J11	2710A	REAR DIFFERENTIALS (W/O TURBO)(LIMITED-SLIP DIFFERENTIAL)	1 - G15	4200	FUEL TANK			
1 - L11	2710C	REAR DIFFERENTIALS (TURBO)(LIMITED-SLIP DIFFERENTIAL)	1 - H15	4300	CLUTCH & BRAKE PEDALS			
1 - N11	2800	REAR SUSPENSION MECHANISMS (W/O TURBO) (W/O AUTOMATIC ADJUSTING SUSPENSION)	1 - J15	4340	BRAKE MASTER CYLINDER & POWER BRAKE (W/O ANTI-LOCK BRAKE SYSTEM)			
1 - C12	2800A	REAR SUSPENSION MECHANISMS (W/O TURBO) (FOR AUTOMATIC ADJUSTING SUSPENSION)	1 - L15	4340A	BRAKE MASTER CYLINDER & POWER BRAKE (ANTI-LOCK BRAKE SYSTEM)			
1 - D12	2800B	REAR SUSPENSION MECHANISMS (TURBO)	1 - N15	4360	BRAKE PIPINGS (W/O ANTI-LOCK BRAKE SYSTEM)			
1 - E12	2810	REAR STABILIZER	1 - C16	4360A	BRAKE PIPINGS (ANTI-LOCK BRAKE SYSTEM)			
1 - F12	2830	REAR LOWER ARMS & SUB-FRAME	1 - D16	4370	ANTI-LOCK BRAKE SYSTEMS			
1 - H12	3200	STEERING WHEEL	1 - F16	4400	PARKING BRAKE SYSTEM			
1 - I12	3210	STEERING COLUMN & SHAFTS	1 - G16	4500B	FUEL PIPINGS (W/O ANTI-LOCK BRAKE SYSTEM)			
1 - J12	3210A	STEERING COLUMN & SHAFTS (W. POWER STEERING)	1 - H16	4500BA	FUEL PIPINGS (ANTI-LOCK BRAKE SYSTEM)			
1 - K12	3220	STEERING GEAR (W/O POWER STEERING)	1 - I16	4600	CHANGE CONTROL SYSTEM (AUTOMATIC TRANSMISSION)			
1 - L12	3220A	STEERING GEAR (W. POWER STEERING)						
1 - M12	3230	STEERING LINKAGE SYSTEM						
1 - C13	3240	POWER STEERING SYSTEM						
1 - E13	3300	FRONT AXLE & BRAKE MECHANISMS (FOR NORMAL SUSPENSION)						
1 - I13	3300A	FRONT AXLE & BRAKE MECHANISMS (FOR HARD SUSPENSION) (W/O ANTI-LOCK BRAKE SYSTEM)						
1 - K13	3300B	FRONT AXLE & BRAKE MECHANISMS (FOR HARD SUSPENSION) (ANTI-LOCK BRAKE SYSTEM)						
1 - M13	3400	FRONT SUSPENSION MECHANISMS (W/O TURBO) (W/O AUTOMATIC ADJUSTING SUSPENSION)						
1 - N13	3400A	FRONT SUSPENSION MECHANISMS (W/O TURBO) (FOR AUTOMATIC ADJUSTING SUSPENSION)						
1 - C14	3400B	FRONT SUSPENSION MECHANISMS (TURBO)						
1 - D14	3410	CROSSMEMBER & STABILIZER						
1 - E14	3700	TIRES & JACK (W/O TURBO)						
1 - H14	3700A	TIRES & JACK (TURBO)						
1 - J14	3900B	ENGINE & TRANSMISSION MOUNTINGS (W/O TURBO)						

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



3240-2

## POWER STEERING SYSTEM

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
32 230		SWITCH, PRESSURE	FB05-32-230A	1	P/S	
32 400		CONTROLLER REFER TO SERV. BULL. NO. 035/86, CAT. 15 FOR MORE INFO.	FB05-32-400C	1		-7701
			FB78-32-400	1		7701-
32 410B		PIPE-NO. 1	FC01-32-410	1		
32 471		HOSE, RETURN	FB05-32-470A	1		
32 480		PIPE, RETURN	FB05-32-480	1		
32 490		HOSE, PRESSURE	FB05-32-490E	1		
32 600		PUMP, VANE	FB05-32-600A	1		-7701
			FB78-32-600B	1		7701-
32 601		PULLEY, VANE PUM	FB05-32-620	1		
32 603		CAP, FILLER	FB05-32-611	1		
32 606		CLIP	FB01-32-642	1		
32 610		SEAL KIT, VANE PUMP	FB05-32-610	1		-7701
			FB78-32-610A	1		7701-
32 614		O-RING, VANE PUMP	FB05-32-632	1		
32 614A		BOLT	FB05-32-614	2		
32 630B		PIPE, VANE PUMP	FB05-32-630	1		
32 631		BOLT, VANE PUMP	FB05-32-611	2		
32 690		TANK, VANE PUMP	FB05-32-690	1		
67 7403		RELAY, N.O.	B092-67-740	1	M/T, TURBO	
67 740Y		RELAY & COVER, NORMAL OPEN	FB11-67-740	1	M/T, TURBO (30A)	
67 742		BRACKET, RELAY	FB10-67-742	1	M/T, TURBO	
67 744		BOOT, RELAY-WATER PROOF	FB10-67-744	1	M/T, TURBO	



SEE ILLUSTRATION/S AT FRAME 1 - C13

7701 FC33\* -550169



(CPE)



(THIS ILLUSTRATION CONSISTS OF 3 PAGES)



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-16"/16"
	x	x	5 HOLES-16"/16"
CONVERTIBLE	-	-	5 HOLES-15"

(CONVERTIBLE)(-7A27)

(THIS ILLUSTRATION CONSISTS OF 3 PAGES)




VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	5 HOLES-15"/16"
CONVERTIBLE	-	-	5 HOLES-15"


**FRONT AXLE & BRAKE MECHANISMS  
(FOR NORMAL SUSPENSION)**

(CONVERTIBLE) (7A27-)

(THIS ILLUSTRATION CONSISTS OF 3 PAGES)



THOUGH ILLUSTRATIONS OF I-CODE 49-240C, 49-280B AND 49-290B ARE FOR LEFT SIDE ONLY, QUANTITIES OF THESE I-CODES IN THE TEXT ARE FOR ONE VEHICLE.



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	
CONVERTIBLE	-	-	5 HOLES-15"

**3300-3**

**FRONT AXLE & BRAKE MECHANISMS  
(FOR NORMAL SUSPENSION)**

**SEE ILLUSTRATION/S AT FRAME 1 - E13**

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	26 043	WASHER, CLAW	1011-33-043	2		
	33 020	KNUCKLE (R), STEERING	FB01-33-021B	1		
	33 020Z	KNUCKLE (L), STEERING	FB01-33-031B	1		
	33 042	NUT	0662-33-042	2		
	33 049	COVER, SET	0662-33-049	2		
	33 061	HUB, FRONT WHEEL	FB05-49-040E	2	CONVERTIBLE	
			FB01-49-060E	2	COUPE	
	33 062	BOLT, WHEEL	FB01-26-113A	8	COUPE	
			FB05-26-113A	10	CONVERTIBLE	
	33 065	SEAL, OIL-FRONT AXLE	FB01-33-065A	2		
	33 071	CAP, HUB	FB01-33-071A	2		
	33 251B	PLATE, HUB/DISK	FB01-33-251	2	COUPE	
			FB05-33-251	2	CONVERTIBLE	
	33 261	COVER (R), DUST	FB01-33-260B	1	COUPE	
			FB05-33-260B	1	CONVERTIBLE	
	33 261Z	COVER (L), DUST	FB01-33-270B	1	COUPE	
			FB05-33-270B	1	CONVERTIBLE	
	33 280B	SUPPORT (R), MOUNTING	FB01-33-281	1		
	33 280X	SUPPORT (L), MOUNTING	FB01-33-291	1		
	33 651	PISTON, FRONT CALIPER	FB05-33-651	8	CONVERTIBLE	
			8341-33-651	2	COUPE	
	33 691	SCREW, BLEEDER	FB05-33-691A	2	CONVERTIBLE	
			0233-33-691	2	COUPE	
	33 693	CAP, RUBBER	FB05-33-693	2	CONVERTIBLE	
	33 693A	CAP, BLEEDER SCREW	0259-33-693	2	COUPE	
	33 694	PIN, GUIDE-FRONT CALIPER	8341-33-694	2	COUPE	
	33 696A	PIN, PAD-FRONT BRAKE	FB05-33-696	4	CONVERTIBLE	
	33 697	BOLT, BRIDGE-FRONT BRAKE	FB05-33-697	8	CONVERTIBLE	
	33 698A	PIN	FA66-33-699	2	COUPE	
	33 980	CALIPER (R), FRONT BRAKE	FC02-33-980A	1	CONVERTIBLE	
		REFER TO WARR. CAMPAIGN NO. 26801 FOR RECALL INFO. ON CERTAIN 1986 & 1987 MODELS.				
	33 980Z	CALIPER (L), FRONT BRAKE	FC02-33-990A	1	CONVERTIBLE	
		REFER TO WARR. CAMPAIGN NO. 26801 FOR RECALL INFO. ON CERTAIN 1986 & 1987 MODELS.				
	33 981A	WASHER, PLAIN-DUST COVER	FB01-33-981	8	COUPE	
	49 240C	SEAL KIT, CALIPER-FRONT	FB05-49-240	1	CONVERTIBLE	

3300-4



**FRONT AXLE & BRAKE MECHANISMS  
(FOR NORMAL SUSPENSION)**

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	49 240C (CONT'D)		8341-49-240	1	COUPE	
	49 250B	BOOT KIT, FRONT CALIPER	FA66-49-250	1	COUPE	
	49 280B	PAD SET, FRONT CALIPER	FA66-49-280	1		
		REFER TO WARR. CAMPAIGN NO. 26801 FOR RECALL INFO. ON CERTAIN 1986 & 1987 MODELS.				
			8BF1-33-625	1	CONVERTIBLE	
			<AN> FC02-33-28Z	1		
	49 290B	ATTACHMENT, PAD-FRONT	FB05-49-290B	1	CONVERTIBLE	
			FA66-49-290A	1	COUPE	

**SEE ILLUSTRATION/S AT FRAME 1 - E13**

(-7A27)



(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	5 HOLES-15"/16"
CONVERTIBLE	-	-	5 HOLES-15"

(7A27-)

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	5 HOLES-15"/16"
CONVERTIBLE	-	-	5 HOLES-15"

3300A-2



**FRONT AXLE & BRAKE MECHANISMS (FOR HARD  
SUSPENSION) (W/O ANTI-LOCK BRAKE SYSTEM)**

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	26 043	WASHER, CLAW	1011-33-043	2		
	26 137	WASHER, PLAIN-LOWER ARM	FB01-26-137	4		
	33 020	KNUCKLE (R), STEERING	FB01-33-021B	1		
	33 020Z	KNUCKLE (L), STEERING	FB01-33-031B	1		
	33 042	NUT	0662-33-042	2		
	33 049	COVER, SET	0662-33-049	2		
	33 061	HUB, FRONT WHEEL	FB05-49-060E	2		
	33 062	BOLT, WHEEL	FB05-26-113A	10		
	33 065	SEAL, OIL-FRONT AXLE	FB01-33-065A	2		
	33 071	CAP, HUB	FB01-33-071A	2		
	33 251B	PLATE, HUB/DISK	FB05-33-251	2		
	33 261	COVER (R), DUST	FB05-33-260B	1		
	33 261Z	COVER (L), DUST	FB05-33-270B	1		
	33 651	PISTON, FRONT CALIPER	FB05-33-651	8		
	33 691	SCREW, BLEEDER	FB05-33-691A	2		
	33 693	CAP, RUBBER	FB05-33-693	2		
	33 696A	PIN, PAD-FRONT BRAKE	FB05-33-696B	4		
	33 697	BOLT, BRIDGE-FRONT BRAKE	FB05-33-697	8		
	33 980	CALIPER (R), FRONT BRAKE	FC02-33-980A	1		
		REFER TO WARR. CAMPAIGN NO. 26801 FOR RECALL INFO. ON CERTAIN 1986 & 1987 MODELS.				
	33 980Z	CALIPER (L), FRONT BRAKE	FC02-33-990A	1		
		REFER TO WARR. CAMPAIGN NO. 26801 FOR RECALL INFO. ON CERTAIN 1986 & 1987 MODELS.				
	33 981A	WASHER, PLAIN-DUST COVER	FB01-33-981	8		
	49 240C	SEAL KIT, CALIPER-FRONT	FB05-49-240	1		
	49 280B	PAD SET, FRONT CALIPER	8BF1-33-625	1		
		REFER TO WARR. CAMPAIGN NO. 26801 FOR RECALL INFO. ON CERTAIN 1986 & 1987 MODELS.				
		< AN >	FC02-33-28Z	1		
	49 290B	ATTACHMENT, PAD-FRONT	FB05-49-290B	1		

**SEE ILLUSTRATION/S AT FRAME 1 - 113**

(-7A27)



(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	5 HOLES-15"/16"
CONVERTIBLE	-	-	5 HOLES-15"

(7A27-)

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	5 HOLES-15"/16"
CONVERTIBLE	-	-	5 HOLES-15"


**FRONT AXLE & BRAKE MECHANISMS (FOR HARD  
SUSPENSION) (ANTI-LOCK BRAKE SYSTEM)**

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	26 043	WASHER, CLAW	1011-33-043	2		
	26 137	WASHER, PLAIN-LOWER ARM	FB01-26-137	4		
	33 020	KNUCKLE (R), STEERING	F051-33-021B	1		
	33 020Z	KNUCKLE (L), STEERING	F051-33-031B	1		
	33 042	NUT	0662-33-042	2		
	33 049	COVER, SET	0662-33-049	2		
	33 061	HUB, FRONT WHEEL	FB05-49-060E	2		
	33 062	BOLT, WHEEL	FB05-26-113A	10		
	33 065	SEAL, OIL-FRONT AXLE	FB01-33-065A	2		
	33 071	CAP, HUB	FB01-33-071A	2		
	33 251B	PLATE, HUB/DISK	FB05-33-251	2		
	33 261	COVER (R), DUST	FB05-33-260B	1		
	33 261Z	COVER (L), DUST	FB05-33-270B	1		
	33 471	ROTOR, SENSOR-FRONT A.B.S.	F048-33-471	2		
	33 651	PISTON, FRONT CALIPER	FB05-33-651	8		
	33 691	SCREW, BLEEDER	FB05-33-691A	2		
	33 693	CAP, RUBBER	FB05-33-693	2		
	33 696A	PIN, PAD-FRONT BRAKE	FB05-33-696	4		
	33 697	BOLT, BRIDGE-FRONT BRAKE	FB05-33-697	8		
	33 980	CALIPER (R), FRONT BRAKE REFER TO WARR. CAMPAIGN NO. 26801 FOR RECALL INFO. ON CERTAIN 1986 & 1987 MODELS.	FC02-33-980A	1		
	33 980Z	CALIPER (L), FRONT BRAKE REFER TO WARR. CAMPAIGN NO. 26801 FOR RECALL INFO. ON CERTAIN 1986 & 1987 MODELS.	FC02-33-990A	1		
	33 981A	WASHER, PLAIN-DUST COVER	FB01-33-981	8		
	49 240C	SEAL KIT, CALIPER-FRONT	FB05-49-240	1		
	49 280B	PAD SET, FRONT CALIPER REFER TO WARR. CAMPAIGN NO. 26801 FOR RECALL INFO. ON CERTAIN 1986 & 1987 MODELS.	8BF1-33-625	1		
			< AN >			
	49 290B	ATTACHMENT, PAD-FRONT	FC02-33-28Z FB05-49-290	1 1		

SEE ILLUSTRATION/S AT FRAME 1 - K13



FRONT SUSPENSION MECHANISMS (W/O TURBO)  
(W/O AUTOMATIC ADJUSTING SUSPENSION)




KNUCKLE, STEERING  
(REFER TO SECT. NO. J30U)

VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	
CONVERTIBLE	-	-	5 HOLES-15"

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
28 091		NUT	M266-28-091	4		7301-
34 011B		SPRING (R), COIL	FB67-34-011	1	NORMAL SUSPENSION, CONVERTIBLE	
			FB01-34-011B	1	NORMAL SUSPENSION COUPE	
			FB44-34-011	1	HARD SUSPENSION	
34 011X		SPRING (L), COIL	FB67-34-021	1	NORMAL SUSPENSION, CONVERTIBLE	
			FB01-34-021B	1	NORMAL SUSPENSION, COUPE	
			FB44-34-021	1	HARD SUSPENSION	
34 012		SHEET, RUBBER	FB01-34-012	2		
34 019		CAP, DAMPER	FB01-34-019	2		
34 091		NUT	B037-28-091	8		-7301
				4		7301-
34 098		BOLT	FB01-34-098	2		
34 099		BOLT	H001-33-302	4		-7301
			FB01-34-099A	4		7401-
34 10X		STOPPER, BUMP	FB01-34-312	2		-5801
34 111		BUMPER, BOUND	FB01-34-111A	2		
34 134A		BOLT, TENSION ROD	8871-33-134A	4		
34 160A		BRACKET, STABILIZER	FB01-34-160A	2		
34 201		BRACKET, LOWER ARM	FB01-34-201	2		
34 310		ARM (R), LOWER	FB01-34-310B	1		
34 310Z		ARM (L), LOWER	FB01-34-360B	1		
34 318		BOLT, FLANGE-STEERING KNUCKLE	M260-34-318	4		7301-
34 341		SHEET, SPRING	FB01-34-341	2		
34 390		RUBBER, MOUNTING	FB01-34-380	2		
			< A > FB01-34-380C	2		
34 460		BUSHING, RUBBER-LOWER ARM	FB01-34-460	2		
34 470		BUSHING, RUBBER FRONT	FB01-34-470	2		
34 550		BALL JOINT, LOWER	FB01-34-550	2		
34 910		DAMPER (R), FRONT	FB44-34-700C	1	NORMAL SUSPENSION, CONVERTIBLE	
			FB01-34-700C	1	NORMAL SUSPENSION COUPE	
			FB44-34-700C	1	HARD SUSPENSION	
34 910Z		DAMPER (L), FRONT	FB44-34-900C	1	NORMAL SUSPENSION CONVERTIBLE	
			FB01-34-900C	1	NORMAL SUSPENSION COUPE	
			FB43-34-900D	1	HARD SUSPENSION	
39 055		BOLT	9978-01-285	2		-6201

- 5801 FC33\* -113629
- 6201 FC33\* -129445
- 7301 FC33\* -537230
- 7401 FC33\* -543109

**FRONT SUSPENSION MECHANISMS (W/O TURBO)  
(FOR AUTOMATIC ADJUSTING SUSPENSION)**




VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A.A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	
CONVERTIBLE	-	-	5 HOLES-15"

ITEM NO.	D-CODE	DESCRIPTION	PART NO	QTY	MODEL/DESCRIPTION	REMARKS
	28 091	NUT	H266-28-091	4		7301-
	34 011B	SPRING (R), COIL	FB44-34-011	1	PINK MARK	
	34 011X	SPRING (L), COIL	FB44-34-021	1	GRAY MARK	
	34 012	SHEET, RUBBER	FB01-34-012	2		
	34 080	ACTUATOR	FB07-34-080A	2		
	34 088	PLATE SET	H126-34-088A	2		
	34 089A	NUT	G054-34-089A	2		
	34 091	NUT	B001-34-091	8		-7301
				4		7301-
	34 098	BOLT	FB01-34-098	2		
	34 099	BOLT	H001-33-302	4		-7301
			FB01-34-099A	4		
	34 10X	STOPPER, BUMP	FB01-34-312	2	W/O A.B.S.	-5801
	34 111	BUMPER, BOUND	FB01-34-111A	2		
	34 134A	BOLT, TENSION ROD	B871-34-134A	4		
	34 160A	BRACKET, STABILIZER	FB01-34-160A	2		
	34 201	BRACKET, LOWER ARM	FB01-34-201	2		
	34 310	ARM (R), LOWER	FB01-34-310B	1		
	34 310Z	ARM (L), LOWER	FB01-34-360B	1		
	34 318	BOLT, FLANGE-STEERING KNUCKLE	H260-34-318	4		7301-
	34 341	SHEET, SPRING	FB01-34-341	2		
	34 390	RUBBER, MOUNTING	FB01-34-380	2		-6A01
			< A > FB01-34-380C	2		6513-
	34 460	BUSHING, RUBBER-LOWER ARM	FB01-34-460	2		
	34 470	BUSHING, RUBBER-FRONT	FB01-34-470	2		
	34 550	BALL JOINT, LOWER	FB01-34-550	2		
	34 910	DAMPER (R), FRONT	FB52-34-700A	1		
	34 910Z	DAMPER (L), FRONT	FB52-34-900A	1		
	39 055	BOLT	B092-39-055	2		-6201

5801	FC33*	-113629
6201	FC33*	-129445
6513	FC33*	-147766
6A01	FC33*	-517640
7301	FC33*	-537230

# SECTION INDEX -- CHASSIS


STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME
1 - C11	2500	DRIVESHAFT	1 - L14	4000B	EXHAUST SYSTEM (W/O TURBO)			
1 - D11	2550	REAR DRIVESHAFTS						
1 - E11	2600	REAR AXLE						
1 - F11	2610	REAR BRAKE MECHANISMS	1 - C15	4000BA	EXHAUST SYSTEM (TURBO)			
1 - H11	2710	REAR DIFFERENTIALS (W/O TURBO)(NORMAL DIFFERENTIAL)	1 - F15	4140B	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)			
1 - J11	2710A	REAR DIFFERENTIALS (W/O TURBO)(LIMITED-SLIP DIFFERENTIAL)	1 - F15	4160	ACCELERATOR CONTROL SYSTEM			
1 - L11	2710C	REAR DIFFERENTIALS (TURBO)(LIMITED-SLIP DIFFERENTIAL)	1 - G15	4200	FUEL TANK			
1 - N11	2600	REAR SUSPENSION MECHANISMS (W/O TURBO) (W/O AUTOMATIC ADJUSTING SUSPENSION)	1 - H15	4300	CLUTCH & BRAKE PEDALS			
1 - C12	2800A	REAR SUSPENSION MECHANISMS (W/O TURBO) (FOR AUTOMATIC ADJUSTING SUSPENSION)	1 - J15	4340	BRAKE MASTER CYLINDER & POWER BRAKE (W/O ANTI-LOCK BRAKE SYSTEM)			
1 - D12	2800B	REAR SUSPENSION MECHANISMS (TURBO)	1 - L15	4340A	BRAKE MASTER CYLINDER & POWER BRAKE (ANTI-LOCK BRAKE SYSTEM)			
1 - F12	2810	REAR STABILIZER	1 - N15	4360	BRAKE PIPINGS (W/O ANTI-LOCK BRAKE SYSTEM)			
1 - F12	2830	REAR LOWER ARMS & SUB-FRAME	1 - C16	4360A	BRAKE PIPINGS (ANTI-LOCK BRAKE SYSTEM)			
1 - H12	3200	STEERING WHEEL	1 - D16	4370	ANTI-LOCK BRAKE SYSTEMS			
1 - I12	3210	STEERING COLUMN & SHAFTS	1 - F16	4400	PARKING BRAKE SYSTEM			
1 - J12	3210A	STEERING COLUMN & SHAFTS (W/ POWER STEERING)	1 - G16	4500B	FUEL PIPINGS (W/O ANTI-LOCK BRAKE SYSTEM)			
1 - K12	3220	STEERING GEAR (W/O POWER STEERING)	1 - H16	4500BA	FUEL PIPINGS (ANTI-LOCK BRAKE SYSTEM)			
1 - L12	3220A	STEERING GEAR (W/ POWER STEERING)	1 - I16	4600	CHANGE CONTROL SYSTEM (AUTOMATIC TRANSMISSION)			
1 - M12	3230	STEERING LINKAGE SYSTEM						
1 - C13	3240	POWER STEERING SYSTEM						
1 - E13	3300	FRONT AXLE & BRAKE MECHANISMS (FOR NORMAL SUSPENSION)						
1 - I13	3300A	FRONT AXLE & BRAKE MECHANISMS (FOR HARD SUSPENSION) (W/O ANTI-LOCK BRAKE SYSTEM)						
1 - K13	3300B	FRONT AXLE & BRAKE MECHANISMS (FOR HARD SUSPENSION) (ANTI-LOCK BRAKE SYSTEM)						
1 - M13	3400	FRONT SUSPENSION MECHANISMS (W/O TURBO) (W/O AUTOMATIC ADJUSTING SUSPENSION)						
1 - N13	3400A	FRONT SUSPENSION MECHANISMS (W/O TURBO) (FOR AUTOMATIC ADJUSTING SUSPENSION)						
1 - C14	3400B	FRONT SUSPENSION MECHANISMS (TURBO)						
1 - D14	3410	CROSSMEMBER & STABILIZER						
1 - E14	3700	TIRES & JACK (W/O TURBO)						
1 - H14	3700A	TIRES & JACK (TURBO)						
1 - J14	3900B	ENGINE & TRANSMISSION MOUNTINGS (W/O TURBO)						
1 - K14	3900BA	ENGINE & TRANSMISSION MOUNTINGS (TURBO)						



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	
CONVERTIBLE	-	-	5 HOLES-15"

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
28 091		NUT	H266-28-091	4		7301-
34 011B		SPRING (R), COIL	FB44-34-011	1	PINK MARK	
34 011X		SPRING (L), COIL	FB44-34-021	1	GRAY MARK	
34 012		SHEET, RUBBER	FB01-34-012	2		
34 019		CAP, DAMPER	FB01-34-019	2		
34 091		NUT	B001-34-091	8		-7301
				4		7301-
34 098		BOLT	FB01-34-098	2		
34 099		BOLT	H001-33-302	4		-7301
			FB01-34-099A	4		
34 111		BUMPER, BOUND	FB01-34-111A	2		
34 134A		BOLT, TENSION ROD	8871-34-134A	4		
34 160A		BRACKET, STABILIZER	FB01-34-160A	2		
34 201		BRACKET, LOWER ARM	FC01-34-201	2		
34 310		ARM (R), LOWER	FB01-34-310B	1		
34 310Z		ARM (L), LOWER	FB01-34-360B	1		
34 318		BOLT, FLANG-STEERING KNUCKLE	H260-34-318	4		7301-
34 341		SHEET, SPRING	FB01-34-341	2		
34 390		RUBBER, MOUNTING	FB01-34-380	2		-6513
			< A > FB01-34-380C	2		6513-
34 460		BUSHING, RUBBER-LOWER ARM	FB01-34-460	2		
34 470		BUSHING, RUBBER-FRONT	FB01-34-470	2		
34 550		BALL JOINT, LOWER	FB01-34-550	2		
34 910		DAMPER (R), FRONT	FB44-34-700C	1		
34 910Z		DAMPER (L), FRONT	FB44-34-900C	1		

6513 FC33\* -147766  
7301 FC33\* -537230




VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	
CONVERTIBLE	-	-	5 HOLES-15"

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTIONS	REMARKS
34 091		NUT	FB01-34-091	4		5906-
34 151		STABILIZER, FRONT	FB01-34-151C	1	NORMAL SUSPENSION COUPE	
			FB43-34-151C	1	HARD SUSPENSION	
34 155		PLATE, STABILIZER	FB01-34-155	2		
34 156A		RUBBER, STABILIZER-FRONT	FB02-34-156A	2	NORMAL SUSPENSION COUPE	
			FB43-34-156I	2	HARD SUSPENSION	
34 170A		LINK, CONTROL-STABILIZER	FB01-34-170A	2		
34 800		MEMBER, CROSS	FB67-34-800C	1	NORMAL SUSPENSION CONVERTIBLE	
			FB01-34-800G	1		
39 036		WASHER	B001-39-036	4		-5906
39 037		NUT	B001-39-037B	4		-5906

5906 FC33\* -103042


**3700-1 TIRES & JACK (W/O TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
26 161A		NUT, HUB	8002-37-160	16	PLATED, FOR 4-HOLE DISC WHEEL	
			0603-26-161	20	PLATED, FOR 5-HOLE DISC WHEEL	.8201
				20	NON-BRIGHT, FOR 5-HOLE DISC WHEEL	8201-
37 190		CAP, CENTER	FB02-37-190A	4	COUPE	
			FB68-37-190	4	CONV.	
37 192B		EMBLEM, CENTER	FB05-37-192	4	COUPE, NORM SUSP.	7101-7401
			F055-37-192	4	COUPE, NORM SUSP.	7101-7401
			FB01-37-192B	4	FOR 6JJ X 15 & 7JJ X 16 ALUM.	-7101
			F057-37-192	4	FOR 6JJ X 15 & 7JJ X 16 ALUM.	7101-
				4	COUPE, HARD SUSP.	
				4	COUPE, NORM SUSP.	7401-
37 600		WHEEL, DISC-STEEL	9965-09-406	1	4T X 16, TEMP. COUPE, HARD SUSP.	
			9965-10-406	1	4T X 16, TEMP. CONV.	
			9965-69-554	1	5.5JJ X 14, 4-HOLE STEEL BASE, COUPE, NORM. SUSP.	
			9965-16-405	1	4T X 15, TEMP. BASE, SE, LX	7601-
37 600A		TIRE	0000-78-559	1	T135/70D15, TEMP. COUPE, NORM SUSP.	
		REFER TO ACC. BULL. NO. XE-1 FOR MORE INFO.	0000-78-5755	1	T135/70D15, TEMP. CONV., COUPE, HARD SUSP.	
			0000-78-202	4	205/60VR15 CONV., COUPE, HARD SUSP.	
			0000-78-850	4	185/70HR14 COUPE	
37 600C		VALVE, AIR	9963-60-111	4	CONV.	
			9963-60-413	4	COUPE	
37 600E		WEIGHT, DISC WHEEL-STEEL	9965-53-0005	4	5G	
			9965-53-0010	4	10G	
			9965-53-0015	4	15G	
			9965-53-0020	4	20G	
			9965-53-0025	4	25G	
			9965-53-0030	4	30G	
			9965-53-0035	4	35G	


7101 FC33\* -528625  
 7401 FC33\* -543109  
 7601 FC33\* -550168  
 8201 FC351 -102771

**3700-2 TIRES & JACK (W/O TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS		
37 600K	WEIGHT, DISC WHEEL-ALUM.		9965-53-0040	4	40G			
			9965-53-0045	4	45G			
			9965-53-0050	4	50G			
			9965-53-0055	4	55G			
			9965-53-0060	4	60G			
			9965-59-0005	4	5G FOR 1-PIECE WHL.			
			9965-59-0010	4	10G FOR 1-PIECE WHL.			
			9965-59-0015	4	15G FOR 1-PIECE WHL.			
			9965-59-0020	4	20G FOR 1-PIECE WHL.			
			9965-59-0025	4	25G FOR 1-PIECE WHL.			
			9965-59-0030	4	30G FOR 1-PIECE WHL.			
			9965-59-0035	4	35G FOR 1-PIECE WHL.			
			9965-59-0040	4	40G FOR 1-PIECE WHL.			
			9965-59-0045	4	45G FOR 1-PIECE WHL.			
			9965-59-0050	4	50G FOR 1-PIECE WHL.			
			9965-59-0055	4	55G FOR 1-PIECE WHL.			
			9965-59-0060	4	60G FOR 1-PIECE WHL.			
		37 600S	WHEEL SET, DISC-ALUM.		9965-61-0005	4	5G FOR 2-PIECE WHL.	
					9965-61-0010	4	10G FOR 2-PIECE WHL.	
					9965-61-0015	4	15G FOR 2-PIECE WHL.	
	9965-61-0020			4	20G FOR 2-PIECE WHL.			
	9965-61-0025			4	25G FOR 2-PIECE WHL.			
	9965-61-0030			4	30G FOR 2-PIECE WHL.			
	9965-61-0035			4	35G FOR 2-PIECE WHL.			
	9965-61-0040			4	40G FOR 2-PIECE WHL.			
	9965-61-0045			4	45G FOR 2-PIECE WHL.			
	9965-61-0050			4	50G FOR 2-PIECE WHL.			
	9965-61-0055			4	55G FOR 2-PIECE WHL.			
	9965-61-0060			4	60G FOR 2-PIECE WHL.			
6701	FC33*	-500010						
7101	FC33*	-528625						

# 3700-3 TIRES & JACK (W/O TURBO)




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
37 600T		WHEEL SET (R), DISC.-ALUM.  REFER TO PARTS BULL. NO. T-2-1 FOR MORE WHEEL INFO.	8BF2-37-192	2	6JJ X 15, 5-HOLE PEWTER HARD SUSP.-SPORT, GTU, GXI	-6701
			8BF5-37-600	2	6JJ X 15, 5-HOLE BRIGHT HARD SUSP.-SPORT, GTU, GXI	6701-7101
			8BF9-37-600	2	6JJ X 15, 5-HOLE POLISHED HARD SUSP.-SPORT, GTU, GXI	7101-
37 600U		WHEEL SET (L), DISC.-ALUM.  REFER TO PARTS BULL. NO. T-2-1 FOR MORE WHEEL INFO.	8BF6-37-192	2	6JJ X 15, 5-HOLE PEWTER HARD SUSP.-SPORT, GTU, GXI	-6701
			8BF4-37-600	2	6JJ X 15, 5-HOLE BRIGHT HARD SUSP.-SPORT, GTU, GXI	6701-7101
			8BFA-37-600	2	6JJ X 15, 5-HOLE POLISHED HARD SUSP.-SPORT, GTU, GXI	7101-
37 600Z		WHEEL, DISC.-ALUM.	9965-09-405	1	4T X 15, TEMP. COUPE, NORM SUSP.	-7601
52 398		PAD, TANK PROTECTOR	0566-52-398A	1		
56 170A		BOLT, JACK SET	FB01-56-177	1		
56 172		WELT, SEAMING-JACK	1901-56-172A	1		
56 176		HOLDER, JACK HANDLE	FE0.-56-176	1		
56 210B		CLAMP, SPARE TIRE	FG67-56-960A	1	L=110MM, CONV.	
			FB67-56-971	1	CONV.	8A25-
			FB01-56-971	1	COUPE	
			FB02-56-961A	1	L-159MM NORM. SUSP.-BASE, SE, LX	
			FB01-56-961B	1	L-165MM HARD SUSP.-SPORT, GTU, GXI	
68 071		WRENCH, WHEEL CAP	F057-68-071	1	CONV.	
68 800A		JACK	FB07-37-790A	1		
68 810A		HANDLE, JACK	FB01-37-810	1		

6701 FC33\* -500010  
 7101 FC33\* -528625  
 7601 FC33\* -550168  
 8A25 FC351 -108679




# 3700A-1 TIRES & JACK (TURBO)



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
26	161A	NUT, HUB	B002-37-160	20	PLATED	
37	192B	EMBLEM, CENTER	FB79-37-192	4	FOR 7JJ X 16, ALUM. WHITE 10TH ANNIV. ED.	
			FB01-37-192B	4	FOR 6JJ X 15 & 7JJ X 16 ALUM.	-7101
			F055-37-192	4	FOR 6JJ X 15 & 7JJ X 16 ALUM.	7101-
37	600A	TIRE REFER TO ACC. BULL. NO. XE-1 FOR MORE INFO.	0000-78-5755	1	T135/70D16, TEMP.	
			0000-78-0208	4	205/55VR16	
37	600C	VALVE, AIR	9963-60-413	4		
37	600K	WEIGHT, DISC WHEEL-ALUM.	9965-59-0005	4	5G FOR 1-PIECE WHL.	
			9965-59-0010	4	10G FOR 1-PIECE WHL.	
			9965-59-0015	4	15G FOR 1-PIECE WHL.	
			9965-59-0020	4	20G FOR 1-PIECE WHL.	
			9965-59-0025	4	25G FOR 1-PIECE WHL.	
			9965-59-0030	4	30G FOR 1-PIECE WHL.	
			9965-59-0035	4	35G FOR 1-PIECE WHL.	
			9965-59-0040	4	40G FOR 1-PIECE WHL.	
			9965-59-0045	4	45G FOR 1-PIECE WHL.	
			9965-59-0050	4	50G FOR 1-PIECE WHL.	
			9965-59-0055	4	55G FOR 1-PIECE WHL.	
			9965-59-0060	4	60G FOR 1-PIECE WHL.	
37	600T	WHEEL SET (R), DISC-ALUM.  REFER TO PARTS BULL. NO. T-2-1 FOR MORE WHEEL INFO.	8BFH-37-600	2	7JJ X 16, 10TH ANNIV. ED.	
			8BF6-37-192	2	7JJ X 16, PEWTER	-6701
			8BF3-37-600	2	7JJ X 16, BRIGHT	6701-7101
			8BFB-37-600	2	7JJ X 16, POLISHED	7101-7701
			8BFD-37-600	2	7JJ X 16, POLISHED	7701-
37	600U	WHEEL SET (L), DISC-ALUM.  REFER TO PARTS BULL. NO. T-2-1 FOR MORE WHEEL INFO.	8BFJ-37-600	2	7JJ X 16, 10TH ANNIV. ED.	
			8BF7-37-192	2	7JJ X 16, PEWTER	-6701
			8BF2-37-600	2	7JJ X 16, BRIGHT	6701-7101
			8BFC-37-600	2	7JJ X 16, POLISHED	7101-7701
			8BFE-37-600	2	7JJ X 16, POLISHED	7701-
37	600Z	WHEEL, DISC-ALUM.	9965-10-406	1	4T X 16, TEMP.	
52	398	PAD, TANK PROTECTOR	0866-52-398A	1		
56	170A	BOLT, JACK SET	FB01-56-177	1		


6701 FC33\* -500010  
 7101 FC33\* -528625  
 7701 FC33\* -550169

**3700A-2 TIRES & JACK (TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
56 172		WELT, SEAMING-JACK	FB01-56-172A	1		
56 176		HOLDER, JACK HANDLE	FB01-56-176	2		
56 210B		CLAMP, SPARE TIRE	FB01-56-971	1	10TH ANNIV. ED.	
			FB03-56-961B	1	L=178MM	
68 800A		JACK	FB07-37-790A	1		
68 810A		HANDLE, JACK	FB01-37-810	1		


# 3900B-1 ENGINE & TRANSMISSION MOUNTINGS (W/O TURBO)



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
26 137		WASHER, PLAIN-LOWER ARM	FB01-26-137	3		
28 333A		NUT, FLANGE	H001-28-333	2	M/T	7301-
39 020A		BRACKET (R), ENGINE	FB01-39-021A	1		
39 030A		BRACKET (L), ENGINE	FB01-39-031	1		
39 035A		BOLT	FB01-39-022	3		
39 040A		RUBBER, ENGINE MOUNTING	FB67-39-040A	2	CONVERTIBLE	
			FB01-39-040A	2	COUPE	
39 045		CASING, STOPPER	3975-39-045	2		
39 340		RUBBER, TRANSMISSION MOUNTING	FB01-39-340A	2	COUPE, M/T	
			FB67-39-340A	2	CONVERTIBLE	
39 349C		WEIGHT, TRANSMISSION BRACKET	FB01-39-349	2	M/T	-7301
39 364		WASHER	FB01-39-364	1		
39 380		MEMBER, TRANSMISSION MOUNTING	FB01-39-370D	1	M/T	
			FB02-39-370C	1	A/T	
39 410		BRACKET, TRANSMISSION MOUNTING	FB01-39-350A	1	M/T	
			FB02-39-350A	1	A/T	
39 811		INSULATOR	FB01-39-385	1	M/T	
56 414A		BOLT, SILENCER	FB01-56-416	3	M/T	

7301 FC33\* -537230


# 3900BA-1 ENGINE & TRANSMISSION MOUNTINGS (TURBO)



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
26 137		WASHER, PLAIN-LOWER ARM	FB01-26-137	3		
28 333A		NUT, FLANGE	H001-28-333	2		7301-
39 020A		BRACKET (R), ENGINE	FB01-39-021A	1		
39 030A		BRACKET (L), ENGINE	FB01-39-031	1		
39 035A		BOLT	FB01-39-022	3		
39 040A		RUBBER, ENGINE MOUNTING	FB01-39-040A	2		
39 045		CASING, STOPPER	3975-39-045	2		
39 340		RUBBER, TRANSMISSION MOUNTING	FB01-39-340A	2		
39 349C		WEIGHT, TRANSMISSION BRACKET	FB01-39-349	2		-7301
39 364		WASHER	FB01-39-364	1		
39 380		MEMBER, TRANSMISSION	F044-39-370D	1		
39 410		BRACKET, TRANSMISSION MOUNTING	FB01-39-350A	1		
39 811		INSULATOR	FB01-39-385	1		
56 414A		BOLT, SILENCER	FB01-56-416	3		

7301 FC33\* -537230


**4000B-1 EXHAUST SYSTEM (W/O TURBO)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	13 815D	PROTECTOR, AIR HOSE	N326-13-815	1		6101-
	20 305	GASKET, EXHAUST PIPE-CONVERTER	N326-40-305	4		
	20 500A	CONVERTER, MONOLITH	N327-20-500	1	A/T	
	40 060A	HANGER, SILENCER	N326-40-060B	2		
	40 061	HANGER, SILENCER	N328-40-060	2		
	40 061B	RUBBER, HANGER	N225-40-061	6		
	40 065A	RUBBER, STOPPER	N326-40-065	2		SC01-
	40 073	SPACER	N304-40-073A	3	A/T	
				4	M/T	
	40 078	GASKET	N304-40-078A	3		
	40 081	BRACKET	N326-40-080	1	M/T	
			N327-40-080	1	A/T	
	40 100A	SILENCER (R), MAIN	N338-40-100B	1	CONVERTIBLE	
			N326-40-100L	1	COUPE	
	40 110A	PIPE, MIDDLE	N319-40-600B	1	CONVERTIBLE	
			N326-40-600E	1	COUPE	
	40 160	HANGER, SILENCER	N304-40-161A	1	A/T	
			1114-40-160	1	M/T	
	40 166	WASHER	0820-40-166	5	A/T	
				6	M/T	
	40 200C	SILENCER (L), MAIN	N338-40-200A	1	CONVERTIBLE	
			< AN > N338-40-200B	1		
			N326-40-200J	1	COUPE	
	40 220	BRACKET, HANGER	N326-40-69XB	1		
	40 230	BRACKET, HANGER	N326-40-690B	1		
	40 305	GASKET	N327-40-305	2		
	40 355A	NUT	8118-40-355	8		
	40 357D	WASHER	N326-40-357	2		
	40 375	GASKET	1480-40-375	1		
	40 4001	CONVERTER, MONOLITH	N326-20-600A	1		
	40 400A	CONVERTER NO. 2, PRE	N326-20-550	1		
	40 401	INSULATOR	0820-40-165	2		
	40 54X	BRACKET, HANGER-MONOLITHIC CONVERTER	N326-40-54X	1	M/T	
			N327-40-54X	1	A/T	
	40 650	BRACKET, HANGER	N326-40-640	2		
	40 720	PIPE, AIR	N338-20-840	1	CONVERTIBLE	
			N326-20-840B	1	COUPE	
	40 728	HOSE, AIR	N326-20-750	1		
	40 780A	CONVERTER NO. 1, PRE	N326-20-500A	1	M/T	

SC01 FC33\* -118628  
6101 FC33\* -124137

**4000B-2 EXHAUST SYSTEM  
(W/O TURBO)**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
40 815A		WASHER	1480-40-815	2		
40 815E		PROTECTOR, HANGER BRACKET	N326-40-815	1	M/T	
40 820		PROTECTOR NO. 2	N326-40-874B	1		
40 844		PROTECTOR, MIDDLE PIPE-LOW	N326-40-844	2		.7401
40 860		PROTECTOR, CONVERTER	N326-40-861A	1		
40 862		PROTECTOR, CONVERTER	N326-40-870A	1		
40 981A		GARNISH, TAIL PIPE	N326-40-990A	2		.6701
			N326-40-990C	2		6701-

6701 FC33\* -500010  
7401 FC33\* -543109

# SECTION INDEX -- CHASSIS

STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME
1 - C11	2500	DRIVESHAFT	1 - L14	4000B	EXHAUST SYSTEM (W/O TURBO)			
1 - D11	2550	REAR DRIVESHAFTS						
1 - E11	2600	REAR AXLE	1 - C15	4000BA	EXHAUST SYSTEM (TURBO)			
1 - F11	2610	REAR BRAKE MECHANISMS	1 - E15	4140B	CLUTCH; RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)			
1 - H11	2710	REAR DIFFERENTIALS (W/O TURBO)(NORMAL DIFFERENTIAL)	1 - F15	4160	ACCELERATOR CONTROL SYSTEM			
1 - J11	2710A	REAR DIFFERENTIALS (W/O TURBO)(LIMITED-SLIP DIFFERENTIAL)	1 - G15	4200	FUEL TANK			
1 - L11	2710C	REAR DIFFERENTIALS (TURBO)(LIMITED-SLIP DIFFERENTIAL)	1 - H15	4300	CLUTCH & BRAKE PEDALS			
1 - N11	2800	REAR SUSPENSION MECHANISMS (W/O TURBO) (W/O AUTOMATIC ADJUSTING SUSPENSION)	1 - J15	4340	BRAKE MASTER CYLINDER & POWER BRAKE (W/O ANTI-LOCK BRAKE SYSTEM)			
1 - C12	2800A	REAR SUSPENSION MECHANISMS (W/O TURBO) (FOR AUTOMATIC ADJUSTING SUSPENSION)	1 - L15	4340A	BRAKE MASTER CYLINDER & POWER BRAKE (ANTI-LOCK BRAKE SYSTEM)			
1 - D12	2800B	REAR SUSPENSION MECHANISMS (TURBO)	1 - N15	4360	BRAKE PIPINGS (W/O ANTI-LOCK BRAKE SYSTEM)			
1 - E12	2810	REAR STABILIZER						
1 - F12	2830	REAR LOWER ARMS & SUB-FRAME	1 - C16	4360A	BRAKE PIPINGS (ANTI-LOCK BRAKE SYSTEM)			
1 - H12	3200	STEERING WHEEL	1 - D16	4370	ANTI-LOCK BRAKE SYSTEMS			
1 - I12	3210	STEERING COLUMN & SHAFTS	1 - F16	4400	PARKING BRAKE SYSTEM			
1 - J12	3210A	STEERING COLUMN & SHAFTS (W POWER STEERING)	1 - G16	4500B	FUEL PIPINGS (W/O ANTI-LOCK BRAKE SYSTEM)			
1 - K12	3220	STEERING GEAR (W/O POWER STEERING)	1 - H16	4500BA	FUEL PIPINGS (ANTI-LOCK BRAKE SYSTEM)			
1 - L12	3220A	STEERING GEAR (W POWER STEERING)	1 - I16	4600	CHANGE CONTROL SYSTEM (AUTOMATIC TRANSMISSION)			
1 - M12	3230	STEERING LINKAGE SYSTEM						
1 - C13	3240	POWER STEERING SYSTEM						
1 - E13	3300	FRONT AXLE & BRAKE MECHANISMS (FOR NORMAL SUSPENSION)						
1 - I13	3300A	FRONT AXLE & BRAKE MECHANISMS (FOR HARD SUSPENSION) (W/O ANTI-LOCK BRAKE SYSTEM)						
1 - K13	3300B	FRONT AXLE & BRAKE MECHANISMS (FOR HARD SUSPENSION) (ANTI-LOCK BRAKE SYSTEM)						
1 - M13	3400	FRONT SUSPENSION MECHANISMS (W/O TURBO) (W/O AUTOMATIC ADJUSTING SUSPENSION)						
1 - N13	3400A	FRONT SUSPENSION MECHANISMS (W/O TURBO) (FOR AUTOMATIC ADJUSTING SUSPENSION)						
1 - C14	3400B	FRONT SUSPENSION MECHANISMS (TURBO)						
1 - D14	3410	CROSSMEMBER & STABILIZER						
1 - E14	3700	TIRES & JACK (W/O TURBO)						
1 - H14	3700A	TIRES & JACK (TURBO)						
1 - J14	3900B	ENGINE & TRANSMISSION MOUNTINGS (W/O TURBO)						
1 - K14	3900BA	ENGINE & TRANSMISSION MOUNTINGS (TURBO)						

# 4000BA-1 EXHAUST SYSTEM (TURBO)





ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	13 453B	STUD	N326-40-353	2		
	13 483	GASKET, EXHAUST PIPE	N318-13-491A	1		
	13 761	GASKET	N318-13-164A	1		
	20 305	GASKET, EXHAUST PIPE-CONVERTER	N326-40-305	3		
	20 500A	CONVERTER, MONOLITH	N332-20-500	1		
	20 523	WASHER, PLAIN	E508-20-523	3		-6401
	20 548A	WASHER, LOCK	N319-13-457B	2		
	40 050A	PIPE, EXHAUST-FRONT	N332-40-500A	1		
	40 060A	HANGER, SILENCER	N326-40-060	2		
	40 061	HANGER, SILENCER	N328-40-060B	2		
	40 061B	RUBBER, HANGER	N225-40-061	6		
	40 065A	RUBBER, STOPPER	N326-40-065	2		
	40 073	SPACER	N304-40-073A	4		
	40 078	GASKET	N304-40-078A	3		
	40 081	BRACKET	N326-40-080	1		
	40 100A	SILENCER (R), MAIN	N332-40-100D	1		-7701
			N332-40-100E	1		7701-
	40 110A	PIPE, MIDDLE	N326-40-600E	1		
			N319-40-600B	1		
	40 160	HANGER, SILENCER	1114-40-161	1		
	40 166	WASHER	0820-40-166	6		
	40 200C	SILENCER (L), MAIN	N332-40-200E	1		
			N332-40-200F	1		
	40 220	BRACKET, HANGER	N326-40-69XB	1		
	40 230	BRACKET, HANGER	N326-40-690B	1		
	40 305	GASKET	N327-40-305	2		
	40 355A	NUT	8118-40-355	6		
			8134-40-355	3		
	40 375	GASKET	1480-40-375	1		
	40 4001	CONVERTER, MONOLITH	N332-20-500	1		
	40 401	INSULATOR	0820-40-165	2		
	40 54X	BRACKET, HANGER-MONOLITH CONVERTER	N326-40-54X	1		
	40 650	BRACKET, HANGER	N326-40-640	2		
	40 720	PIPE, AIR	N332-20-840A	1		
	40 720B	PIPE, AIR	N332-20-850A	1		
	40 728	HOSE, AIR	N332-13-814A	1		
	40 811	PROTECTOR, FRONT PIPE	N332-40-823A	1		
	40 815A	WASHER	1480-40-815	2		
	40 815E	PROTECTOR, HANGER BRACKET	N326-40-815	1		
	40 844	PROTECTOR, MIDDLE PIPE-LOWER	N326-40-844	2		-7401
6401	FC33*	-140158				
7401	FC33*	-543109				
7701	FC33*	-550169				






**CLUTCH RELEASE & MASTER CYLINDERS  
(MANUAL TRANSMISSION)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
17 341J		BALL, STEEL	.961-11-500	1		
33 691		SCREW, BLEEDER	0259-33-691	1		
33 693A		CAP, BLEEDER SCREW	0259-33-693	1		
41 341		ROD, PUSH	H005-41-341	1		
41 360		HOLDER, CLUTCH	8871-41-370	1	W/O TURBO	
			F044-41-370A	1	TURBO	
41 380		HOSE, FLEXIBLE	FB01-41-380	1	W/O TURBO	
			F044-41-380B	1	TURBO	
41 412		BOLT, JOINT	W001-41-412	1		
41 424		SPRING, O.W. VALVE	H005-41-424	1		
41 470		SPRING	GA02-41-470	1		
41 551S		TANK SET, RESERVE	H115-49-570B	1		
41 552S		CAP SET, RESERVE TANK	B093-49-580	1		
41 920		CYLINDER, CLUTCH RELEASE	FB01-41-920A	1	W/O TURBO	
			F044-41-920C	1	TURBO	
41 990		CYLINDER, CLUTCH MASTER	FB01-41-400C	1		
43 552S		CAP SET, RESEKVE TANK	B093-49-580	1		6A01-
43 635A		CLIP, FLEXIBLE HOSE	0136-43-635	1		
45 510		PIPE, CLUTCH	FB01-45-510A	1	W/O TURBO	
			FB44-45-510	1	TURBO	
49 460		PARTS KIT, INNER	FB01-49-460	1		
49 470		SEAL KIT	FB01-49-470	1		
49 520		PARTS KIT, INNER	FB01-49-520A	1		
49 530		SEAL KIT	FB01-49-530A	1		
49 686B		BUSHING, ELBOW JOINT	0305-49-686B	1		

6A01 FC33\* -517640


**4160-1 ACCELERATOR CONTROL SYSTEM**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
18 660		SWITCH, KICK DOWN	F034-66-470	1	M/T, W/ A.A.S. A/T	
41 610B		PEDAL & ARM	FB01-11-610	1		
41 619		SPRING, RETURN	8239-41-619	1		
41 644		BUSHING	B092-41-644	2		
41 650E		RETAINER, ACCELERATOR ROD	FB01-41-650	1		.7401
			FB01-41-650A	1		7401-
41 660		CABLE, ACCELERATOR	FB01-41-660D	1	W/O TURBO	
			FB44-41-660C	1	TURBO	
41 682		RUBBER, STOP	B001-41-652	1		.7401
41 711A		PAD, ACCELERATOR PEDAL	FA54-41-711A	1		
43 029		RUBBER, STOPPER	B001-43-029	1		7401-
60 071C		CLIP	UB40-60-071	1	TURBO	

7401 FC33\* -543109

**4200-1 FUEL TANK**




93-5106		99351-06999	L=130MM
		99351-06999	L=510MM

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
42 046		PLUG, DRAIN	BC88-42-045	1		
42 110		TANK, FUEL	FB01-42-110D	1		
42 210		PIPE, FILLER	FB01-42-210	1		-5910
			FB01-42-210A	1		5910-6501
			FB01-42-210B	1	REQUIRES FB01-42-245A	6501-
42 240A		HOSE, JOINT-FILLER PIPE	FB01-42-240E	1		
42 241		GASKET, FILLER PIPE	0866-42-366B	1		
42 247		HOSE, JOINT-FUEL TANK SIDE	FB01-42-247A	1		
42 250		CAP, FILLER	FC01-42-250	1		
42 280		VALVE, NON-RETURN	GB53-42-270	1		
42 285		REINFORCEMENT, JOINT HOSE-FUEL	FB01-42-285	1		
42 289		WIRE, EARTH-FILLER PIPE	FB01-42-289	1		
42 290		PIPE, FILLER NO. 2	FB01-42-290	1		
42 408		STOPPER, FILLER LID	VA64-42-459	1		
42 410		LID, FUEL FILLER	FB01-42-410B	1		
42 410C		BAND (R), TANK FIXTURE	FB01-42-710	1		-6901
			FB01-42-710A	1		6901-
42 413		SHEET	FB01-42-715	2		
42 420A		BAND (L), TANK FIXTURE	FB01-42-720	1		-6901
			FB01-42-720A	1		6901-
42 438		SPRING, LIFT	FB01-42-451C	1		
42 480		OPENER, FILLER LID	G030-56-890B	1		-6101
			FB01-56-890	1		6101-
42 523		PAD, FUEL TANK	8531-42-762A	1		
42 531		PIPE, EVAPORATION	FB01-42-531B	1		
42 561B		HOSE, EVAPORATION	FB01-42-561A	1		
42 565		PLUG, DRAIN-VENTILATION HOSE	FB01-42-565	1		
42 571		HOSE, VENT	FB01-42-562	1		
42 581		HOSE, BREATHER	FB01-42-245	1		-6501
			FB01-42-245A	1		6501-
42 582		HOSE, BREATHER	FB01-42-248	1		
42 710		VALVE, CHECK	FB01-42-910	1		
42 720		VALVE-FUEL VAPOR	FB01-42-980	1		
42 780A		SCREW 'A', FIXING BAND	H260-42-780	2		6901-
42 790		SCREW 'B', FIXING BAND	H260-42-790	2		6901-
42 901A		INSULATOR	FB01-42-761	3		
42 985		GASKET, VAPOR VALVE	FB01-42-985	1		
60 960A		GAUGE, FUEL TANK	FB01-60-960B	1		
93 5106		HOSE	9935-10-6999	2		

- 5910 FC33\* -103555
- 6101 FC33\* -124137
- 6501 FC33\* -146093
- 6901 FC33\* -512255


# 4300-1 CLUTCH & BRAKE PEDALS



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
18 660B		SWITCH, CLUTCH	H005-66-190A	1	M/T	
41 023A		BUSHING	0727-41-023	1	M/T	
41 030		PEDAL, CLUTCH	FB01-41-031C	1	M/T	
41 040		SHEET, SPRING	W090-41-040	1	M/T	
41 043		SHEET, SPRING	0183-41-043	1	M/T	
41 051		ROD, CLUTCH PEDAL	0824-41-051A	1	M/T	
41 081A		SPRING, RETURN	0559-41-081A	1	M/T	
41 084		SPACER	0824-41-084	1	M/T	
41 131		ROD, PUSH	0727-41-131	1	M/T	
41 140		FORK, CLUTCH	0305-41-140	1	M/T	
			FB05-41-140A	1	M/T	-6625
41 443		GASKET	H001-41-443	1		6625-
41 644		BUSHING	0259-41-644	2	M/T	
43 028		PAD, PEDAL	FB01-43-028A	1	A/T	
			S083-43-028	2	M/T	
43 029		RUBBER, STOPPER	B001-43-029	1	A/T	
				2	M/T	
			G030-43-029	1	M/T	
43 030		PEDAL, BRAKE	FB01-43-031	1	A/T	
			FB02-43-031	1	A/T	
43 041		REST, FOOT	FB01-43-040B	1		
43 042		PAD, FOOT REST	FB01-43-042	1		
43 061A		PIPE, PEDAL	0866-43-062	1	A/T	
				2	M/T	
43 063		SPACER	FB01-43-063	1		6201-
43 070		BRACKET, MASTER CYLINDER	FB05-43-070A	1	M/T	
			FB01-43-070E	1	A/T	
43 081A		SPRING, RETURN-BRAKE	B092-41-081	1		
43 090		PLATE	FB02-43-090A	1	A/T	
43 140		FORK, BRAKE	FB01-43-140	1		
43 152		PIN, SNAP	D001-43-152	1		
43 231		BOLT, CLUTCH CUT SWITCH	GE68-43-231	2	M/T	6625-
43 301		PROTECTOR	H001-43-301	1	M/T	
46 085		BUSHING	1015-46-085	2	A/T	
				4	M/T	
46 683		PIN	0187-46-683	1	M/T	
46 785A		PIN	0604-46-785	1	M/T	
66 365A		CLIP	B258-66-365	1	M/T	6C01-
66 400		SWITCH, CLUTCH CUT	FB01-66-400	1	M/T	
67 210		SWITCH, LIGHT-BRAKE	B002-66-490A	1	M/T, W/O ACC	
			H003-66-490	1	M/T, W/ ACC	

6201 FC33\* -129445  
 6625 FC33\* -157816  
 6C01 FC33\* -525576

**4300-2 CLUTCH & BRAKE PEDALS**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
67 210 (CONT'D)				1	A/T	

**BRAKE MASTER CYLINDER & POWER BRAKE  
(W/O ANTI-LOCK BRAKE SYSTEM)**

(W/O TURBO)


(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	5 HOLES-15"/16"
CONVERTIBLE	-	-	5 HOLES-15"

(TURBO)

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



VEHICLE RESTRICTION			
BODY TYPE	HARD SUSP.	A. A. SUSP.	DISC WHEEL
COUPE	-	-	4 HOLES-14"
	x	-	5 HOLES-15"/16"
	x	x	5 HOLES-15"/16"
CONVERTIBLE	-	-	5 HOLES-15"

4340-2

**BRAKE MASTER CYLINDER & POWER BRAKE  
(W/O ANTI-LOCK BRAKE SYSTEM)**

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	43 410	SWITCH, PRESSURE	FB07-43-410	1	W/ A.A.S.	
	43 443	GASKET, VACUUM POWER ASSIST	H001-43-443	1		
	43 540	INDICATOR, LEVEL	FB01-43-540	1		
	43 550S	TANK SET, RESERVE	FB01-49-680	1		
	43 552S	CAP SET, RESERVE TANK	B093-49-580	1		
	43 640	HOSE, VACUUM	FB01-43-640	1	W/O TURBO	
	43 694	BOLT, CONNECTOR	8573-43-694	1	W/O TURBO	
	43 750A	HOLDER, P.B.V.	FB01-43-750	1		
	43 770	VALVE, CHECK	FB44-43-770	1	TURBO	
	43 800	VACUUM POWER ASSIST	FB01-43-800C	1	COUPE, NORM. SUSP.	
			FB05-43-800D	1	CONV. W/ HARD SUSP. NORM. SUSP.	
	43 830	PIPE, VACUUM	FB01-43-830A	1	W/O TURBO	
	43 836	HOSE, VACUUM	FB01-43-836	1	W/O TURBO	
			FB44-43-836B	1	TURBO	
	43 836A	HOSE, VACUUM	FB45-43-836A	2	TURBO	
	43 836C	HOSE, VACUUM	2192-43-835A	1	TURBO	
	43 840C	PIPE, VACUUM	FB01-43-840	1	W/O TURBO	
			FB44-43-840B	1	TURBO	
	43 850	PIPE, VACUUM	FB44-43-850B	1	TURBO	
	43 880	BRACKET, VACUUM PIPE	FB44-43-880B	1	TURBO	
	43 990	CYLINDER, TANDEM MASTER	FB02-43-400C	1	W/O A.A.S.	
			FB08-43-400C	1	W/ A.A.S.	
	49 610	PARTS KIT, BRAKE MASTER	HA18-49-610	1		
	49 625	CUP, SECONDARY	FB01-49-625	2		
	49 626	CUP, PRIMARY	0305-49-626	2		
	49 635	CUP, FLOATING	1708-49-635	2		
	49 640D	PARTS KIT, INNER	HA18-49-640	1		
	49 660B	BUSHING, ELBOW JOINT	0305-49-660B	2		
	49 720	REPAIR KIT	FB01-49-720	1	COUPE, NORM. SUSP.	
			FB05-49-720	1	CONV. W/ HARD SUSP. NORM. SUSP.	

**SEE ILLUSTRATION/S AT FRAME 1 - J15**

-7301

7301 FC33\* -537230


**1 - K15**



**4340A-1 BRAKE MASTER CYLINDER & POWER BRAKE  
(ANTI-LOCK BRAKE SYSTEM)**


(W/O TURBO)

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



(TURBO)

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)



4340A-2

**BRAKE MASTER CYLINDER & POWER BRAKE  
(ANTI-LOCK BRAKE SYSTEM)**


ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	41 5525	CAP SET, RESERVE TANK	B093-49-580	1		6A01-
	43 410	SWITCH, PRESSURE	FB07-43-410	1	W/O TURBO	
	43 443	GASKET, VACUUM POWER ASSIST	H001-43-443	1		
	43 540	INDICATOR, LEVEL	FB01-43-540	1		
	43 5505	TANK SET, RESERVE	FO48-49-680	1		
	43 5525	CAP SET, RESERVE TANK	GA02-49-580B	1		-6C01
	43 640	HOSE, VACUUM	FB01-43-640	1	W/O TURBO	
	43 694	BOLT, CONNECTOR	B573-43-694	1	W/O TURBO	
	43 750A	HOLDER, P.B.V.	FB01-43-750	1		
	43 770	VALVE, CHECK	FB44-43-770	1	TURBO	
	43 800	VACUUM POWER ASSIST	FB05-43-800D	1		
	43 830	PIPE, VACUUM	FB01-43-830A	1	W/O TURBO	
	43 836	HOSE, VACUUM	FB01-43-836	1	W/O TURBO	
			FB44-43-836B	1	TURBO	
	43 836A	HOSE, VACUUM	FB45-43-836A	2	TURBO	
	43 836C	HOSE, VACUUM	2192-43-836A	1	TURBO	
	43 840C	PIPE, VACUUM	FB01-43-840	1	W/O TURBO	
			FB44-43-840B	1	TURBO	
	43 850	PIPE, VACUUM	FB44-43-850B	1	TURBO	
	43 880	BRACKET, VACUUM PIPE	FB44-43-880B	1	TURBO	
	43 990	CYLINDER, TANDEM MASTER	FB55-43-400A	1	W/O TURBO	
			FB60-43-400A	1	TURBO	
	49 610	PARTS KIT, BRAKE MASTER	HA18-49-610	1		
	49 625	CUP, SECONDARY	FB01-49-625	2		
	49 626	CUP, PRIMARY	0305-49-626	2		
	49 635	CUP, FLOATING	1708-49-635	2		-7301
	49 640D	PARTS KIT, INNER	HA18-49-640	1		
	49 686B	BUSHING, ELBOW JOINT	0305-49-686B	2		
	49 720	REPAIR KIT	FB05-49-720	1		

SEE ILLUSTRATION/S AT FRAME 1 - L15

6A01 FC33\* -517640  
 6C01 FC33\* -525576  
 7301 FC33\* -537230

1 - M15

# 4360-1 BRAKE PIPINGS (W/O ANTI-LOCK BRAKE SYSTEM)




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
41 780A		BRACKET, P.B. VALVE	FB44-41-780A	1	TURBO	
43 635		CLIP, FLEXIBLE HOSE	W023-43-635	6		
43 63X		DUCT (R), AIR-BRAKE PIPE	FB01-43-63XB	1		
43 63XZ		DUCT (L), AIR-BRAKE PIPE	FB01-43-64XB	1		
43 694A		BOLT, CONNECTOR	B001-43-694A	2		
43 710		PIPE (R), BRAKE-FRONT	FB05-43-710B	1	COUPE W/ HARD SUSP. CONVERTIBLE W/ NORM. SUSP.	
43 710Z		PIPE (L), BRAKE-FRONT	FB05-43-720B	1	COUPE W/ HARD SUSP. CONV. W/ NORM. SUSP.	
43 810		HOSE, FLEXIBLE	FB01-43-810B	2		
43 810A		HOSE NO. 1, FLEXIBLE	FB05-43-810	2	COUPE W/ HARD SUSP. CONV. W/ NORM. SUSP.	
43 900A		VALVE, P.B.	FB10-43-900	1		
43 980		HOSE, FLEXIBLE	FB01-43-980	2	COUPE W/ NORM. SUSP.	
45 221		JOINT, PIPE	FB01-45-291A	1		
45 250		PIPE, BRAKE-FRONT	FB01-43-360	1		
45 280		PIPE (R), BRAKE-FRONT	FB01-45-280E	1		
45 320		PIPE (L), BRAKE-FRONT	FB01-45-320	1		
45 350		PIPE, BRAKE-REAR	FB02-43-370	1		
45 360A		PIPE, BRAKE-REAR	FB01-45-360C	1		
45 360B		PIPE (R), REAR BRAKE	FB01-45-360D	1		
45 370A		PIPE (L), REAR BRAKE	FB01-45-370D	1		
45 916		HOLDER, PIPE	FB55-45-961A	1		6625-
45 919C		CLIP, PIPE	G030-45-919	8		
45 961B		CAP	H002-45-961	9		
50 825C		NUT, CLIP	FA01-50-054	16		
58 868E		PLUG, SERVICE COVER	Q559-58-868	2		

6625 FC33\* -157816

# SECTION INDEX -- CHASSIS

STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME	STARTING LOCATION	SECT. NO.	SECTION NAME
1-C11	2500	DRIVESHAFT	1-L14	4000B	EXHAUST SYSTEM (W/O TURBO)			
1-D11	2550	REAR DRIVESHAFTS	1-C15	4000BA	EXHAUST SYSTEM (TURBO)			
1-F11	2600	REAR AXLE	1-E15	4140B	CLUTCH RELEASE & MASTER CYLINDERS (MANUAL TRANSMISSION)			
1-F11	2610	REAR BRAKE MECHANISMS	1-F15	4160	ACCELERATOR CONTROL SYSTEM			
1-H11	2710	REAR DIFFERENTIALS (W/O TURBO)(NORMAL DIFFERENTIAL)	1-G15	4200	FUEL TANK			
1-J11	2710A	REAR DIFFERENTIALS (W/O TURBO)(LIMITED-SLIP DIFFERENTIAL)	1-H15	4300	CLUTCH & BRAKE PEDALS			
1-L11	2710C	REAR DIFFERENTIALS (TURBO)(LIMITED-SLIP DIFFERENTIAL)	1-J15	4340	BRAKE MASTER CYLINDER & POWER BRAKE (W/O ANTI-LOCK BRAKE SYSTEM)			
1-N11	2800	REAR SUSPENSION MECHANISMS (W/O TURBO) (W/O AUTOMATIC ADJUSTING SUSPENSION)	1-L15	4340A	BRAKE MASTER CYLINDER & POWER BRAKE (ANTI-LOCK BRAKE SYSTEM)			
1-C12	2800A	REAR SUSPENSION MECHANISMS (W/O TURBO) (FOR AUTOMATIC ADJUSTING SUSPENSION)	1-N15	4360	BRAKE PIPINGS (W/O ANTI-LOCK BRAKE SYSTEM)			
1-D12	2800B	REAR SUSPENSION MECHANISMS (TURBO)						
1-E12	2810	REAR STABILIZER	1-C16	4360A	BRAKE PIPINGS (ANTI-LOCK BRAKE SYSTEM)			
1-F12	2830	REAR LOWER ARMS & SUB-FRAME	1-D16	4370	ANTI-LOCK BRAKE SYSTEMS			
1-H12	3200	STEERING WHEEL	1-F16	4400	PARKING BRAKE SYSTEM			
1-I12	3210	STEERING COLUMN & SHAFTS	1-G16	4500B	FUEL PIPINGS (W/O ANTI-LOCK BRAKE SYSTEM)			
1-J12	3210A	STEERING COLUMN & SHAFTS (W/ POWER STEERING)	1-H16	4500BA	FUEL PIPINGS (ANTI-LOCK BRAKE SYSTEM)			
1-K12	3220	STEERING GEAR (W/O POWER STEERING)	1-I16	4600	CHANGE CONTROL SYSTEM (AUTOMATIC TRANSMISSION)			
1-L12	3220A	STEERING GEAR (W/ POWER STEERING)						
1-M12	3230	STEERING LINKAGE SYSTEM						
1-C13	3240	POWER STEERING SYSTEM						
1-E13	3300	FRONT AXLE & BRAKE MECHANISMS (FOR NORMAL SUSPENSION)						
1-I13	3300A	FRONT AXLE & BRAKE MECHANISMS (FOR HARD SUSPENSION) (W/O ANTI-LOCK BRAKE SYSTEM)						
1-K13	3300B	FRONT AXLE & BRAKE MECHANISMS (FOR HARD SUSPENSION) (ANTI-LOCK BRAKE SYSTEM)						
1-M13	3400	FRONT SUSPENSION MECHANISMS (W/O TURBO) (W/O AUTOMATIC ADJUSTING SUSPENSION)						
1-N13	3400A	FRONT SUSPENSION MECHANISMS (W/O TURBO) (FOR AUTOMATIC ADJUSTING SUSPENSION)						
1-C14	3400B	FRONT SUSPENSION MECHANISMS (TURBO)						
1-D14	3410	CROSSMEMBER & STABILIZER						
1-E14	3700	TIRES & JACK (W/O TURBO)						
1-H14	3700A	TIRES & JACK (TURBO)						
1-J14	3900B	ENGINE & TRANSMISSION MOUNTINGS (W/O TURBO)						
1-K14	3900BA	ENGINE & TRANSMISSION MOUNTINGS (TURBO)						

# 4360A-1 BRAKE PIPINGS (ANTI-LOCK BRAKE SYSTEM)





ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
41 780A		BRACKET, P.B. VALVE	FB44-41-780A	1		
43 635		CLIP, FLEXIBLE HOSE	WV023-43-635	6		
43 63X		DUCT (R), AIR-BRAKE PIPE	FB01-43-63XB	1		
43 63XZ		DUCT (L), AIR-BRAKE PIPE	FB01-43-64XB	1		
43 694A		BOLT, CONNECTOR	B001-43-694A	2		
43 710		PIPE (R), BRAKE-FRONT	FB05-43-710B	1		
43 710Z		PIPE (L), BRAKE-FRONT	FB05-43-720B	1		
43 810		HOSE, FLEXIBLE	FB01-43-810A	2		
43 810A		HOSE NO. 1, FLEXIBLE	FB05-43-810	2		
43 900A		VALVE, P.B.	FB10-43-900	1		
45 221		JOINT, PIPE	FB01-45-291A	1		
45 240B		PIPE, BRAKE-FRONT	FB55-45-330E	1		
45 250		PIPE, BRAKE-FRONT	FO48-43-360	1		
45 280		PIPE (R), BRAKE-FRONT	FB55-45-280D	1		-6C01
			FB55-45-280E	1		6C01-
45 320		PIPE (L), BRAKE-FRONT	FB55-45-320F	1		
45 340		PIPE, BRAKE-REAR	FB55-45-340E	1		
45 350		PIPE, BRAKE-REAR	FB55-43-370	1		
45 360A		PIPE, BRAKE-REAR	FB55-45-360B	1		
45 360B		PIPE (R), REAR BRAKE	FB01-45-380D	1		
45 370A		PIPE (L), REAR BRAKE	FB01-45-370D	1		
45 902B		CLIP	UA01-45-902	1		6C01-
45 916		HOLDER, PIPE	FB55-45-961A	2		
45 916C		HOLDER, PIPE	FB55-45-951	1		6C01-
45 919C		CLIP, PIPE	G030-45-919	3		
45 961B		CAP	HC02-45-961	7		
45 964		HOLDER, PIPE-FRONT BRAKE (L)	FO48-45-964	1		-6A16
50 825C		NUT, CLIP	FA01-50-054	16		

6A16 FC33\* -519914  
6C01 FC33\* -525576

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)

(THIS ILLUSTRATION CONSISTS OF 2 PAGES)




**4370-2 ANTI-LOCK BRAKE SYSTEMS**

**SEE ILLUSTRATION/S AT FRAME 1 - D16**

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	43 310	BRACKET NO. 1, A.B.S.	FB55-43-310A	1		
	43 320	BRACKET NO. 2, A.B.S.	FB55-43-320B	1		
	43 330	BRACKET NO. 5, A.B.S.	FB55-43-330A	1		
	43 350	INSULATOR, HYDRAULIC UNIT	FB55-43-350A	1		
	43 504	JOINT, PIPE	W023-43-504	2		
	43 694A	BOLT, CONNECTOR	B001-43-694A	2		
	43 701	SENSOR (R), FRONT-A.B.S.	F051-43-70XB	1		
	43 701Z	SENSOR (L), FRONT-A.B.S.	F051-43-73XB	1		
	43 708	BOLT, REAR SENSOR	F051-43-708A	2		
	43 709	SLEEVE, GUIDE-CONTROL HUB	F051-43-709	2		
	43 711	SENSOR (R), REAR A.B.S.	F051-43-71YC	1		
	43 711Z	SENSOR (L), REAR-A.B.S.	F051-43-72YC	1		
	43 776	CLIP, ANTI-LOCK BRAKE SYSTEM	F048-43-776B	1		
	43 798	BRACKET, MAIN RELAY-A.B.S.	FB36-43-798C	1		
	43 799	JOINT, FLARE	FB55-43-799	2		
	43 7A0	HYDRAULIC UNIT, A.B.S.	F048-43-7A0E	1		
	43 7A2	RELAY, MOTOR-HYDRAULIC UNIT	F048-43-7A2	1		
	43 7A3	RELAY, VALVE-HYDRAULIC UNIT	F048-43-7A3	1		
	43 7A4	COVER 'L', HYDRAULIC UNIT	F048-43-7A4B	1		
	43 7A5	COVER 'I', HYDRAULIC UNIT	F048-43-7A5	1		
	43 7A6	RUBBER, MOUNTING-HYDRAULIC UNIT	F048-43-7A6	1		
	43 7A7	STUD, HEX-HYDRAULIC UNIT	F048-43-7A7	1		
	43 7A8	WASHER, HYDRAULIC UNIT	F048-43-7A8	1		
	43 7A9	WIRE, EARTH-HYDRAULIC UNIT	F048-43-7A9	1		
	43 7B0	ELECTRIC UNIT, A.B.S.	F048-43-7B0B	1		
	43 7C0	RELAY, MAIN-A.B.S.	F048-43-7C0	1		-7701
	43 7Z1	BRACKET, PIPE HOLDER	FB55-43-7Z1	1		7114-
	52 398	PAD, TANK PROTECTOR	0866-52-393A	1		7114-
	56 414B	BOLT, INSULATOR-FRONT HEAT	FB01-56-414	1		7114-
	67 230	WIRING, ANTI-LOCK BRAKE SYSTEM	FB55-67-230D	1		-7701
			< A > FB55-67-230E	1		7701-

7114 FC33\* -529915  
7701 FC33\* -550169

**4400-1 PARKING BRAKE SYSTEM**




ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	41 081A	SPRING, RETURN	0613-41-308	1		
	43 635	CLIP, FLEXIBLE HOSE	W023-43-635	2		
	44 010	LEVER, PARKING BRAKE	FB01-44-010B	1		
	44 031	SPRING, PARKING LEVER	G030-44-031	1		
	44 033	BUTTON, RELEASE	FB01-44-033	1		
	44 034	CAP, PARK BRAKE LEVER	FB01-44-034	1		
	44 061A	COVER	FB01-44-061B	1		
	44 062	COVER	FB01-44-062A	1		
	44 150	CABLE, PARKING	FB01-44-150B	1		
	44 187	SCREW	0866-44-187A	1		
	44 189	CLIP	0866-44-189	1		
	44 410	CABLE (R), PARKING	FB01-44-410E	2		
	44 439	CLIP, CABLE	1011-44-439	1		
			FB01-44-439A	1		
	66 840	SWITCH, PARKING LAMP	8871-66-450	1		





# 4500BA-1 FUEL PIPINGS (ANTI-LOCK BRAKE SYSTEM)




a	b	c	d	e
45-915A	45-919C	45-918	45-912D	45-919

93-5108		99351-05150	L=150MM
93-5105		99351-05400	L=400MM
93-5808		99351-08999	L=445MM
		99350-08999	L=380MM

ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
	13 157A	CLIP	8574-13-157	2		-6919
				3		6919-
	13 497	HOSE, FUEL	ESA1-13-497A	1		6919-
	45 111	PIPE, FUEL-MAIN	FB01-45-111C	1		
	45 128	HOSE, FUEL MAIN	FB01-42-611	1		
	45 146	PROTECTOR, FUEL HOSE	B986-45-146	1		6919-
	45 181A	RUBBER, MOUNTING	FA23-45-181	2		
	45 182A	SPACER	FA23-45-182	2		
	45 611	PIPE, FUEL-RETURN	FB01-45-611E	1		
	45 711	PIPE, EVAPORATION	FB01-45-711B	1		
	45 712	PIPE, EVAPORATION	FB55-45-731	1		
	45 720	PIPE, EVAPORATION-FRONT	FB55-45-721	1		
	45 722	PROTECTOR, EVAPORATION HOSE-FRONT	FB55-45-722A	1		
	45 732	PROTECTOR, EVAPORATION HOSE	FB55-45-732A	1		
	45 910E	HOLDER, PIPE	FB01-45-910	3		
	45 912D	HOLDER 'A'	FB01-45-912	7		
	45 914	HOLDER, PIPE	FB01-45-914	2		
	45 915A	HOLDER, PIPE	G037-45-913	1		
	45 915B	HOLDER, PIPE	F048-45-930	1		
	45 918	CLIP, FUEL PIPE	B075-45-918	1		
	45 919	CLIP, PIPE	FB01-45-919	1		
	45 919C	CLIP, PIPE	G030-45-919	2		
	45 920A	HOLDER 'B', PIPE	FB01-45-920	1		
	45 940	HOLDER, PIPE	FB01-45-940	1		
	45 980	HOLDER 'D', PIPE	FB01-45-980A	1		
	45 990	HOLDER 'K', PIPE-FUEL	FB01-45-990	1		
	93 5105	HOSE, FUEL	9935-10-515	1		
			9935-10-540	1		
			9935-10-8445	1		
	93 5808	HOSE	9935-80-8919	1		

6919 FC33\* -515659

**CHANGE CONTROL SYSTEM  
(AUTOMATIC TRANSMISSION)**



ITEM NO.	D-CODE	DESCRIPTION	PART NO.	QTY	MODEL/DESCRIPTION	REMARKS
43 152		PIN, SNAP	D001-43-152	2		
46 010		LEVER, SELECT	FB02-46-100D	1		
46 016		BOLT	H002-46-016A	1		
46 021		ROD, PUSH	FB02-46-100D	1		
46 030		KNOB, CHANGE LEVER BLACK	FB02-46-050E 00	1		
46 040		SWITCH, OVERDRIVE CONTROL BLACK	FB02-46-040B 00	1		
46 058		SCREW, CHANGE LEVER KNOB	FB02-46-058C	2		
46 074		LEVER, SELECT	FB02-46-074	1		
46 082C		COVER, SELECT LEVER	FB02-46-088	1		
46 084		SPACER, SELECT LEVER	1481-46-084A	4		
46 085		BUSHING	FB02-46-085	2		
46 092		BUSHING, CENTER RING	FB02-46-092	1		
46 093A		SPACER, SELECT LEVER	FB02-46-093	1		
46 110		BRACKET, LEVER	FB02-46-110	1		
46 152		SPINDLE	H002-46-152	1		
46 216		HARNES, SELECTOR LEVER	FB02-46-216B	1		
46 571		ROD, SELECTOR	FB02-46-571B	1		
46 684		BUSHING	FB02-46-684 1015-46-684A	1		
46 757A		BOOT	FB02-46-757B	1		